

8W-20 CHARGING SYSTEM

Component	Page	Component	Page
Battery . . . . .	8W-20-2	Module-Front Control . . . . .	8W-20-2
Fusible Link . . . . .	8W-20-2	Module-Integrated Power . . . . .	8W-20-2
G108 . . . . .	8W-20-2	Module-Powertrain Control . . . . .	8W-20-2
Generator . . . . .	8W-20-2	Sensor-Battery Temperature . . . . .	8W-20-2

