

## 8W-43 OCCUPANT RESTRAINT SYSTEM

<b>Component</b>	<b>Page</b>
Airbag-Driver Squib 1 . . . . .	8W-43-3
Airbag-Driver Squib 2 . . . . .	8W-43-3
Airbag-Passenger Squib . . . . .	8W-43-3
Airbag-Side Curtain-Left . . . . .	8W-43-4
Airbag-Side Curtain-Right . . . . .	8W-43-4
Clockspring . . . . .	8W-43-3
Cluster . . . . .	8W-43-2
Fuse 9 . . . . .	8W-43-5
Fuse 46 . . . . .	8W-43-2, 5
Fuse 57 . . . . .	8W-43-2
G300 . . . . .	8W-43-2, 5
G301 . . . . .	8W-43-2
Lamp-Passenger Airbag On/Off Indicator . .	8W-43-2
Module-Front Control . . . . .	8W-43-2, 5
Module-Integrated Power . . . . .	8W-43-2, 5
Module-Occupant Classification . . . . .	8W-43-5, 6

<b>Component</b>	<b>Page</b>
Module-Occupant Restraint	
Controller . . . . .	8W-43-2, 3, 4
Seat Belt-Tensioner-Driver . . . . .	8W-43-3
Seat Belt-Tensioner-Passenger . . . . .	8W-43-3
Sensor-Front Impact-Left . . . . .	8W-43-3
Sensor-Front Impact-Right . . . . .	8W-43-3
Sensor-Seat Track Position-Driver . . . . .	8W-43-5
Sensor-Seat Track Position-Passenger . . . .	8W-43-5
Sensor-Seat Weight-Left Front . . . . .	8W-43-6
Sensor-Seat Weight-Left Rear . . . . .	8W-43-6
Sensor-Seat Weight-Right Front . . . . .	8W-43-6
Sensor-Seat Weight-Right Rear . . . . .	8W-43-6
Sensor-Side Impact-Left 1 . . . . .	8W-43-4
Sensor-Side Impact-Right 1 . . . . .	8W-43-4
Switch-Passenger Airbag On/Off . . . . .	8W-43-2
Switch-Seat Belt-Driver . . . . .	8W-43-2









