

8W-02 COMPONENT INDEX

| Component | Page | Component | Page |
|---|-------------------|--|-------------|
| Actuator-Blend Door | 8W-42 | Latches-Door | 8W-61 |
| Actuator-Mode Door-Floor To Defrost | 8W-42 | Mirror-Inside Rearview | 8W-49 |
| Actuator-Mode Door-Floor To Panel | 8W-42 | Mirrors-Outside Rearview | 8W-62 |
| Actuator-Recirculation Door | 8W-42 | Module-Anti-Lock Brakes | 8W-34, 35 |
| Airbag-Driver Squibs | 8W-43 | Module-Brake Provision | 8W-54 |
| Airbag-Passenger Squib | 8W-43 | Module-Electronic Overhead | 8W-49 |
| Airbag-Side Curtain-Left | 8W-43 | Module-Front Control | 8W-13 |
| Airbag-Side Curtain-Right | 8W-43 | Module-Fuel Pump | 8W-30 |
| Amplifier-Radio | 8W-47 | Module-Hands Free | 8W-55 |
| Amplifier-Subwoofer | 8W-47 | Modules-Heated Seat | 8W-63 |
| Antenna-Satellite | 8W-47 | Module-Integrated Power | 8W-13 |
| Assembly-Exhaust Gas Recirculation Valve . . | 8W-30 | Module-Occupant Classification | 8W-43 |
| Assembly-Line Pressure Sensor/Variable Force Solenoid | 8W-31 | Module-Occupant Restraint Controller | 8W-43 |
| Assembly-Natural Vacuum Leak Detection . . | 8W-30 | Module-Powertrain Control | 8W-30, 31 |
| Assembly-Seat Motor | 8W-63 | Module-Sentry Key Remote Entry | 8W-39 |
| Assembly-Shift Motor/Mode Sensor | 8W-31 | Motor-Blower | 8W-42 |
| Assembly-Transmission Solenoid/Pressure Switch | 8W-31 | Motor-IAC | 8W-30 |
| Assembly-Transmission Solenoid/TRS | 8W-31 | Motor-Sunroof | 8W-64 |
| Backlite-Heated | 8W-48 | Motors-Window | 8W-60 |
| Battery | 8W-13 | Motor-Windshield Wiper | 8W-53 |
| Circuit Breaker-Window/Door Lock | 8W-13 | Power Outlet-Console | 8W-41 |
| Circuit Breaker-Window/Door Lock | 8W-47 | Power Outlet-Instrument Panel | 8W-41 |
| Clockspring | 8W-33, 40, 43, 47 | Pump-Washer-Windshield | 8W-53 |
| Cluster | 8W-40 | Radio | 8W-47 |
| Clutch-A/C Compressor | 8W-42 | Receiver-Satellite | 8W-47 |
| Coils-Ignition | 8W-30 | Relay-A/C Clutch | 8W-42 |
| Control-A/C-Heater | 8W-42 | Relay-Auto Shut Down | 8W-30 |
| Data Link Connector | 8W-18 | Relay-Blower Motor | 8W-42 |
| Diodes | 8W-13 | Relay-Fog Lamp | 8W-50 |
| Fuses | 8W-13 | Relay-Fuel Pump | 8W-30 |
| Fusible Link | 8W-13 | Relay-Horn | 8W-41 |
| Generator | 8W-20 | Relay-Park Lamp | 8W-50, 51 |
| Grounds | 8W-15 | Relay-Rear Window Defogger | 8W-48 |
| Heaters-Seats | 8W-63 | Relay-Starter | 8W-21 |
| Horns | 8W-41 | Relays-Trailer Tow | 8W-54 |
| Injectors-Fuel | 8W-30 | Relay-Transmission Control | 8W-31 |
| Lamps-Backup | 8W-51, 54 | Relay-Wiper High/Low | 8W-53 |
| Lamp-Center Bezel | 8W-44 | Relay-Wiper On/Off | 8W-53 |
| Lamp-Chmal-Aftermarket | 8W-51 | Resistor-Blower Motor | 8W-42 |
| Lamps-Dome | 8W-44 | Seat Belt-Tensioners | 8W-43 |
| Lamps-Fog | 8W-50 | Sensor-Ambient Air Temperature | 8W-30 |
| Lamps-Headlamps | 8W-50 | Sensor-Brake Fluid Level | 8W-34, 35 |
| Lamp-High Mounted Stop | 8W-51 | Sensor-Camshaft Position | 8W-30 |
| Lamps-License | 8W-51 | Sensor-Crankshaft Position | 8W-30 |
| Lamps-Park/Turn | 8W-50, 52 | Sensor-Engine Coolant Temperature | 8W-30 |
| Lamp-Passenger Airbag On/Off Indicator . . . | 8W-43 | Sensor-Evaporator Temperature | 8W-42 |
| Lamps-Tail/Stop/Turn | 8W-51, 52 | Sensors-Front Impact | 8W-43 |
| | | Sensor-Input Speed | 8W-31 |
| | | Sensor-Intake Air Temperature | 8W-30 |

| Component | Page |
|--|---------------|
| Sensor-Knock | 8W-30 |
| Sensor-Line Pressure | 8W-31 |
| Sensor-MAP | 8W-30 |
| Sensor-Output Speed | 8W-31 |
| Sensors-Oxygen | 8W-30 |
| Sensors-Seat Track Position | 8W-43 |
| Sensors-Seat Weight | 8W-43 |
| Sensors-Side Impact | 8W-43 |
| Sensor-Sun | 8W-40 |
| Sensor-Throttle Position | 8W-30 |
| Sensor-Transmission Range | 8W-31 |
| Sensor-Washer Fluid Level-Front Rear | 8W-53 |
| Sensors-Wheel Speed-ABS | 8W-30, 34, 35 |
| Servo-Speed Control | 8W-33 |
| Solenoid-Brake Transmission Shift | 8W-31 |
| Solenoid-EVAP/Purge | 8W-30 |
| Speakers | 8W-47 |
| Splices | 8W-70 |
| Starter | 8W-21 |
| Switch And Lamp-Glove Box | 8W-44 |
| Switch-Backup Lamp | 8W-31, 51 |
| Switch-Clutch Interlock | 8W-31 |

| Component | Page |
|--|-------------|
| Switch-Headlamp | 8W-44, 50 |
| Switch-Horn | 8W-41 |
| Switch-Ignition | 8W-13 |
| Switch-Mirror | 8W-62 |
| Switch-Multifunction | 8W-53 |
| Switch-Oil Pressure | 8W-30 |
| Switch-Parking Brake | 8W-40 |
| Switch-Passenger Airbag On/Off | 8W-43 |
| Switches-Power Window | 8W-60 |
| Switches-Remote Radio | 8W-47 |
| Switch-Seat Belt-Driver | 8W-43 |
| Switch-Seat-Driver | 8W-63 |
| Switches-Speed Control | 8W-33 |
| Switch-Stop Lamp | 8W-51 |
| Switch-Sunroof | 8W-64 |
| Switch-Tow/Haul Overdrive Off | 8W-31 |
| Switch-Transfer Case Selector | 8W-31 |
| Switches-Window/Door Lock | 8W-60, 61 |
| Transducer-A/C Pressure | 8W-42 |
| Wiring-Trailer Tow | 8W-54 |