

## 8W-02 COMPONENT INDEX

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Acc Delay	8W-12	Latch-Liftgate-Manual Release	8W-61
Actuators-Door	8W-42	Latch-Power Liftgate	8W-39, 61
Airbags	8W-43	Latches-Door	8W-61
Amplifier-Radio	8W-47	Media System-Monitor/DVD	8W-47
Assemblies-Seat-2nd Row	8W-63	Mini Fuses	8W-10
Assembly-EGR Valve	8W-30	Mirror-Inside Rearview	8W-49
Assembly-Line Pressure Sensor/Variable Force Solenoid	8W-31	Mirrors-Outside Rearview	8W-62
Assembly-Power Liftgate Drive Unit	8W-61	Module-110v Inverter	8W-56
Assembly-Shift Motor/Mode Sensor	8W-31	Module-Antilock Brakes	8W-35
Assembly-Transmission Solenoid/Pressure Switch	8W-31	Module-Brake Provision	8W-54
Assembly-Transmission Solenoid/TRS	8W-31	Module-Clock-Analog	8W-40
B+ Module	8W-10	Module-Electronic Overhead	8W-49
Battery	8W-20	Module-Front Control	8W-12, 13
Capacitor-Ignition	8W-30	Module-Fuel Pump	8W-30
Cartridge Fuses	8W-10	Module-Hands Free	8W-55
Chime-Power Liftgate	8W-61	Module-Heated Seat	8W-63
Circuit Breaker (JB)	8W-12	Module-Integrated Power	8W-13
Clockspring	8W-33, 40, 43	Module-Occupant Restraint Controller	8W-43
Cluster	8W-40, 42	Module-Park Assist	8W-56
Clutch-A/C Compressor	8W-42	Module-Power Liftgate	8W-61
Coils-Ignition	8W-30	Module-Power-Blower Motor-Front	8W-42
Controls-A/C-Heater	8W-42	Module-Powertrain Control	8W-30, 31
Data Link Connector	8W-18	Module-Seat Memory	8W-63
Display-Park Assist-Rear	8W-56	Module-Wireless Control	8W-39
Fan Module-Condenser Cooling	8W-30	Modules-Door	8W-60, 61, 62
Fuses	8W-10, 12, 13	Motor-Adjustable Pedals	8W-56
Fusible Link	8W-20	Motor-IAC	8W-30
Generator	8W-20	Motor-Rear Window Wiper	8W-53
Glass-Liftgate-Heated	8W-48	Motor-Sunroof	8W-64
Grounds	8W-15	Motor-Windshield Wiper	8W-53
Heaters-Seat	8W-63	Motors-Blower	8W-42
Horns	8W-41	Motors-Seat Adjuster	8W-63
Injectors-Fuel	8W-30	Motors-Window	8W-60
Junction Block	8W-12	Power Distribution Center	8W-10
Lamp-Center Bezel	8W-44	Power Outlets	8W-41
Lamp-High Mounted Stop	8W-51	Pump-Auxiliary Coolant	8W-42
Lamp-License Plate	8W-51	Pump-Washer-Windshield	8W-53
Lamp-Liftgate	8W-44	Radio	8W-47
Lamp-Reading-Front	8W-44	Receiver-Satellite	8W-47
Lamps-Dome	8W-44	Relay-A/C Clutch	8W-42
Lamps-Fog	8W-50	Relay-Accessory Delay	8W-12
Lamps-Footwell	8W-44	Relay-Adjustable Pedals	8W-56
Lamps-Headlamp	8W-50	Relay-Auto Shut Down	8W-30
Lamps-Park/Turn	8W-50	Relay-Fog Lamp	8W-50
Lamps-Side Marker	8W-50	Relay-Fuel Pump	8W-30
Lamps-Tail/Stop/Turn	8W-51	Relay-Horn	8W-41
Lamps-Vanity	8W-44	Relay-Park Lamp	8W-52
		Relay-Radiator Fan High	8W-30
		Relay-Radiator Fan Low	8W-30

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Relay-Rear Window Defogger . . . . .	8W-48	Sensors-Wheel Speed . . . . .	8W-35
Relay-Run Remote . . . . .	8W-10	Servo-Speed Control . . . . .	8W-33
Relay-Run/Start . . . . .	8W-10	Solenoid-Brake Transmission Shift	
Relay-Starter Motor . . . . .	8W-21	Interlock . . . . .	8W-31
Relay-Stop Lamp Inhibit . . . . .	8W-51	Solenoid-EVAP/Purge . . . . .	8W-30
Relay-Transmission Control . . . . .	8W-31	Solenoids-Multi Displacement System . . . . .	8W-30
Relays-Blower Motor . . . . .	8W-42	Spare . . . . .	8W-12
Relays-Trailer Tow . . . . .	8W-54	Speakers . . . . .	8W-47
Relays-Wiper . . . . .	8W-53	Splices . . . . .	8W-70
Resistor-Radiator Fan . . . . .	8W-30	Starter . . . . .	8W-21
Resistors-Blower Motor . . . . .	8W-42	Switch And Lamp-Glove Box . . . . .	8W-44
Seat Belt-Tensioners . . . . .	8W-43	Switch-Adjustable Pedals . . . . .	8W-56
Sensor-Accelerator Pedal Position . . . . .	8W-30	Switch-EVAP System Monitor . . . . .	8W-30
Sensor-Adjustable Pedals . . . . .	8W-56	Switch-Headlamp . . . . .	8W-40, 44, 50
Sensor-Ambient Air Temperature . . . . .	8W-42	Switch-Horn . . . . .	8W-41
Sensor-Brake Fluid Level . . . . .	8W-13, 35	Switch-Ignition . . . . .	8W-10
Sensor-Camshaft Position . . . . .	8W-30	Switch-Inverter . . . . .	8W-56
Sensor-Crankshaft Position . . . . .	8W-30	Switch-Liftgate Ajar . . . . .	8W-39
Sensor-Dynamics . . . . .	8W-35	Switch-Liftgate Release PLG . . . . .	8W-61
Sensor-Engine Coolant Temperature . . . . .	8W-30	Switch-Memory Selector . . . . .	8W-62
Sensor-Engine Oil Temperature . . . . .	8W-30	Switch-Mirror . . . . .	8W-62
Sensor-Evaporator Temperature . . . . .	8W-42	Switch-Multifunction . . . . .	8W-53
Sensor-Infrared . . . . .	8W-49	Switch-Oil Pressure . . . . .	8W-30
Sensor-Input Speed . . . . .	8W-31	Switch-Parking Brake . . . . .	8W-40
Sensor-Intake Air Temperature . . . . .	8W-30	Switch-Seat Belt-Driver . . . . .	8W-40
Sensor-Line Pressure . . . . .	8W-31	Switch-Stop Lamp . . . . .	8W-51
Sensor-MAP . . . . .	8W-30	Switch-Sunroof . . . . .	8W-64
Sensor-Oil Pressure . . . . .	8W-30	Switch-Sunroof/Liftgate PLG . . . . .	8W-61
Sensor-Output Speed . . . . .	8W-31	Switch-Tow/Haul Overdrive . . . . .	8W-31
Sensor-Park Assists . . . . .	8W-56	Switch-Traction Control . . . . .	8W-35
Sensor-Seat Track Position-Driver . . . . .	8W-43	Switch-Transfer Case Selector . . . . .	8W-31
Sensor-Steering Angle . . . . .	8W-18, 35	Switches-Heated Seat . . . . .	8W-63
Sensor-Sun . . . . .	8W-40, 42	Switches-Power Window . . . . .	8W-60
Sensor-Throttle Position . . . . .	8W-30	Switches-Remote Radio . . . . .	8W-47
Sensor-Transmission Range . . . . .	8W-31	Switches-Seat . . . . .	8W-63
Sensor-Vacuum Pressure . . . . .	8W-35	Switches-Speed Control . . . . .	8W-33
Sensor-Washer Fluid Level-Front Rear . . . . .	8W-53	Switches-Window/Door Lock . . . . .	8W-60, 61, 62
Sensors-Impact . . . . .	8W-43	Throttle Body . . . . .	8W-33
Sensors-Knock . . . . .	8W-30	Transducer-A/C Pressure . . . . .	8W-42
Sensors-Liftgate Pinch . . . . .	8W-61	Wiring-Trailer Tow 7-Way . . . . .	8W-54
Sensors-Oxygen . . . . .	8W-30		