

8W-21 STARTING SYSTEM

Component	Page	Component	Page
Battery	8W-21-3	Module-Integrated Power	8W-21-2
Fuse 1	8W-21-3	Module-Powertrain Control	8W-21-3
G110	8W-21-3	Module-Wireless Control	8W-21-2
G111	8W-21-3	Power Distribution Center	8W-21-3
G114	8W-21-2	Relay-Starter Motor	8W-21-3
G208	8W-21-2	Starter	8W-21-3
Junction Block	8W-21-2	Switch-Hood Ajar	8W-21-2
Module-Front Control	8W-21-2, 3	Switch-Ignition	8W-21-2



