

8W-54 TRAILER TOW

Component	Page
Fuse 3	8W-54-2
Fuse 9	8W-54-3
Fuse 19	8W-54-3
Fuse 21	8W-54-3
Fuse 23	8W-54-4
G114	8W-54-2
G305	8W-54-3
Junction Block	8W-54-2, 4
Lamp-High Mounted Stop	8W-54-2
Lamp-Tail/Stop/Turn-Left	8W-54-2, 4
Lamp-Tail/Stop/Turn-Right	8W-54-2, 4

Component	Page
Module-Brake Provision	8W-54-2
Module-Front Control	8W-54-3, 4
Module-Integrated Power	8W-54-3, 4
Power Distribution Center	8W-54-2, 4
Relay-Park Lamp	8W-54-3
Relay-Stop Lamp Inhibit	8W-54-2
Relay-Trailer Tow-Left	8W-54-3
Relay-Trailer Tow-Right	8W-54-3
Switch-Stop Lamp	8W-54-2
Wiring-Trailer Tow 7-Way	8W-54-2, 3, 4





