

8W-50 FRONT LIGHTING

| Component | Page |
|--------------------------------|---------------|
| Cluster | 8W-50-2 |
| Fuse 8 | 8W-50-3 |
| Fuse 10 | 8W-50-3 |
| Fuse 15 | 8W-50-2 |
| G112 | 8W-50-2, 3, 4 |
| G113 | 8W-50-2, 3, 4 |
| G208 | 8W-50-2 |
| Lamp-Fog-Left Front | 8W-50-2 |
| Lamp-Fog-Right Front | 8W-50-2 |
| Lamp-Headlamp-Left | 8W-50-4 |
| Lamp-Headlamp-Right | 8W-50-4 |

| Component | Page |
|--|---------------|
| Lamp-Park/Turn-Left Front | 8W-50-3 |
| Lamp-Park/Turn-Right Front | 8W-50-3 |
| Lamp-Side Marker-Left Front | 8W-50-3 |
| Lamp-Side Marker-Right Front | 8W-50-3 |
| Module-Front Control | 8W-50-2, 3, 4 |
| Module-Integrated Power | 8W-50-2, 3 |
| Relay-Fog Lamp | 8W-50-2 |
| Relay-Park Lamp | 8W-50-3 |
| Switch-Headlamp | 8W-50-2 |
| Switch-Inverter | 8W-50-2 |





