

## 8W - 21 STARTING SYSTEM

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Battery . . . . .	8W-21-2, 3	G300 . . . . .	8W-21-2
Brake Lamp Switch . . . . .	8W-21-2	Generator . . . . .	8W-21-2, 3
Clutch Pedal Interlock Switch . . . . .	8W-21-2, 3	Ignition Switch . . . . .	8W-21-2, 3
Engine Control Module . . . . .	8W-21-3	Integrated Power Module . . . . .	8W-21-2, 3
Front Control Module . . . . .	8W-21-2	Powertrain Control Module . . . . .	8W-21-2
Fuse 9 . . . . .	8W-21-2, 3	Starter Motor . . . . .	8W-21-2, 3
Fusible Link . . . . .	8W-21-2, 3	Starter Motor Relay . . . . .	8W-21-2, 3
G101 . . . . .	8W-21-2, 3		



