

## 8W-20 CHARGING SYSTEM

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Assembly-Natural Vacuum Leak		G107 . . . . .	8W-20-2
Detection . . . . .	8W-20-2	G108 . . . . .	8W-20-3
Battery . . . . .	8W-20-2, 3	G109 . . . . .	8W-20-3
Battery-Auxiliary . . . . .	8W-20-3	G120 . . . . .	8W-20-3
Fuse 12 . . . . .	8W-20-3	Generator . . . . .	8W-20-2, 3
Fuse 23 . . . . .	8W-20-2	Module-Engine Control . . . . .	8W-20-3
Fusible Link . . . . .	8W-20-2, 3	Module-Integrated Power . . . . .	8W-20-2, 3
G100 . . . . .	8W-20-2, 3	Module-Powertrain Control . . . . .	8W-20-2
G101 . . . . .	8W-20-2, 3	Starter . . . . .	8W-20-2, 3
G102 . . . . .	8W-20-2, 3		





