




## 8W-15 GROUND DISTRIBUTION


Component	Page	Component	Page
Amplifier-Radio	8W-15-19	Latch-Door-Passenger	8W-15-24
Amplifier-Subwoofer	8W-15-23	Latch-Door-Right Rear	8W-15-25
Assembly-Exhaust Gas Recirculation Valve	8W-15-13	Mirror-Inside Rearview	8W-15-17
Assembly-Natural Vacuum Leak Detection	8W-15-14	Mirror-Outside Rearview-Driver	8W-15-23
Backlite-Heated	8W-15-25	Mirror-Outside Rearview-Passenger	8W-15-23
Battery	8W-15-2	Module-Anti-Lock Brakes	8W-15-11
Battery-Auxiliary	8W-15-2	Module-Brake	8W-15-10, 12
Clockspring	8W-15-18	Module-Electronic Overhead	8W-15-17
Cluster	8W-15-18, 20	Module-Engine Control	8W-15-16
Clutch-A/C Compressor	8W-15-13, 15, 16	Module-Final Drive Control	8W-15-9, 11
Control-A/C-Heater	8W-15-17, 21	Module-Front Control	8W-15-5, 8
Data Link Connector	8W-15-17	Module-Fuel Pump	8W-15-4
Data Link Connector-Engine	8W-15-16	Module-Hands Free	8W-15-19
G100	8W-15-2	Module-Heated Seats	8W-15-25
G101	8W-15-2	Module-Integrated Power	8W-15-5, 7, 8, 10, 12
G102	8W-15-2	Module-Occupant Restraint Controller	8W-15-22
G103	8W-15-5, 6	Module-Powertrain Control	8W-15-13, 15
G104	8W-15-7, 8, 9, 10	Module-Sentry Key Immobilizer	8W-15-18
G105	8W-15-2	Module-Transfer Case Control	8W-15-4
G106	8W-15-11, 12	Motor-Condenser Fan	8W-15-10, 12
G107	8W-15-13, 14	Motor-Sunroof	8W-15-20
G108	8W-15-2	Motor-Windshield Wiper	8W-15-10, 12
G109	8W-15-2	Power Outlet-Console	8W-15-21
G110	8W-15-15	Power Outlet-Instrument Panel	8W-15-21
G113	8W-15-15	Power Outlet-Rear	8W-15-23
G114	8W-15-16	Pump-Washer-Windshield	8W-15-2, 11
G120	8W-15-16	Radio	8W-15-19
G121	8W-15-16	Relay-Blower Motor	8W-15-7
G201	8W-15-17, 18	Relay-Fuel Heater	8W-15-7
G202	8W-15-19	Relay-Fuel Pump	8W-15-7
G203	8W-15-20, 21	Relay-Ignition Run-Acc	8W-15-7
G204	8W-15-22	Relay-Intake Air Heater No. 1	8W-15-2
G302	8W-15-23	Relay-Intake Air Heater No. 2	8W-15-2
G303	8W-15-25	Relay-Run	8W-15-7
Gauge-Engine Oil Temperature	8W-15-17	Relay-Transmission Control	8W-15-5, 7
Generator	8W-15-14, 16	Relay-Wiper On/Off	8W-15-10, 12
Heater-Fuel	8W-15-16	Sensor-Brake Fluid Level	8W-15-5, 9
Heater-Seat Cushion-Driver	8W-15-23	Sensor-Engine Oil Temperature	8W-15-15
Heater-Seat Cushion-Passenger	8W-15-22	Sensor-Oxygen-Left Front	8W-15-14
Horn-No. 1	8W-15-10, 12	Sensor-Oxygen-Left Rear	8W-15-14, 15
Horn-No. 2	8W-15-10, 12	Sensor-Oxygen-Right Front	8W-15-14
Lamp-Bar-Tailgate	8W-15-3	Sensor-Oxygen-Right Rear	8W-15-14, 15
Lamp-Center Bezel	8W-15-21	Sensor-Transfer Case Position	8W-15-9, 13
Lamp-Clearance No. 1	8W-15-21	Sensor-Washer Fluid Level	8W-15-2, 9
Lamp-Clearance No. 2	8W-15-21	Servo-Speed Control	8W-15-6, 8
Lamp-Clearance No. 3	8W-15-21	Solenoid-Brake Transmission Shift Interlock	8W-15-20
Lamp-Clearance No. 4	8W-15-21	Solenoid-Radiator Fan	8W-15-7
Lamp-Clearance No. 5	8W-15-21	Switch-Adjustable Pedals	8W-15-21
Lamp-Dome-Rear	8W-15-20	Switch-Axle Lock	8W-15-11
Lamp-Fender-Front Left	8W-15-3	Switch-Clutch Interlock	8W-15-6, 7, 8
Lamp-Fender-Front Right	8W-15-3	Switch-Cylinder Lock-Driver	8W-15-24
Lamp-Fender-Rear Left	8W-15-3	Switch-Disconnecting Stabilizer Bar	8W-15-11
Lamp-Fender-Rear Right	8W-15-3	Switch-Door Lock-Passenger	8W-15-24
Lamp-Fog-Left	8W-15-4	Switch-Headlamp	8W-15-20
Lamp-Fog-Right	8W-15-4	Switch-Heated Seat-Driver	8W-15-21
Lamp-Glove Box	8W-15-21	Switch-Heated Seat-Passenger	8W-15-21
Lamp-Headlamp-Left	8W-15-6, 8	Switch-Ignition	8W-15-18
Lamp-Headlamp-Right	8W-15-2	Switch-Power Steering Pressure	8W-15-13
Lamp-High Mounted Stop	8W-15-20	Switch-Remote Radio-Left	8W-15-18
Lamp-License-Left	8W-15-3	Switch-Remote Radio-Right	8W-15-18
Lamp-License-Right	8W-15-3	Switch-Seat Belt-Driver	8W-15-25
Lamp-Park/Turn-Left Front	8W-15-6, 9	Switch-Seat-Driver	8W-15-23
Lamp-Park/Turn-Right Front	8W-15-2	Switch-Seat-Passenger	8W-15-22
Lamp-Reading-Front	8W-15-20	Switch-Stop Lamp	8W-15-9, 17
Lamp-Tail Stop Turn-Left	8W-15-3	Switch-Tow/Haul Overdrive	8W-15-17
Lamp-Tail Stop Turn-Right	8W-15-3	Switch-Transfer Case Selector	8W-15-4
Lamp-Underhood	8W-15-10, 12	Switch-Window/Door Lock-Driver	8W-15-23
Lamp-Vanity-Left	8W-15-20	Wiring-Trailer Tow 4-Way	8W-15-4
Lamp-Vanity-Right	8W-15-20	Wiring-Trailer Tow 7-Way	8W-15-4
Latch-Door-Driver	8W-15-24		
Latch-Door-Left Rear	8W-15-25		







● BOX  
●● EXCEPT BOX










**AWAL**









\* 5.7L AWAL ETC

