

8W-02 COMPONENT INDEX

Component	Page	Component	Page
Actuator-Blend DoorS	8W-42	Lamps-Park/Turn	8W-50, 52
Actuator-Fuel Control	8W-30	Lamp-Reading-Front	8W-44
Actuator-Mode Doors	8W-42	Lamps-Tail Stop Turn	8W-51
Actuator-Recirculation Door	8W-42	Lamp-Underhood	8W-44
Airbag-Driver Squibs	8W-43	Lamp-Vanity	8W-44
Airbag-Side Curtains	8W-43	Latches-Door	8W-39, 61
Amplifier-Radio	8W-47	Lumbar Motor-Passenger	8W-63
Amplifier-Subwoofer	8W-47	Mirror-Inside Rearview	8W-49, 55
Assembly-Exhaust Gas Recirculation Valve . .	8W-30	Mirrors-Outside Rearview	8W-62
Assembly-Natural Vacuum Leak Detection . .	8W-30	Module-Anti-Lock Brakes	8W-34, 35
Assembly-Shift Motor/Mode Sensor	8W-31	Module-Brake	8W-54
Assembly-Transmission Solenoid	8W-31	Module-Electronic Overhead	8W-49
Assembly-Transmission Solenoid/TRS	8W-31	Module-Engine Control	8W-30
Assembly-Transmission Throttle Valve	8W-31	Module-Final Drive Control	8W-31
Assembly-Winch	8W-56	Modules-Front Control	8W-13
Backlite-Heated	8W-48	Module-Fuel Pump	8W-30
Battery	8W-13, 20, 30	Module-Hands Free	8W-55
Battery-Auxiliary	8W-13	Module-Heated Seats	8W-63
Capacitor-Ignition	8W-30	Modules-Integrated Power	8W-13
Circuit Breaker-Power Window	8W-13	Module-Occupant Restraint Controller	8W-43
Clockspring	8W-33, 41, 43, 47	Module-Powertrain Control	8W-30, 31
Cluster	8W-40	Module-Sentry Key Immobilizer	8W-39
Clutch-A/C Compressor	8W-42	Module-Transfer Case Control	8W-31
Coils-Ignition	8W-30	Motor-Adjustable Pedal	8W-56
Control-A/C-Heater	8W-42	Motor-Blower	8W-42
Data Link Connectors	8W-18	Motor-Condenser Fan	8W-42
Drive-Fan-Radiator	8W-30	Motors-IAC	8W-30
Fuse Holder	8W-13	Motors-Lumbar	8W-63
Fuses	8W-13	Motor-Power Window	8W-60
Fusible Link	8W-13	Motors-Seat Adjuster	8W-63
Gauge-Engine Oil Temperature	8W-40	Motor-Sunroof	8W-64
Generator	8W-20	Motor-Windshield Wiper	8W-53
Grounds	8W-15	Power Outlets	8W-41
Heater-Fuel	8W-30	PTCS	8W-13
Heaters-Intake Air	8W-30	PTO Switch	8W-30
Heater-Seat Cushions	8W-63	Pump-Fuel Injection	8W-30
Horns	8W-41	Pump-Washer-Windshield	8W-53
Injectors-Fuel	8W-30	Radio	8W-47
Lamp-Bar-Tailgate	8W-51	Receiver-Satellite	8W-47
Lamp-Center Bezel	8W-44	Relay-Adjustable Pedals	8W-56
Lamp-CHMSL-Aftermarket	8W-51	Relay-Auto Shut Down	8W-30
Lamps-Clearance	8W-50	Relay-Blower Motor	8W-42
Lamp-Dome-Rear	8W-44	Relay-Clutch-A/C Compressor	8W-42
Lamps-Fender	8W-51	Relay-Condenser Fan	8W-13, 42
Lamps-Fog	8W-50	Relay-Fog Lamp	8W-50
Lamp-Glove Box	8W-44	Relay-Fuel Heater	8W-30
Lamps-Headlamp	8W-50	Relay-Fuel Pump	8W-30
Lamp-High Mounted Stop	8W-51	Relay-Heated Mirror	8W-62
Lamps-License	8W-51	Relay-Horn	8W-41

Component	Page	Component	Page
Relay-Ignition Run-Acc	8W-13	Solenoids-Locker	8W-31
Relay-Intake Air Heaters	8W-30	Solenoid-Radiator Fan	8W-30
Relay-Oxygen Sensor Downstream	8W-30	Solenoid-Reverse Lock-Out	8W-30
Relay-Park Lamp	8W-50, 52	Solenoid-Wastegate	8W-30
Relay-Rear Window Defogger	8W-48	Speakers	8W-47
Relay-Run	8W-13	Splices	8W-70
Relay-Starter	8W-21	Starter	8W-21
Relay-Starter Motor	8W-21	Switch-Adjustable Pedals	8W-56
Relays-Trailer Tow	8W-54	Switch-Axle Lock	8W-31
Relay-Transmission Control	8W-31	Switch-Back Up Lamp	8W-51
Relays-Wiper	8W-53	Switch-Clutch Interlock	8W-21
Resistor Block-Blower Motor	8W-42	Switch-Cylinder Lock-Driver	8W-61
Seat Belt-Tensioners	8W-43	Switch-Disconnecting Stabilizer Bar	8W-31
Sensor-Accelerator Pedal Position	8W-30	Switch-Door Lock-Passenger	8W-61
Sensor-Ambient Air Temperature	8W-49	Switch-Engine Oil Pressure	8W-30
Sensor-Battery Temperature	8W-30	Switch-Headlamp	8W-40
Sensor-Brake Fluid Level	8W-34, 35	Switches-Heated Seat	8W-63
Sensor-Camshaft Position	8W-30	Switch-Horn	8W-41
Sensor-Crankshaft Position	8W-30	Switch-Ignition	8W-13
Sensor-Engine Coolant Temperature	8W-30	Switch-Multifunction	8W-40
Sensor-Engine Oil Pressure	8W-30	Switch-Oil Pressure	8W-30
Sensor-Engine Oil Temperature	8W-30, 40	Switch-Parking Brake	8W-40
Sensor-Evaporator Temperature	8W-42	Switch-Passenger Airbag On/Off	8W-43
Sensor-Input Speed	8W-31	Switch-Power Steering Pressure	8W-30
Sensor-Intake Air Temperature	8W-30	Switches-Power Window	8W-60
Sensor-Knocks	8W-30	Switch-Push-Button Starter	8W-21
Sensor-Line Pressure	8W-31	Switches-Remote Radio	8W-47
Sensor-Map	8W-30	Switch-Remote Radio-Right	8W-47
Sensor-Output Speed	8W-31	Switches-Seat Belt	8W-40
Sensors-Oxygen	8W-30	Switches-Speed Control	8W-33
Sensors-Side Impact	8W-43	Switch-Stop Lamp	8W-33
Sensor-Temperature/Pressure Intake	8W-30	Switch-Sunroof	8W-64
Sensor-Temperature/Pressure-Map	8W-30	Switch-Tow/Haul Overdrive	8W-31
Sensor-Throttle Position	8W-30	Switch-Transfer Case Selector	8W-31
Sensor-Transfer Case Position	8W-31	Switch-Window/Door Lock-Driver	8W-60, 61, 62
Sensor-Transmission Range	8W-31	Tail/Stop Lamp	8W-52
Sensor-Washer Fluid Level	8W-53	Tail/Turn Lamp	8W-52
Sensor-Water In Fuel	8W-30	Throttle Body	8W-30
Sensors-Wheel Speed	8W-34, 35	Transducer-A/C Pressure	8W-42
Servo-Speed Control	8W-33	Wiring-Trailer Tow 4-Way	8W-54
Solenoid-Brake Transmission Shift Interlock	8W-40	Wiring-Trailer Tow 7-Way	8W-54
Solenoid-EVAP/Purge	8W-30		