

## 8W-54 TRAILER TOW

<b>Component</b>	<b>Page</b>
Fuse 1 . . . . .	8W-54-2
Fuse 15 . . . . .	8W-54-3, 4, 5
Fuse 19 . . . . .	8W-54-2
Fuse 24 . . . . .	8W-54-2
Fuse 33 . . . . .	8W-54-3, 4, 5
Fuse 46 . . . . .	8W-54-3, 4, 5
Fuse 47 . . . . .	8W-54-3, 4, 5
G104 . . . . .	8W-54-2, 3, 4, 6
G106 . . . . .	8W-54-2, 3, 4, 6

<b>Component</b>	<b>Page</b>
Module-Brake . . . . .	8W-54-2, 3
Module-Front Control . . . . .	8W-54-2, 3, 4, 5
Module-Integrated Power . . . . .	8W-54-2, 3, 4, 5
Relay-Park Lamp . . . . .	8W-54-3, 4, 5
Relay-Trailer Tow-Left Turn . . . . .	8W-54-3, 4, 5
Relay-Trailer Tow-Right Turn . . . . .	8W-54-3, 4, 5
Switch-Stop Lamp . . . . .	8W-54-2
Wiring-Trailer Tow 4-Way . . . . .	8W-54-4, 5, 6
Wiring-Trailer Tow 7-Way . . . . .	8W-54-2, 5, 6









