

8W-02 COMPONENT INDEX

Component	Page	Component	Page
Actuator-Recirculation Door	8W-42	Module-Antilock Brakes	8W-35
Actuators-Blend Door	8W-42	Module-Brake Provision	8W-54
Actuators-Mode Door	8W-42	Module-Electronic Overhead	8W-49
Airbags	8W-43	Module-Front Control	8W-13
Amplifier-Radio	8W-47	Module-Fuel Pump	8W-30
Assembly-Exhaust Gas Recirculation Valve . .	8W-30	Module-Hands Free	8W-55
Assembly-Natural Vacuum Leak Detection . .	8W-30	Module-Heated Seat	8W-63
Assembly-Shift Motor/Mode Sensor	8W-31	Module-Integrated Power	8W-13
Assembly-Transmission Solenoid/Pressure Switch	8W-31	Module-Occupant Classification	8W-43
Assembly-Transmission Solenoid/TRS	8W-31	Module-Occupant Restraint Controller	8W-43
Battery	8W-20	Module-Power-Blower Motor-Front	8W-42
Capacitor-Ignition	8W-30	Module-Powertrain Control	8W-30, 31
Circuit Breaker	8W-12	Module-Seat Memory	8W-63
Clockspring	8W-33, 40, 43	Module-Sentry Key Remote Entry	8W-39
Cluster	8W-40	Modules-Memory Mirror	8W-62
Clutch-A/C Compressor	8W-42	Motor-Adjustable Pedals	8W-56
Coils-Ignition	8W-30	Motor-IAC	8W-30
Controls-A/C	8W-42	Motor-Rear Window Wiper	8W-53
Data Link Connector	8W-18	Motors-Blower	8W-42
Fan Module-Condenser Cooling	8W-30	Motors-Seat Adjuster	8W-63
Fuses	8W-10, 12, 13	Motor-Sunroof	8W-64
Fusible Link	8W-20	Motors-Window	8W-60
Generator	8W-20	Motor-Windshield Wiper	8W-53
Glass-Liftgate-Heated	8W-48	Power Distribution Center	8W-10
Grounds	8W-15	Power Outlets	8W-41
Heaters-Cushion Pad	8W-63	Pump-Auxiliary Coolant	8W-42
Heaters-Seat Back	8W-63	Pump-Washer Windshield	8W-53
Horns	8W-41	Radio	8W-47
Injectors-Fuel	8W-30	Receiver-Satellite	8W-47
Junction Block	8W-12	Relay-A/C Clutch	8W-42
Lamp-Center Bezel	8W-44	Relay-Accessory Delay	8W-12
Lamp-High Mounted Stop	8W-51	Relay-Adjustable Pedals	8W-56
Lamp-License Plate	8W-51	Relay-Auto Shut Down	8W-30
Lamp-Liftgate	8W-44	Relay-Fog Lamp	8W-50
Lamp-Passenger Airbag On/Off Indicator . . .	8W-43	Relay-Fuel Pump	8W-30
Lamp-Reading-Front	8W-44	Relay-Horn	8W-41
Lamps-Dome	8W-44	Relay-Park Lamp	8W-52
Lamps-Fog	8W-50	Relay-Rear Window Defogger	8W-48
Lamps-Headlamp	8W-50	Relay-Run Remote	8W-10
Lamps-Park/Turn-Left Front	8W-50	Relay-Run/Start	8W-10
Lamps-Side Marker	8W-50	Relays-Blower Motor	8W-42
Lamps-Tail/Stop/Turn	8W-51	Relays-Radiator Fan	8W-30
Lamps-Vanity	8W-44	Relay-Starter Motor	8W-21
Latches-Door	8W-61	Relays-Trailer Tow	8W-54
Latch-Liftgate	8W-61	Relays-Wiper	8W-53
Media System-Monitor/Dvd	8W-47	Relay-Transmission Control	8W-31
Mirror-Inside Rearview	8W-49	Resistor-Radiator Fan	8W-30
Mirrors-Outside Rearview	8W-62	Resistors-Blower Motor	8W-42
		Seat Belts-Tensioner	8W-43

Component	Page	Component	Page
Sensor-Accelerator Pedal Position	8W-30	Starter	8W-21
Sensor-Adjustable Pedals	8W-56	Switch And Lamp-Glove Box	8W-44
Sensor-Ambient Air Temperature	8W-42	Switch-Adjustable Pedals	8W-56
Sensor-Battery Temperature	8W-20	Switches-Heated Seat	8W-63
Sensor-Brake Fluid Level	8W-35	Switches-Power Window	8W-60
Sensor-Camshaft Position	8W-30	Switches-Remote Radio	8W-47
Sensor-Crankshaft Position	8W-30	Switches-Seat	8W-63
Sensor-Engine Coolant Temperature	8W-30	Switches-Speed Control	8W-33
Sensor-EvapOrator Temperature	8W-42	Switches-Window/Door Lock	8W-60, 61
Sensor-G	8W-35	Switch-Headlamp	8W-40, 44, 50
Sensor-Infrared	8W-49	Switch-Hood Ajar	8W-13
Sensor-Intake Air Temperature	8W-30	Switch-Horn	8W-41
Sensor-Knocks	8W-30	Switch-Ignition	8W-10
Sensor-Line Pressure	8W-31	Switch-Liftgate Ajar	8W-39
Sensor-MAP	8W-30	Switch-Memory Selector	8W-62
Sensors-Front Impact	8W-43	Switch-Mirror	8W-62
Sensors-Oxygen	8W-30	Switch-Multifunction	8W-53
Sensors-Seat Track Position	8W-43	Switch-Oil Pressure	8W-30
Sensors-Seat Weight	8W-43	Switch-Parking Brake	8W-40
Sensors-Side Impact	8W-43	Switch-Power Steering Pressure	8W-30
Sensors-Speed	8W-31	Switch-Seat Belt-Driver	8W-40
Sensor-Sun	8W-40	Switch-Stop Lamp	8W-51
Sensors-Wheel Speed-ABS	8W-35	Switch-Sunroof	8W-64
Sensor-Throttle Position	8W-30	Switch-Tow/Haul Overdrive	8W-31
Sensor-Transmission Range	8W-31	Switch-Traction Control	8W-35
Sensor-Washer Fluid Level-Front Rear	8W-53	Switch-Transfer Case Selector	8W-31
Servo-Speed Control	8W-33	Throttle Body	8W-33
Solenoid-Brake Transmission Shift		Transducer-A/C Pressure	8W-42
Interlock	8W-31	Wiring-Trailer Tow 4-Way	8W-54
Solenoid-EVAP/Purge	8W-30	Wiring-Trailer Tow 7-Way	8W-54
Speakers	8W-47		
Splices	8W-70		