

8W-43 AIRBAG SYSTEM

| Component | Page | Component | Page |
|---|------------------|--|-------------|
| Airbag-Driver Squib 1 | 8W-43-4 | Seat Belt-Tensioner-Driver | 8W-43-3 |
| Airbag-Driver Squib 2 | 8W-43-4 | Seat Belt-Tensioner-Passenger | 8W-43-3 |
| Airbag-Passenger Squib | 8W-43-4 | Sensor-Front Impact-Left | 8W-43-4 |
| Airbag-Side Curtain-Left | 8W-43-2 | Sensor-Front Impact-Right | 8W-43-4 |
| Airbag-Side Curtain-Right | 8W-43-2 | Sensor-Seat Track Position-Driver | 8W-43-6 |
| Clockspring | 8W-43-4 | Sensor-Seat Track Position-Passenger | 8W-43-6 |
| Fuse 16 | 8W-43-2, 6 | Sensor-Seat Weight-Left Front | 8W-43-7 |
| Fuse 25 | 8W-43-2 | Sensor-Seat Weight-Left Rear | 8W-43-7 |
| Fuse 33 | 8W-43-6 | Sensor-Seat Weight-Right Front | 8W-43-7 |
| G201 | 8W-43-2 | Sensor-Seat Weight-Right Rear | 8W-43-7 |
| G306 | 8W-43-6 | Sensor-Side Impact-Left 1 | 8W-43-5 |
| Junction Block | 8W-43-2, 6 | Sensor-Side Impact-Left 2 | 8W-43-5 |
| Lamp-Passenger Airbag On/Off Indicator . . | 8W-43-2 | Sensor-Side Impact-Left 3 | 8W-43-5 |
| Module-Front Control | 8W-43-2, 6 | Sensor-Side Impact-Right 1 | 8W-43-5 |
| Module-Occupant Classification | 8W-43-6, 7 | Sensor-Side Impact-Right 2 | 8W-43-5 |
| Module-Occupant Restraint Controller | 8W-43-2, 3, 4, 5 | Sensor-Side Impact-Right 3 | 8W-43-5 |











