




8W-30 FUEL/IGNITION SYSTEM


Component	Page
Assembly-Exhaust Gas Recirculation Valve	8W-30-18
Assembly-Natural Vacuum Leak Detection	8W-30-15
Assembly-Transmission Solenoid/TRS	8W-30-23
Capacitor-Ignition	8W-30-7
Clockspring	8W-30-22
Cluster	8W-30-4
Coil-Ignition-No. 1	8W-30-9, 12
Coil-Ignition-No. 2	8W-30-9, 10, 11
Coil-Ignition-No. 3	8W-30-9, 12
Coil-Ignition-No. 4	8W-30-10, 11
Coil-Ignition-No. 5	8W-30-9, 12
Coil-Ignition-No. 6	8W-30-10, 11
Coil-Ignition-No. 7	8W-30-9, 12
Coil-Ignition-No. 8	8W-30-10, 11
Data Link Connector	8W-30-13
Fan Module-Condenser Cooling	8W-30-5
Fuse 10	8W-30-6
Fuse 16	8W-30-2
Fuse 18	8W-30-2, 3, 21
Fuse 22	8W-30-2, 6
Fuse 23	8W-30-5
Fuse 27	8W-30-4
Fuse 34	8W-30-2
G100	8W-30-2, 14, 18, 20
G112	8W-30-5
G114	8W-30-4, 15
Generator	8W-30-15
Injector-Fuel-No. 1	8W-30-7, 12
Injector-Fuel-No. 2	8W-30-8, 11
Injector-Fuel-No. 3	8W-30-7, 12
Injector-Fuel-No. 4	8W-30-7, 8, 11
Injector-Fuel-No. 5	8W-30-7, 8, 12
Injector-Fuel-No. 6	8W-30-8, 11
Injector-Fuel-No. 7	8W-30-8, 12
Injector-Fuel-No. 8	8W-30-7, 11
Junction Block	8W-30-2, 3, 13, 20, 21, 22
Module-Antilock Brakes	8W-30-20


Component	Page
Module-Front Control	8W-30-5, 13
Module-Fuel Pump	8W-30-3, 4
Module-Integrated Power	8W-30-3, 4, 5
Module-Powertrain Control	8W-30-2, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23
Motor-Iac	8W-30-17
Power Distribution Center	8W-30-2, 3, 6
Relay-A/C Clutch	8W-30-21
Relay-Auto Shut Down	8W-30-6, 7
Relay-Fuel Pump	8W-30-3
Relay-Radiator Fan High	8W-30-5
Relay-Radiator Fan Low	8W-30-5
Relay-Starter Motor	8W-30-23
Resistor-Radiator Fan	8W-30-5
Sensor-Accelerator Pedal Position	8W-30-21
Sensor-Camshaft Position	8W-30-15
Sensor-Crankshaft Position	8W-30-15
Sensor-Engine Coolant Temperature	8W-30-17, 18
Sensor-Intake Air Temperature	8W-30-17, 18
Sensor-Knock	8W-30-17
Sensor-Knock No. 1	8W-30-19
Sensor-Knock No. 2	8W-30-19
Sensor-Map	8W-30-16, 18
Sensor-Oxygen-Left Front	8W-30-14
Sensor-Oxygen-Left Rear	8W-30-14
Sensor-Oxygen-Right Front	8W-30-14
Sensor-Oxygen-Right Rear	8W-30-14
Sensor-Throttle Position	8W-30-16
Sensor-Transmission Range	8W-30-23
Servo-Speed Control	8W-30-23
Solenoid-EVAP/Purge	8W-30-3
Switch-Oil Pressure	8W-30-15
Switch-Power Steering Pressure	8W-30-20
Switch-Speed Control-Left	8W-30-22
Switch-Speed Control-Right	8W-30-22
Switch-Stop Lamp	8W-30-20
Throttle Body	8W-30-19































5.7L














5.7L

