

## 8W-60 POWER WINDOWS

<b>Component</b>	<b>Page</b>
Circuit Breaker . . . . .	8W-60-2
G306 . . . . .	8W-60-2
Junction Block . . . . .	8W-60-2
Module-Memory Mirror-Passenger . . . . .	8W-60-2
Motor-Window-Left Front . . . . .	8W-60-2
Motor-Window-Left Rear . . . . .	8W-60-3
Motor-Window-Right Front . . . . .	8W-60-2

<b>Component</b>	<b>Page</b>
Motor-Window-Right Rear . . . . .	8W-60-3
Relay-Accessory Delay . . . . .	8W-60-2
Switch-Power Window-Left Rear . . . . .	8W-60-3
Switch-Power Window-Right Rear . . . . .	8W-60-3
Switch-Window/Door Lock-Driver . . . . .	8W-60-2, 3
Switch-Window/Door Lock-Passenger . . . . .	8W-60-2





