

8W-63 POWER SEAT

Component	Page	Component	Page
Assembly-Seat Motor	8W-63-2	Heater-Cushion Pad-Passenger	8W-63-4
Fuse 4	8W-63-2	Module-Heated Seat	8W-63-3, 4
Fuse 58	8W-63-3	Module-Integrated Power	8W-63-2, 3
G300	8W-63-4	Switch-Heated Seat-Driver	8W-63-3
G301	8W-63-2	Switch-Heated Seat-Passenger	8W-63-3
Heater-Cushion Pad-Driver	8W-63-4	Switch-Seat-Driver	8W-63-2





