



8W-42 AIR CONDITIONING-HEATER


Component	Page	Component	Page
A/C Compressor Clutch	8W-42-16, 19	G200	8W-42-2, 3, 4, 5, 6, 8, 10, 11, 13
A/C Compressor Clutch Relay	8W-42-16, 19	G300	8W-42-9, 15
A/C Pressure Sensor	8W-42-16, 19	G302	8W-42-14
A/C-Heater Control	8W-42-2, 3, 4, 5, 6, 7, 9	Integrated Power Module	8W-42-2, 3, 8, 10, 13, 14, 16, 17, 18, 19, 20
ATC Remote Sensor	8W-42-13	Mode Door Actuator	8W-42-7, 12
Auto Temp Control	8W-42-10, 11, 12, 13, 14, 15	Passenger Blend Door Actuator	8W-42-7, 12
Battery	8W-42-17	Powertrain Control Module	8W-42-19, 20
Blower Motor Resistor	8W-42-2, 3	Radiator Fan No. 1	8W-42-17, 18, 20
Body Control Module	8W-42-6, 9, 11, 15	Radiator Fan No. 2	8W-42-18, 20
Driver Blend Door Actuator	8W-42-7, 12	Radiator Fan Relay	8W-42-20
ECM/PCM Relay	8W-42-17	Radiator Fan Relay No. 1	8W-42-17, 18
Engine Control Module	8W-42-16, 17	Radiator Fan Relay No. 2	8W-42-18
Evaporator Temperature Sensor	8W-42-7, 12	Radiator Fan Relay No. 3	8W-42-18
Front Blower Module	8W-42-13	Rear A/C-Heater Unit	8W-42-8, 9
Front Blower Motor	8W-42-2, 3, 13	Rear Auto Temp Control Switch	8W-42-15
Front Blower Motor Relay	8W-42-2, 3, 13	Rear Blower Front Control Switch	8W-42-8
Front Control Module	8W-42-2, 3, 8, 13, 14	Rear Blower Motor	8W-42-14
Fuse 10	8W-42-2, 3, 13	Rear Blower Motor Power Module	8W-42-14
Fuse 12	8W-42-8, 14	Rear Blower Motor Relay	8W-42-8, 14
Fuse 14	8W-42-10	Rear Blower Rear Control Switch	8W-42-8, 9
Fuse 16	8W-42-17	Rear Mode Motor	8W-42-14
Fuse 18	8W-42-16, 19	Rear Temperature Motor	8W-42-14
Fuse 27	8W-42-18, 20	Rear Wiper/Washer Indicator	8W-42-4
Fuselink	8W-42-17	Rear Wiper/Washer Switch	8W-42-4
G101	8W-42-19	Recirculation Door Actuator	8W-42-7, 12
G102	8W-42-18, 20		
G103	8W-42-16		

MTC EXPORT







MTC EXPORT




MTC




MTC




3 ZONE MTC







ATC



ATC





3 ZONE ATC

