




8W-30 FUEL/IGNITION SYSTEM


Component	Page	Component	Page
A/C Compressor Clutch	8W-30-20	G100	8W-30-2, 6, 15, 21
A/C Compressor Clutch Relay	8W-30-4, 20	G101	8W-30-2, 6, 7, 10, 15, 20
A/C Pressure Sensor	8W-30-13, 18, 27	G103	8W-30-20, 21, 24
Accelerator Pedal Position Sensor	8W-30-32, 34	G300	8W-30-7, 23, 32
Ambient Temperature Sensor	8W-30-8	G302	8W-30-5, 21, 31
Auto Shut Down Relay	8W-30-4, 11, 14, 16, 19	Generator	8W-30-4, 21
Battery	8W-30-2, 6, 10, 15, 20, 28	Glow Plug No. 1	8W-30-28
Battery Temperature Sensor	8W-30-8, 27	Glow Plug No. 2	8W-30-28
Body Control Module	8W-30-5, 21	Glow Plug No. 3	8W-30-28
Boost Pressure Sensor	8W-30-27	Glow Plug No. 4	8W-30-28
Brake Lamp Switch	8W-30-7, 23, 33	Glow Plug Relay	8W-30-28
Cabin Heater Assist	8W-30-24	Idle Air Control Motor	8W-30-9
Camshaft Position Sensor	8W-30-8, 26	Ignition Coil	8W-30-11, 16
Clockspring	8W-30-5, 25, 32	Ignition Switch	8W-30-10
Clutch Pedal Interlock Switch	8W-30-7	Inlet Air Temperature Sensor	8W-30-12, 17
Clutch Pedal Upstop Switch	8W-30-32	Integrated Power Module	8W-30-2, 3, 4, 5, 10, 11, 14, 16, 19, 20, 21, 22, 24, 26, 28, 30, 31, 32, 33
Crank Case Ventilation Heater	8W-30-21	Knock Sensor	8W-30-9
Crankshaft Position Sensor	8W-30-12, 17, 26	Left Speed Control Switch	8W-30-5, 25
Data Link Connector	8W-30-3, 24	Lift Pump Motor	8W-30-31
Dosing Pump	8W-30-24	Lift Pump Relay	8W-30-31
ECM/PCM Relay	8W-30-20, 22, 26, 28, 30	Manifold Absolute Pressure Sensor	8W-30-13, 18
EGR Solenoid	8W-30-15, 30	Mass Air Flow Sensor	8W-30-22
Engine Control Module	8W-30-20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35	Natural Vacuum Leak Detection Assembly	8W-30-10
Engine Coolant Temp Sensor	8W-30-13, 18, 27	Oxygen Sensor 1/1 Upstream	8W-30-6
Engine Oil Pressure Sensor	8W-30-23	Oxygen Sensor 1/2 Downstream	8W-30-6
Engine Oil Pressure Switch	8W-30-7	Powertrain Control Module	8W-30-2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19
EVAP/Purge Solenoid	8W-30-4	Radiator Fan Relay	8W-30-11, 16
Front Control Module	8W-30-2, 5, 24, 32	Radiator Fan Relay No. 1	8W-30-33
Fuel Heater	8W-30-31	Radiator Fan Relay No. 2	8W-30-33
Fuel Heater Relay	8W-30-21, 31	Radiator Fan Relay No. 3	8W-30-33
Fuel Injector No. 1	8W-30-14, 19, 29	Right Speed Control Switch	8W-30-5, 25
Fuel Injector No. 2	8W-30-14, 19, 29	Speed Control Servo	8W-30-7
Fuel Injector No. 3	8W-30-14, 19, 29	Starter Motor Relay	8W-30-5, 21
Fuel Injector No. 4	8W-30-14, 19, 29	Throttle Position Sensor	8W-30-12, 17
Fuel Injector No. 5	8W-30-19	Transmission Control Module	8W-30-28, 32, 34, 35
Fuel Injector No. 6	8W-30-19	Transmission Control Relay	8W-30-28
Fuel Pressure Sensor	8W-30-33	Transmission Range Sensor	8W-30-32
Fuel Pressure Solenoid	8W-30-22	Vehicle Speed Sensor	8W-30-9, 30
Fuel Pump Module	8W-30-5, 21	Water In Fuel Sensor	8W-30-32
Fuel Pump Relay	8W-30-5		
Fuse 15	8W-30-24, 31		
Fuse 16	8W-30-4, 11, 14, 16, 19, 20, 22, 26, 28, 30		
Fuse 17	8W-30-2, 5, 21, 31		
Fuse 18	8W-30-20		
Fuse 26	8W-30-33		
Fuselink	8W-30-28		











GAS















* 2.4L




2.4L











2.4L




























DIESEL





■ ■ GROUND (DRAIN)

