

8W-02 COMPONENT INDEX

Component	Page	Component	Page
A/C Compressor Clutch	8W-42	Dosing Pump	8W-30
A/C Compressor Clutch Relay	8W-42	DVD Screen	8W-47
A/C Pressure Sensor	8W-42	DVD/CD Changer	8W-47
A/C-Heater Control	8W-42	ECM/PCM Relay	8W-30
Accelerator Pedal Position Sensor	8W-30	EGR Solenoid	8W-30
Accessory Relay	8W-10	Electronic Control Unit	8W-64
Adjustable Pedals Motor	8W-56	Engine Control Module	8W-30
Adjustable Pedals Relay	8W-56	Engine Coolant Temp Sensor	8W-30
Adjustable Pedals Sensor	8W-56	Engine Oil Pressure Sensor	8W-30
Adjustable Pedals Switch	8W-56	Engine Oil Pressure Switch	8W-30
Airbag	8W-43	EVAP/Purge Solenoid	8W-30
Airbag On/Off Indicator Lamp	8W-43	Evaporator Temperature Sensor	8W-42
Airbag Squibs	8W-43	Floor Console Lamp	8W-44
Ambient Temperature Sensor	8W-49	Fog Lamps	8W-50
Amplifier	8W-47	Folding Mirror Relay	8W-62
Antenna	8W-47	Front Blower Module	8W-42
ATC Remote Sensor	8W-42	Front Cigar Lighter	8W-41
Auto Shut Down Relay	8W-30	Front Control Module	8W-10
Auto Temp Control	8W-42	Front Fog Lamp Relay	8W-50
B-Pillar Switches	8W-61	Front Intrusion Sensor	8W-39
Back-Up Lamp Switch	8W-51	Front Reading Lamps/Switch	8W-44
Battery	8W-20	Front Wiper High/Low Relay	8W-53
Battery Temperature Sensor	8W-20	Front Wiper On/Off Relay	8W-53
Belt Tension Sensor	8W-43	Fuel Heater	8W-30
Blend Door Actuators	8W-42	Fuel Heater Relay	8W-30
Blower Motors	8W-42	Fuel Injectors	8W-30
Blower Motor Relays	8W-42	Fuel Pressure Sensor	8W-30
Blower Motor Resistor	8W-42	Fuel Pressure Solenoid	8W-30
Body Control Module	8W-45	Fuel Pump Module	8W-30
Boost Pressure Sensor	8W-30	Fuel Pump Relay	8W-30
Brake Fluid Level Switch	8W-35	Full Open Switches	8W-61
Brake Lamp Switch	8W-30, 51	Fuselink	8W-10
Brake Transmission Shift Interlock Solenoid	8W-31	Fuses	8W-10
Cabin Heater Assist	8W-30	Generator	8W-20
Camshaft Position Sensor	8W-30	Glow Plug Relay	8W-30
CD Changer	8W-47	Glow Plugs	8W-30
Center High Mounted Stop Lamp	8W-51	Grounds	8W-15
Cinch/Release Motors	8W-61	Hands Free Module	8W-47, 55
Clockspring	8W-30, 33, 41, 43, 47	Headlamp Leveling Motors	8W-50
Clutch Pedal Interlock Switch	8W-21	Headlamp Switch	8W-50
Clutch Pedal Upstop Switch	8W-30	Headlamp Washer Pump Motor	8W-53
Controller Antilock Brake	8W-35	Headlamp Washer Relay	8W-53
Crank Case Ventilation Heater	8W-30	Headlamps	8W-50
Crankshaft Position Sensor	8W-30	Heated Seat Backs	8W-63
Cylinder Lock Switches	8W-39	Heated Seat Cushions	8W-63
Data Link Connector	8W-18	Heated Seat Modules	8W-63
Defogger Relay	8W-48	High Beam Lamps	8W-50
Door Ajar Switches	8W-39	High Note Horn	8W-41
Door Courtesy Lamps	8W-44	Hood Ajar Switch	8W-39
Door Lock Motor/Ajar Switches	8W-61	Horn Relay	8W-41
Door Lock Switches	8W-61	Horn Switch	8W-41
		Idle Air Control Motor	8W-30

Component	Page	Component	Page
Ignition Coil	8W-30	Radiator Fans	8W-42
Ignition Switch	8W-10	Radio	8W-47
Impact Sensors	8W-43	Reading Lamps	8W-44
Inlet Air Temperature Sensor	8W-30	Rear A/C-Heater Unit	8W-42
Instrument Cluster	8W-40	Rear Auto Temp Control Switch	8W-42
Instrument Panel Switch		Rear Blower Control Switches	8W-42
Bank	8W-43, 44, 52, 53, 63	Rear Blower Motor Power Module	8W-42
Integrated Power Module	8W-10	Rear Dome Lamp	8W-44
Knock Sensor	8W-30	Rear Intrusion Sensor	8W-39
Lamp Assemblies	8W-51	Rear Mode Motor	8W-42
License Lamp	8W-51, 61	Rear Temperature Motor	8W-42
Lift Pump Motor	8W-30	Rear View Mirror	8W-49, 55, 62
Lift Pump Relay	8W-30	Rear Window Defogger Grid	8W-48
Liftgate Ajar Switch	8W-39, 61	Rear Wiper Motor	8W-53
Liftgate Cinch/Release Motor	8W-61	Recirculation Door Actuator	8W-42
Liftgate Flood Lamps	8W-44	Remote Radio Switches	8W-47
Liftgate Pinch Sensors	8W-61	Repeater Lamps	8W-52
Low Beam Lamps	8W-50	Seat Belt Switches	8W-43
Manifold Absolute Pressure Sensor	8W-30	Seat Belt Tensioners	8W-43
Mass Air Flow Sensor	8W-30	Seat Weight Sensor	8W-43
Memory Seat/Mirror/Adjustable Pedals		Sentry Key Remote Entry Module	8W-39
Module	8W-56, 62, 63	Siren	8W-39
Memory Set Switch	8W-63	Sliding Door Control Modules	8W-61
Message Center	8W-40, 46	Sliding Door Latch Sensing Switches	8W-61
Mode Door Actuator	8W-42	Sliding Door Lock Motors	8W-61
Multi-Function Switch	8W-50, 52, 53	Sliding Door Motors	8W-61
Natural Vacuum Leak Detection Assembly	8W-30	Speakers	8W-47
Occupant Classification Module	8W-43	Speed Control Servo	8W-33
Occupant Restraint Controller	8W-43	Speed Control Switches	8W-33
Overhead Console	8W-49	Speed Sensors	8W-31
Oxygen Sensors	8W-30	Splices	8W-70
Park Assist Display	8W-56	Starter Motor	8W-21
Park Assist Module	8W-56	Starter Motor Relay	8W-21
Park Assist Sensors	8W-56	Sunroof Module	8W-64
Park Lamp Relay	8W-10	Sunroof Switch	8W-64
Park Lamps	8W-50	Thatcham Alarm Indicator	8W-39
Park/Turn Signal Lamps	8W-50	Thatcham Alarm Module	8W-39
Parking Brake Switch	8W-40	Throttle Position Sensor	8W-30
Power Folding Mirror Switch	8W-62	Traction Control Switch	8W-35
Power Liftgate Module	8W-61	Trailer Tow Connector	8W-54
Power Liftgate Motor	8W-61	Transmission Control Module	8W-31
Power Mirror Switch	8W-62	Transmission Control Relay	8W-31
Power Mirrors	8W-62	Transmission Range Sensor	8W-31
Power Outlets	8W-41	Transmission Solenoid/Pressure Switch	
Power Seat Circuit Breaker	8W-10	Assembly	8W-31
Power Seat Motors	8W-63	Turn Signal Lamps	8W-52
Power Seat Position Sensors	8W-63	Vehicle Speed Sensor	8W-30
Power Seat Switches	8W-63	Vent Motors	8W-60
Power Window Circuit Breaker	8W-10	Visor/Vanity Lamps	8W-44
Power Window Motors	8W-60	Washer Fluid Level Switch	8W-53
Power Window Switches	8W-60	Washer Pump Motor	8W-53
Powertrain Control Module	8W-30, 31	Water In Fuel Sensor	8W-30
PTCs	8W-10	Wheel Speed Sensors	8W-35
Radiator Fan Relays	8W-42	Wiper Module	8W-53