

8W-31 TRANSMISSION CONTROL SYSTEM

Component	Page	Component	Page
Accelerator Pedal Position Sensor	8W-31-12	Input Speed Sensor	8W-31-4, 9
Battery	8W-31-2, 5, 6, 7, 10, 11	Integrated Power Module	8W-31-2, 3, 5, 6, 8, 12
Brake Transmission Shift Interlock Solenoid	8W-31-3, 8	Output Speed Sensor	8W-31-4, 9
Data Link Connector	8W-31-12	Powertrain Control Module	8W-31-2, 3, 4, 5, 6
Engine Control Module	8W-31-8, 12	Transmission Control Module	8W-31-7, 8, 9, 10, 11, 12
Front Control Module	8W-31-3, 6, 8, 12	Transmission Control Relay	8W-31-2, 5, 7, 10, 11
Fuse 15	8W-31-2, 5	Transmission Range Sensor	8W-31-3, 4, 8, 9
Fuselink	8W-31-7, 10, 11	Transmission Solenoid/Pressure Switch Assembly	8W-31-2, 5, 6, 7, 10, 11
G101	8W-31-2, 5, 6, 7		

















