

8W-21 STARTING SYSTEM

Component	Page	Component	Page
Battery	8W-21-2, 3	G300	8W-21-2
Brake Lamp Switch	8W-21-2	Generator	8W-21-2, 3
Clutch Pedal Interlock Switch	8W-21-2, 3	Ignition Switch	8W-21-2, 3
Engine Control Module	8W-21-3	Integrated Power Module	8W-21-2, 3
Front Control Module	8W-21-2	Powertrain Control Module	8W-21-2
Fuse 9	8W-21-2, 3	Starter Motor	8W-21-2, 3
Fuselink	8W-21-2, 3	Starter Motor Relay	8W-21-2, 3
G101	8W-21-2, 3		





