


8W-10 POWER DISTRIBUTION


Component	Page	Component	Page
A/C Compressor Clutch	8W-10-22, 24, 45, 48	Front Wiper On/Off Relay	8W-10-16, 30, 60
A/C Compressor		Fuel Heater	8W-10-49
Clutch Relay	8W-10-22, 24, 44, 45, 48	Fuel Heater Relay	8W-10-24, 48, 65
Accessory Relay	8W-10-16, 31, 65	Fuel Injector No. 1	8W-10-42
Adjustable Pedals Relay	8W-10-47, 60	Fuel Injector No. 2	8W-10-42
Adjustable Pedals Switch	8W-10-40, 47	Fuel Injector No. 3	8W-10-42
Ambient Temperature Sensor	8W-10-62	Fuel Injector No. 4	8W-10-42
Amplifier	8W-10-32, 50	Fuel Injector No. 5	8W-10-42
Auto Shut Down Relay	8W-10-21, 41	Fuel Injector No. 6	8W-10-42
Auto Temp Control	8W-10-40	Fuel Pressure Solenoid	8W-10-44
Back-Up Lamp Switch	8W-10-66	Fuel Pump Module	8W-10-22, 45
Battery	8W-10-13, 14, 15, 41, 48	Fuel Pump Relay	8W-10-22, 45, 65
Blower Motor Resistor	8W-10-19, 38	Fuse 1	8W-10-15, 16, 27
Body Control Module	8W-10-25, 40, 45, 49, 50, 52, 54, 55, 56, 57, 67, 68	Fuse 2	8W-10-15, 28, 29
Brake Fluid Level Switch	8W-10-65	Fuse 3	8W-10-15, 28, 29
Brake Lamp Switch	8W-10-26, 52, 67	Fuse 4	8W-10-15, 16, 17, 30
Brake Transmission Shift Interlock		Fuse 5	8W-10-16, 31
Solenoid	8W-10-63	Fuse 6	8W-10-16, 31
Cabin Heater Assist	8W-10-23, 43, 60	Fuse 8	8W-10-17, 35
Camshaft Position Sensor	8W-10-44	Fuse 9	8W-10-17, 18, 19, 36, 37
Center High Mounted Stop Lamp	8W-10-67	Fuse 10	8W-10-19, 38
Clockspring	8W-10-61	Fuse 11	8W-10-16, 31
Clutch Pedal Interlock		Fuse 12	8W-10-19, 38
Switch	8W-10-18, 37, 54, 55, 61	Fuse 13	8W-10-20, 39
Controller Antilock		Fuse 14	8W-10-20, 21, 23, 39, 47, 60
Brake	8W-10-18, 25, 36, 37, 50, 56, 62, 67	Fuse 15	8W-10-20, 21, 22, 23, 24, 41, 43
Crank Case Ventilation Heater	8W-10-49	Fuse 16	8W-10-21, 23, 41, 43
Data Link Connector	8W-10-35, 62, 68	Fuse 17	8W-10-21, 22, 23, 24, 45, 48
Defogger Relay	8W-10-19, 20, 39, 64	Fuse 18	8W-10-22, 24, 25, 45, 48
Driver Heated Seat Module	8W-10-50	Fuse 19	8W-10-22, 24, 25, 26, 50
Driver Power Seat Switch	8W-10-50	Fuse 20	8W-10-25, 50
Driver Power Window Switch	8W-10-33, 34	Fuse 21	8W-10-25, 50
DVD/CD Changer	8W-10-40	Fuse 22	8W-10-25, 50
ECM/PCM Relay	8W-10-23, 43	Fuse 23	8W-10-25, 54, 55
EGR Solenoid	8W-10-44	Fuse 24	8W-10-25, 52
Engine Control Module	8W-10-18, 23, 24, 37, 43, 44, 48, 62, 67	Fuse 26	8W-10-25, 26, 52
Floor Console Lamp	8W-10-32	Fuse 27	8W-10-26, 52
Floor Console Power Outlet	8W-10-32, 35	Fuse 28	8W-10-16, 31
Front Blower Module	8W-10-19, 38	Fuse 30	8W-10-26, 53
Front Blower Motor Relay	8W-10-18, 19, 38, 64	Fuse 31	8W-10-26, 53
Front Cigar Lighter	8W-10-16, 32	Fuse 32	8W-10-26, 53
Front Control Module	8W-10-15, 16, 17, 18, 19, 20, 22, 24, 26, 27, 28, 29, 30, 31, 35, 36, 37, 38, 39, 45, 47, 48, 53, 54, 55, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69	Fuselink	8W-10-13, 14
Front Fog Lamp Relay	8W-10-15, 27, 64	G100	8W-10-56
Front Wiper High/Low Relay	8W-10-16, 30, 65	G101	8W-10-41, 48, 68
		G103	8W-10-68
		G300	8W-10-58, 59
		Generator	8W-10-13, 14, 44
		Glow Plug Relay	8W-10-13, 44
		Hands Free Module	8W-10-40
		Headlamp Switch	8W-10-29, 63
		Headlamp Washer Pump Motor	8W-10-26, 53
		Headlamp Washer Relay	8W-10-26, 53, 64

Component	Page
High Note Horn	8W-10-17, 35
Horn Relay	8W-10-17, 35, 60
Ignition Coil	8W-10-42
Ignition Switch	8W-10-18, 25, 36, 37, 45, 46, 49, 54, 55, 61
Instrument Cluster	8W-10-25, 52
Instrument Panel Switch Bank	8W-10-69
Integrated Power Module	8W-10-3, 4, 5, 13, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 47, 48, 49, 50, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69
Left Fog Lamp	8W-10-15, 27
Left Front Park/Turn Signal Lamp	8W-10-15, 28, 57, 66
Left Headlamp	8W-10-58
Left Headlamp Leveling Motor	8W-10-29, 63, 66
Left High Beam Lamp	8W-10-59
Left Low Beam Lamp	8W-10-59
Left Park Lamp	8W-10-29, 59, 66
Left Power Mirror	8W-10-39
Left Rear Lamp Assembly	8W-10-28, 29, 66
Left Repeater Lamp	8W-10-52
Left Sliding Door Control Module	8W-10-26, 53
Left Turn Signal Lamp	8W-10-57
License Lamp	8W-10-28, 29, 66
Lift Pump Motor	8W-10-23, 43
Lift Pump Relay	8W-10-23, 43
Mass Air Flow Sensor	8W-10-44
Memory Seat/Mirror/Adjustable Pedals Module	8W-10-50
Message Center	8W-10-52
Occupant Classification Module	8W-10-69
Occupant Restraint Controller	8W-10-64, 69
Overhead Console	8W-10-40
Park Assist Module	8W-10-45, 54
Park Lamp Relay	8W-10-15, 28, 29, 60
Passenger Airbag On/Off Indicator Lamp	8W-10-69
Passenger Folding Mirror Relay	8W-10-22, 24, 45, 48
Passenger Heated Seat Module	8W-10-51
Passenger Power Seat Switch	8W-10-51
Passenger Power Window Switch	8W-10-31
Power Liftgate Module	8W-10-26, 53
Power Mirror Switch	8W-10-22, 24, 47, 48
Power Outlet	8W-10-35
Power Seat Circuit Breaker	8W-10-25, 50


Component	Page
Power Window Circuit Breaker	8W-10-16, 31
Power Window Switch	8W-10-33
Powertrain Control Module	8W-10-18, 21, 22, 36, 41, 42, 45, 56, 62, 63, 68
PTC 4	8W-10-20, 39
PTC 7	8W-10-16, 17, 18, 35
Radiator Fan Relay	8W-10-26, 52, 56
Radiator Fan Relay No. 1	8W-10-13, 44
Radiator Fan Relay No. 2	8W-10-26, 44, 52
Radiator Fan Relay No. 3	8W-10-44
Radio	8W-10-32, 40
Rear A/C-Heater Unit	8W-10-19, 38
Rear Blower Motor Power Module	8W-10-19, 38
Rear Blower Motor Relay	8W-10-19, 20, 38, 64
Rear Power Outlet	8W-10-16, 31, 32
Rear Window Defogger Grid	8W-10-20, 39
Rear Wiper Motor	8W-10-16, 31
Right Fog Lamp	8W-10-15, 27
Right Front Park/Turn Signal Lamp	8W-10-15, 28, 57, 61
Right Headlamp	8W-10-58
Right Headlamp Leveling Motor	8W-10-29, 61, 63
Right High Beam Lamp	8W-10-59
Right Low Beam Lamp	8W-10-59
Right Park Lamp	8W-10-29, 59, 61
Right Power Mirror	8W-10-39
Right Rear Lamp Assembly	8W-10-15, 28, 29, 61, 67
Right Repeater Lamp	8W-10-52
Right Sliding Door Control Module	8W-10-26, 53
Right Turn Signal Lamp	8W-10-57
Sentry Key Remote Entry Module	8W-10-40, 46, 49, 54, 55
Siren	8W-10-40
Starter Motor	8W-10-13, 14, 18, 36, 37
Starter Motor Relay	8W-10-18, 36, 37, 54, 55
Sunroof Module	8W-10-31, 53
Thatcham Alarm Module	8W-10-40, 46, 49, 55, 68
Trailer Tow Connector	8W-10-28, 66
Transmission Control Module	8W-10-13, 62
Transmission Control Relay	8W-10-13, 21, 41
Transmission Solenoid/Pressure Switch Assembly	8W-10-41
Vehicle Speed Sensor	8W-10-43
Washer Fluid Level Switch	8W-10-61
Washer Pump Motor	8W-10-69
Wiper Module	8W-10-16, 30, 60

INTEGRATED POWER MODULE
 (FRONT VIEW)





**INTEGRATED POWER MODULE
(REAR VIEW)**



FUSES

FUSE NO.	AMPS	FUSED CIRCUIT	FUNCTION
1	20A	INTERNAL ○○○	FUSED B(+)
2	15A	INTERNAL	FUSED PARK LAMP RELAY OUTPUT (LEFT)
3	15A	INTERNAL	FUSED PARK LAMP RELAY OUTPUT (RIGHT)
4	30A	INTERNAL	FUSED B(+)
5	20A	F306 16DB/PK	FUSED ACCESSORY RELAY OUTPUT
6	20A	F307 18LB/PK ■■■■	FUSED B(+)
6	20A	F307 18LB/PK ■■■■	FUSED ACCESSORY RELAY OUTPUT
8	20A	INTERNAL	FUSED B(+)
9	40A	INTERNAL	FUSED B(+)
10	40A	C7 12DB	FUSED FRONT BLOWER MOTOR RELAY OUTPUT
11	20A	F302 18GY/PK	FUSED ACCESSORY RELAY OUTPUT
12	25A	C51 12LB/BR □□□	FUSED REAR BLOWER MOTOR RELAY OUTPUT
13	40A	C15 12DB/WT	FUSED DEFOGGER RELAY OUTPUT
14	20A	INTERNAL	FUSED B(+)(I.O.D.)
15	20A	INTERNAL ■	FUSED B(+)
15	20A	INTERNAL ○○	FUSED B(+)
16	25A	INTERNAL	FUSED B(+)
17	20A	INTERNAL	FUSED B(+)
18	15A	INTERNAL	FUSED B(+)
19	40A	A101 12VT/RD	FUSED B(+)
20	30A	A116 14YL/RD ●●●	FUSED B(+)
21	25A	A111 12DG/RD ◇◇◇	FUSED B(+)
22	40A	A110 12OR/RD	FUSED B(+)
23	10A	A106 20LB/RD	FUSED B(+)
24	20A	A701 16BR/RD	FUSED B(+)(HAZARD)
26	20A	A103 18GY/RD	FUSED B(+)
27	40A	A112 12OR/RD	FUSED B(+)
28	40A	F30 12PK/YL	FUSED ACCESSORY RELAY OUTPUT
30	40A	INTERNAL ▲▲	FUSED B(+)
31	40A	A113 12WT/RD	FUSED B(+)
32	40A	A115 12YL/RD	FUSED B(+)

- EATX GAS
- ▲▲ EXPORT
- ◇◇◇ ABS
- DIESEL
- FOG LAMPS
- HIGHLINE AUDIO
- 3 ZONE HVAC
- BATTERY POSITION
- ACCESSORY RELAY POSITION

POSITIVE TEMPERATURE COEFFICIENTS

PTC NO.	AMPS	FUSED CIRCUIT	FUNCTION
4	8A	C16 20DB/GY	FUSED DEFOGGER RELAY OUTPUT
7	13A	A105 18DB/RD	FUSED B(+)

RELAYS

**A/C
COMPRESSOR
CLUTCH
RELAY**

CAVITY	CIRCUIT	FUNCTION
30	INTERNAL	FUSED B(+)
85	C13 18LB/OR ○	A/C CLUTCH RELAY CONTROL
85	C13 20LB/OR ○○	A/C COMPRESSOR CLUTCH RELAY CONTROL
86	F202 18PK/GY ○	FUSED IGNITION SWITCH OUTPUT (RUN-START)
86	K342 16BR/WT ○○	ECM/PCM RELAY OUTPUT
87	C3 18DB/YL	A/C COMPRESSOR CLUTCH RELAY OUTPUT
87A	-	-

**ACCESSORY
RELAY**

CAVITY	CIRCUIT	FUNCTION
30	INTERNAL	B(+)
85	FCM 35	ACCESSORY RELAY CONTROL (RUN-ACC)
86	INTERNAL	B(+)
87	INTERNAL	FUSED ACCESSORY RELAY OUTPUT
87A	-	-

**AUTO
SHUT
DOWN
RELAY
(GAS)**

CAVITY	CIRCUIT	FUNCTION
30	K342 16BR/WT	ASD RELAY OUTPUT
85	K51 18BR/WT	ASD RELAY CONTROL
86	INTERNAL	FUSED B(+)
87	INTERNAL	FUSED B(+)
87A	-	-

○ GAS
○○ DIESEL

**DEFOGGER
RELAY**

CAVITY	CIRCUIT	FUNCTION
30	INTERNAL	B(+)
85	FCM 31	DEFOGGER RELAY CONTROL
86	INTERNAL	B(+)
87	INTERNAL	DEFOGGER RELAY OUTPUT
87A	-	-

**ECM/PCM
RELAY
(DIESEL)**

CAVITY	CIRCUIT	FUNCTION
30	INTERNAL	FUSED B(+)
85	K51 20BR/WT	ECM/PCM RELAY CONTROL
86	INTERNAL	FUSED B(+)
87	K342 16BR/WT	ECM/PCM RELAY OUTPUT
87A	-	-

**FRONT
BLOWER
MOTOR
RELAY**

CAVITY	CIRCUIT	FUNCTION
30	INTERNAL	B(+)
85	FCM 30	FRONT BLOWER MOTOR RELAY CONTROL
86	INTERNAL	B(+)
87	C7 12DB	FUSED FRONT BLOWER MOTOR RELAY OUTPUT
87A	-	-

**FRONT
FOG
LAMP
RELAY**

CAVITY	CIRCUIT	FUNCTION
30	INTERNAL	FUSED B(+)
85	FCM 33	FRONT FOG LAMP RELAY CONTROL
86	INTERNAL	FUSED B(+)
87	INTERNAL	FRONT FOG LAMP RELAY OUTPUT
87A	-	-

**FRONT
WIPER
HIGH/LOW
RELAY**

CAVITY	CIRCUIT	FUNCTION
30	INTERNAL	FRONT WIPER ON/OFF RELAY OUTPUT
85	FCM 34	FRONT WIPER HIGH/LOW RELAY CONTROL
86	INTERNAL	FRONT WIPER ON/OFF RELAY OUTPUT
87	W4 12BR/OR	FRONT WIPER HIGH/LOW RELAY HIGH SPEED OUTPUT
87A	W3 12BR/WT	FRONT WIPER HIGH/LOW RELAY LOW SPEED OUTPUT

**FRONT
WIPER
ON/OFF
RELAY**

CAVITY	CIRCUIT	FUNCTION
30	INTERNAL	FRONT WIPER ON/OFF RELAY OUTPUT
85	INTERNAL	FUSED B(+)
86	FCM 14	FRONT WIPER ON/OFF RELAY CONTROL
87	INTERNAL	FUSED B(+)
87A	INTERNAL	GROUND

**FUEL
HEATER
RELAY
(DIESEL)**

CAVITY	CIRCUIT	FUNCTION
30	INTERNAL	FUSED B(+)
85	Z114 18BK/LG	GROUND
86	INTERNAL	FUSED IGNITION SWITCH OUTPUT (RUN-START)
87	N1 16DB/OR	FUEL HEATER RELAY OUTPUT
87A	-	-

**FUEL
PUMP
RELAY
(GAS)**

CAVITY	CIRCUIT	FUNCTION
30	N1 18DB/OR	FUEL PUMP RELAY OUTPUT
85	K31 18BR	FUEL PUMP RELAY CONTROL
86	INTERNAL	FUSED IGNITION SWITCH OUTPUT (RUN-START)
87	INTERNAL	FUSED B(+)
87A	-	-

**HEADLAMP
WASHER
RELAY
(EXPORT)**


CAVITY	CIRCUIT	FUNCTION
30	INTERNAL	FUSED B(+)
85	FCM 32	HEADLAMP WASHER RELAY CONTROL
86	INTERNAL	FUSED B(+)
87	V53 12BR/OR	HEADLAMP WASHER RELAY OUTPUT
87A	-	-

**HORN
RELAY**

CAVITY	CIRCUIT	FUNCTION
30	INTERNAL	FUSED B(+)
85	FCM 10	HORN RELAY CONTROL
86	INTERNAL	FUSED B(+)
87	X2 18DG/OR	HORN RELAY OUTPUT
87A	-	-

**LIFT
PUMP
RELAY
(DIESEL)**


CAVITY	CIRCUIT	FUNCTION
30	INTERNAL	FUSED B(+)
85	N21 20DB/TN	LIFT PUMP RELAY CONTROL
86	F202 18PK/GY	FUSED IGNITION SWITCH OUTPUT (RUN-START)
87	N2 18DB/YL	LIFT PUMP RELAY OUTPUT
87A	-	-





FRONT CONTROL MODULE


CAV	CIRCUIT	FUNCTION
1	A1	B(+)
2	A1	B(+)
3	L43	LEFT LOW BEAM DRIVER
4	L34	RIGHT HIGH BEAM DRIVER
5	L33	LEFT HIGH BEAM DRIVER
6	L44	RIGHT LOW BEAM DRIVER
7	-	-
8	Z117, Z118, Z343, Z344	GROUND
9	A1	B(+)
10	FCM 10	HORN RELAY CONTROL
11	-	-
12	P201 ◆◆◆◆	ADJUSTABLE PEDALS RELAY CONTROL
13	FCM 13	PARK LAMP RELAY CONTROL
14	FCM 14	FRONT WIPER ON/OFF RELAY CONTROL
15	C41 ○○	CABIN HEATER ASSIST CONTROL
16	W7	WIPER PARK SWITCH SENSE
17	X3	HORN SWITCH SENSE
18	W1	WASHER FLUID LEVEL SWITCH SENSE
19	FCM 19	FUSED IGNITION SWITCH OUTPUT (START)
20	-	-
21	L78	FUSED PARK LAMP RELAY OUTPUT (RIGHT)
22	D25	PCI BUS
23	G931 ○○	AMBIENT TEMPERATURE SENSOR RETURN
24	-	-
25	G31 ○○	AMBIENT TEMPERATURE SENSOR SIGNAL
26	L13 ▲▲	HEADLAMP ADJUST SIGNAL
27	F1, F2	FCM OUTPUT (UNLOCK-RUN-START)
28	-	-
29	F100	ORC RUN ONLY DRIVER
30	FCM 30	FRONT/REAR BLOWER MOTOR RELAY CONTROL
31	FCM 31	DEFOGGER RELAY CONTROL
32	FCM 32 ▲▲	HEADLAMP WASHER RELAY CONTROL
33	FCM 33	FRONT FOG LAMP RELAY CONTROL
34	FCM 34	FRONT WIPER HIGH/LOW RELAY CONTROL
35	FCM 35	ACCESSORY RELAY CONTROL (RUN-ACC)
36	B20	BRAKE FLUID LEVEL SWITCH SENSE
37	F20	FUSED IGNITION SWITCH OUTPUT (RUN-START)
38	A1	B(+) (WHEN IPM C5 CPA IS NOT ENGAGED)
39	T2 ■	TRS REVERSE SENSE
40	-	-
41	L77	FUSED PARK LAMP RELAY OUTPUT (LEFT)
42	D123	FLASH PROGRAM ENABLE
43	Z116	GROUND
44	L50 ○○	PRIMARY BRAKE SWITCH SIGNAL
44	L50 ○	BRAKE LAMP SWITCH OUTPUT
45	W10	FRONT WASHER PUMP MOTOR CONTROL
46	W20	REAR WASHER PUMP MOTOR CONTROL
47	K32	BRAKE TRANSMISSION SHIFT INTERLOCK SOLENOID CONTROL
48	F201	ORC RUN-START DRIVER
49	-	-


○ GAS
 ○○ DIESEL
 ▲▲ EXPORT
 ■ MTX
 ◆◆◆◆ EXCEPT EXPORT EXCEPT MEMORY





























































• LHD
•• RHD











■ MTX
 ◇◇◇ ABS

























◆◆◆◆ EXCEPT EXPORT EXCEPT MEMORY


















RHD







◇◇◇ ABS
 ■■■ ABS EXCEPT EXPORT/ASSY. PLANT EVAC & FILL
 ■■■■ ABS EXCEPT EXPORT/MTX/ASSY. PLANT EVAC & FILL













FRONT CONTROL MODULE






○ DIESEL
▲▲▲ MEMORY








○○○ FOG LAMPS
▲▲ EXPORT



FRONT CONTROL MODULE







▲ EXCEPT EXPORT
 ▼ OCCUPANT SENSING

