




8W-61 POWER DOOR LOCKS


Component	Page	Component	Page
Amplifier	8W-61-7	Left Sliding Door Motor	8W-61-9
Body Control Module	8W-61-2, 3, 4, 5, 8, 11, 14, 15, 16, 17, 20	License Lamp	8W-61-19, 20
Driver Door Lock Switch	8W-61-2, 3	Liftgate Ajar Switch	8W-61-16
Front Control Module	8W-61-6, 17	Liftgate Cinch/Release Motor	8W-61-19
Fuse 14	8W-61-5	Liftgate Left Pinch Sensor	8W-61-19
Fuse 19	8W-61-2, 3, 4, 15	Liftgate Right Pinch Sensor	8W-61-19
Fuse 31	8W-61-8	Memory Seat/Mirror/Adjustable Pedals Module	8W-61-6
Fuse 32	8W-61-17	Overhead Console	8W-61-7
G200	8W-61-5	Passenger Door Lock Switch	8W-61-2, 3
G300	8W-61-2, 3, 4, 8, 9, 10, 15	Power Liftgate Module	8W-61-17, 18, 19, 20
G301	8W-61-2, 3, 4, 11, 12, 13, 15	Power Liftgate Motor	8W-61-18
G302	8W-61-17	Right B-Pillar Switch	8W-61-11
G303	8W-61-16, 19, 20	Right Cinch/Release Motor	8W-61-12
Integrated Power Module	8W-61-2, 3, 4, 5, 6, 8, 11, 15, 17	Right Front Door Lock Motor/Ajar Switch	8W-61-4
Left B-Pillar Switch	8W-61-8	Right Full Open Switch	8W-61-12
Left Cinch/Release Motor	8W-61-9	Right Sliding Door Control Module	8W-61-7, 11, 12, 13, 14
Left Front Door Lock Motor/Ajar Switch ..	8W-61-4	Right Sliding Door Latch Sensing Switch	8W-61-11, 13
Left Full Open Switch	8W-61-9	Right Sliding Door Lock Motor	8W-61-14
Left Sliding Door Control Module	8W-61-6, 8, 9, 10, 14	Right Sliding Door Lock Motor/Ajar Switch	8W-61-15
Left Sliding Door Latch Sensing Switch	8W-61-8, 10	Right Sliding Door Motor	8W-61-12
Left Sliding Door Lock Motor	8W-61-14	Sentry Key Remote Entry Module	8W-61-5
Left Sliding Door Lock Motor/Ajar Switch	8W-61-15		





RHD















▼▼▼ SIDE AIRBAG
 ▼▼▼▼ EXCEPT SIDE AIRBAG










POWER SLIDING DOOR







POWER SLIDING DOOR





POWER RELEASE





POWER LIFTGATE

