




## 8W-44 INTERIOR LIGHTING


<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
A/C-Heater Control . . . . .	8W-44-8	Instrument Panel Switch Bank . . . . .	8W-44-7
Accessory Relay . . . . .	8W-44-4	Integrated Power Module . . . . .	8W-44-4
Auto Temp Control . . . . .	8W-44-8	Left Liftgate Flood Lamp . . . . .	8W-44-9, 10
Body Control Module . . . . .	8W-44-2, 3, 4, 5, 7, 8, 9, 10	Left Mid Reading Lamp . . . . .	8W-44-3
Driver Door Courtesy Lamp . . . . .	8W-44-2	Left Rear Reading Lamp . . . . .	8W-44-3
Floor Console Lamp . . . . .	8W-44-4, 5	Left Visor/Vanity Lamp . . . . .	8W-44-5, 6
Floor Console Power Outlet . . . . .	8W-44-4	Overhead Console . . . . .	8W-44-5
Front Control Module . . . . .	8W-44-4	Passenger Door Courtesy Lamp . . . . .	8W-44-2
Front Reading Lamps/Switch . . . . .	8W-44-2, 4, 5	Radio . . . . .	8W-44-7
Fuse 6 . . . . .	8W-44-4	Rear Auto Temp Control Switch . . . . .	8W-44-8
G200 . . . . .	8W-44-7, 8	Rear Blower Rear Control Switch . . . . .	8W-44-8
G300 . . . . .	8W-44-2, 8	Rear Dome Lamp . . . . .	8W-44-3, 5
G301 . . . . .	8W-44-2, 3, 5, 6	Rear Power Outlet . . . . .	8W-44-4
G302 . . . . .	8W-44-4	Right Liftgate Flood Lamp . . . . .	8W-44-9, 10
G303 . . . . .	8W-44-9, 10	Right Mid Reading Lamp . . . . .	8W-44-3
Headlamp Switch . . . . .	8W-44-3	Right Rear Reading Lamp . . . . .	8W-44-3, 4
Instrument Cluster . . . . .	8W-44-7	Right Visor/Vanity Lamp . . . . .	8W-44-5, 6














△ HEATED SEATS  
 △△ EXCEPT HEATED SEATS

