

8W-91 CONNECTOR/GROUND/SPLICE LOCATION

TABLE OF CONTENTS

page

CONNECTOR/GROUND/SPLICE LOCATION
 DESCRIPTION 1

CONNECTOR/GROUND/SPLICE LOCATION

DESCRIPTION

This section provides illustrations identifying connector, ground, and splice locations in the vehicle.

Connector, ground, and splice indexes are provided. Use the wiring diagrams in each section for connector, ground, and splice identification. Refer to the appropriate index for the proper figure number. For items that are not shown in this section N/S is placed in the Fig. column.

CONNECTORS

CONNECTOR NAME/NUMBER	COLOR	LOCATION	FIG.
A/C Compressor Clutch	LTGY	Top of A/C Compressor	10, 11, 15, 17, 18
A/C Pressure Sensor	GY	At Throttle Body	9, 10, 15, 16, 17
A/C-Heater Control C1 (MTC)	BK/RD	Rear of Control	20, 23, 25
A/C-Heater Control C2 (MTC)	BK/BL	Rear of Control	20, 23, 25
Accelerator Pedal Position Sensor (Diesel)		At Accelerator Pedal	42
Adjustable Pedals Module (Except Export)		Near Brake Lamp Switch	N/S
Adjustable Pedals Motor		On Pedal Support	N/S
Adjustable Pedals Relay (Except Export)		Left Side Engine Compartment	6
Adjustable Pedals Sensor		On Adjustable Pedals Motor	N/S
Adjustable Pedals Switch (Except Export)		Left Side Kick Panel	41
Ambient Temperature Sensor (Except Base)	BK	On Radiator Closure Panel	1
Amplifier C1	NAT	Right Quarter Panel	48
Amplifier C2	NAT	Right Quarter Panel	48
ATC Remote Sensor		Above ATC Control	N/S
Auto Temp Control C1	NAT	Rear of Control	20
Auto Temp Control C2	BK	Rear of Control	20
Auto Temp Control C3 (MTX)		Rear of Control	N/S
Back-Up Lamp Switch	BK	On Transmission	16
Battery Temperature Sensor	BK	At Battery	N/S
Blower Motor Resistor C1 (MTC)	BK	Right Side of HVAC	N/S
Blower Motor Resistor C2 (MTC)	BK	Right Side of HVAC	N/S
Body Control Module C1	BK	Under Left Instrument Panel	41, 42

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

CONNECTOR NAME/NUMBER	COLOR	LOCATION	FIG.
Body Control Module C2	BK/GN	Under Left Instrument Panel	41, 42
Body Control Module C3	BK/WT	Under Left Instrument Panel	41, 42
Body Control Module C4	BK/GY	Under Left Instrument Panel	20, 21, 30
Body Control Module C5	BK	Under Left Instrument Panel	20, 21, 30
Boost Pressure Sensor (Diesel)	BK	Top Left of Engine	15
Brake Fluid Level Switch	BK	On Master Cylinder	6
Brake Lamp Switch	BK	At Top Of Brake Pedal	41, 42
Brake Transmission Shift Interlock Solenoid (EATX)	BK	Near Steering Column	20, 21, 22, 31
C100	BK	Left Fender Shield	5, 11
C101	LTGY	Left Fender Shield	5
C102 (Gas)	BK	At Fuel Rail	11, 17
C103 (Diesel)	BK	Left Side Engine Compartment	N/S
C104 (Except Export	LTGY	Near Controller Antilock Brake	18
C106 (Export)	BK/YL	Near Left Headlamp Leveling Motor	N/S
C107 (Export)	BK/YL	Near Right Headlamp Leveling Motor	N/S
C111 (EATX)	LTGY	Left Front Engine	11
C112 (Gas)	BK	Near T/O for C101	N/S
C200	GY	Left Side Instrument Panel	20, 21, 30, 41, 42
C202	GY	Right Side Instrument Panel A/C Heater Unit	20, 24, 29
C204 (Premium	NAT	Rear of Radio	50
C206	BK	Near Radio	20
C207		Near Radio	N/S
C300 (LHD)	BK	Left Front Door Lower	36, 43
C300 (RHD)	BK	Right Front Door Lower	N/S
C301	LTGY	Left Front Door Upper	36, 43
C302	LTGY	Right Front Door Upper	8, 39, 44
C303	BK	Right Front Door Lower	8, 39, 44
C304 (LHD)	YL	Left Wire Track Seat to Body	32
C305	GY	Left Wire Track Seat to Body	32 33
C306 (RHD)	YL	Right Wire Track Seat to Body	33
C307	YL	Right Wire Track Seat to Body	N/S
C308 (Except Side Airbags)	GN	Left Rear Sliding Door	40
C309 (Except Side Airbags)	GN/GY	Right Rear Sliding Door	32, 33, 39
C310 (Front Console)	BK	At Front Console	34
C311 (3 Zone HVAC)	GY	Rear A/C Switch	40
C312	GY	Right B Pillar	33, 39, 50
C313 (Rear Console/Export)	BK	At Rear Console	34
C314	BK	Left Side Liftgate	49
C315 (Power Liftgate)	BK	Right Side Liftgate	49
C316 (Power Sliding Door)	BK	Wire Track to Sliding Door	N/S

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

CONNECTOR NAME/NUMBER	COLOR	LOCATION	FIG.
C317 (Power Sliding Door)	BK	Right Sliding Door	32, 45
C318 (Trailer Tow)	BK	Left Quarter	N/S
C319 (Trailer Tow)			
C320	DKGY	Driver Power Seat on Seat Harness	N/S
C321	DKGY	Under Passenger Seat	N/S
C322 (Memory)	BK	On Seat Harness to Body	32
C324 (Manual Sliding Door)	BK	Left Sliding Door	N/S
C325 (Manual Sliding Door)	BK	Right Sliding Door	32
C328 (Sunroof)		Left Quarter Panel	47
C329 (Diesel)	BK	Near Fuel Tank	N/S
C330 (Diesel)	LTGY	Near Throttle Body	15, 16
C331 (Diesel)	BK	Left Rear Engine Compartment	N/S
C332 (3 Zone ATC)	BK/LTGN	Near T/O for Right Rear Lamp Assembly	48
C333 (Except Export	DKGY	Left Side Instrument Panel	21
C334	BK	Right Quarter Panel	48
C335	LTGY	Near Fuel Tank	34
Cabin Heater Assist C1 (Diesel)	BK	Top of Engine	N/S
Cabin Heater Assist C2 (Diesel)	BK	Top of Engine	N/S
Camshaft Position Sensor (Gas)	BK	Rear of Cylinder Head Right Side of Engine	11, 17
Camshaft Position Sensor (Diesel)	BK	Rear of Cylinder Head	15, 16
CD Changer		Behind CD Changer	N/S
Center High Mounted Stop Lamp	BK	At Lamp	49
Clockspring - C1	WT	Steering Column	20, 21, 22, 23, 31
Clockspring - C2	YL	Steering Column	20, 21, 22, 23, 31
Clockspring - C3	BK	Steering Column	N/S
Clockspring - C4		Steering Column	N/S
Clutch Pedal Interlock Switch (MTX)	BK	At Switch/Driver Side	42
Clutch Pedal Upstop Switch (Diesel)	RD	At Switch/Driver Side	42
Controller Anti-Lock Brake	BK	Right Side of Engine Compartment	11, 16, 17, 18
Crank Case Ventilation Heater (Diesel)	BK	Top of Cylinder Head	15
Crankshaft Position Sensor (Diesel)	BK	Rear of Engine	16
Crankshaft Position Sensor (Gas)	BK	Rear of Engine	13, 17
Data Link Connector	BK	Lower Instrument Panel Near Steering Column	41, 42
Dosing Pump (Diesel)	BK	Top of Engine	N/S
Driver Airbag Squib1	BN/YL	Steering Column	N/S
Driver Airbag Squib2	BK/YL	Steering Column	N/S

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

CONNECTOR NAME/NUMBER	COLOR	LOCATION	FIG.
Driver Blend Door Actuator	GY	On HVAC	N/S
Driver Door Courtesy Lamp	GY	At Lamp	43
Driver Door Lock Switch	BK	At Switch	43
Driver Heated Seat Back	LTGN	At Seat	N/S
Driver Heated Seat Cushion	BK	At Seat	N/S
Driver Heated Seat Module C1	GY	Driver Heated Seat	N/S
Driver Heated Seat Module C2	GY	Driver Heated Seat Back	N/S
Driver Heated Seat Module C3	GN	At Seat	N/S
Driver Knee Blocker Airbag Squib	YL	Below Steering Column	20
Driver Power Seat Front Riser Motor	RD	At Seat	N/S
Driver Power Seat Front Riser Position Sensor	BK	At Seat	N/S
Driver Power Seat Horizontal Motor	BK	At Seat	N/S
Driver Power Seat Horizontal Position Sensor	BK	At Seat	N/S
Driver Power Seat Rear Riser Motor	RD	At Seat	N/S
Driver Power Seat Rear Riser Position Sensor	BK	At Seat	N/S
Driver Power Seat Recliner Motor	GN	At Seat	N/S
Driver Power Seat Recliner Position Sensor	BK	At Seat	N/S
Driver Power Seat Switch	GN	At Switch	N/S
Driver Power Window Motor	RD	At Motor	43
Driver Power Window Switch (LHD Low Line)	LTGY	At Switch	43
Driver Power Window Switch (LHD Except Low Line)	LTGN	At Switch	N/S
Driver Power Window Switch (RHD)	NAT	At Switch	N/S
Driver Seat Belt Switch	WT	At Switch on Seat Harness	N/S
Driver Seat Belt Tensioner	YL	On Seat Harness	N/S
DVD Screen	BK	Headliner	50
DVD/CD Changer C1	BK	Below Radio	N/S
DVD/CD Changer C2		Below Radio	N/S
EGR Solenoid (Diesel)	LTGY	Above Transmission Right Side of Engine	15
EGR Solenoid (3.3L)	BK	Above A/C Compressor Right Side of Engine	18
Engine Control Module C1 (Diesel)	BK	Right Side of Engine	N/S
Engine Control Module C2 (Diesel)	BK	Right Side of Engine	N/S

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

CONNECTOR NAME/NUMBER	COLOR	LOCATION	FIG.
Engine Coolant Temp Sensor (Gas)	BK	On Cylinder Block	N/S
Engine Oil Pressure Sensor (Diesel)	BK	Rear of Engine	16
Engine Coolant Temp Sensor (Diesel)	BL	On Cylinder Block	15
Engine Oil Pressure Switch (Gas)	LTGN	On Cylinder Block	12, 18
Engine Starter Motor		At Starter Motor	13, 15, 18
EVAP/Purge Solenoid (Gas)	BK	Right Motor Mount	10, 17
Evaporator Temperature Sensor	BK	Right Side of HVAC	N/S
Floor Console Lamp	BK	At Lamp	N/S
Floor Console Power Outlet	RD	At Front Console	N/S
Front Blower Module C1 (ATC)	BK	On HVAC	N/S
Front Blower Module C2 (ATC)	BK	On HVAC	N/S
Front Cigar Lighter	RD/NAT	Rear of Lighter	20, 23, 25
Front Control Module	BK	In Integrated Power Module	N/S
Front Intrusion Sensor (United Kingdom)	BK	At Sensor	N/S
Front Reading Lamps/Switch	BK	At Switch	N/S
Fuel Heater (Diesel)	BK	Left Rear Engine Compartment	N/S
Fuel Injector No.1 (2.4L/3.3L/3.8L)	BK	At Fuel Injector	N/S
Fuel Injector No.1 (Diesel)	BK	At Fuel Injector	15
Fuel Injector No.2 (2.4L/3.3L/3.8L)	BK	At Fuel Injector	N/S
Fuel Injector No.2 (Diesel)	BK	At Fuel Injector	15
Fuel Injector No.3 (2.4L/3.3L/3.8L)	BK	At Fuel Injector	N/S
Fuel Injector No.3 (Diesel)	BK	At Fuel Injector	15
Fuel Injector No.4 (2.4L/3.3L/3.8L)	BK	At Fuel Injector	N/S
Fuel Injector No.4 (Diesel)	BK	At Fuel Injector	15
Fuel Injector No.5 (3.3L/3.8L)	BK	At Fuel Injector	N/S
Fuel Injector No.6 (3.3L/3.8L)	BK	At Fuel Injector	N/S
Fuel Pressure Sensor (Diesel)	BK	Top Left of Engine	15
Fuel Pressure Solenoid (Diesel)		Right Front Engine	15
Fuel Pump Module	LTGY	Side of Fuel Tank	34
Generator	BK	Rear of Generator	11, 15, 17, 18
Glow Plug No.1 (Diesel)		Top of Engine	N/S
Glow Plug No.2 (Diesel)		Top of Engine	15
Glow Plug No.3 (Diesel)		Top of Engine	15
Glow Plug No.4 (Diesel)		Top of Engine	15
Glow Plug Relay (Diesel)	BK	Near Transmission	15, 16
Hands Free Module C1		Instrument Panel	N/S

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

CONNECTOR NAME/NUMBER	COLOR	LOCATION	FIG.
Hands Free Module C2	BK	Instrument Panel	N/S
Hands Free Module C3		Instrument Panel	N/S
Headlamp Switch	BK	Rear of Switch	20, 21, 30
Headlamp Washer Pump Motor (Export)	BK	At Motor	3
High Note Horn	BK	Left Frame Rail	5
Hood Ajar Switch (Export)	BK	Left Fender	6
Idle Air Control Motor (Gas)	BK	On Throttle Body	10, 11 17
Ignition Coil (2.4L)	BK	Top of Valve Cover	10, 11
Ignition Coil (3.3L/ 3.8L)	DKGY	Top of Engine	17, 18
Ignition Switch	BK	Rear of Switch at Steering Column	20, 21, 22, 23, 31
Inlet Air Temperature Sensor	BK	Top Left of Engine	9, 10, 11, 17
Input Speed Sensor	GY	Front of Transmission	14, 19
Instrument Cluster	BK	Rear of Cluster	20, 21, 28
Instrument Panel Switch Bank (Heated Seats)	BK	Right Center of Instrument Panel	20, 23, 25
Instrument Panel Switch Bank (Except Heated Seats)		Right Center of Instrument Panel	20, 23, 25
Integrated Power Module C1		Left Fender Shield	7
Integrated Power Module C2	GN/BL	Left Fender Shield	7
Integrated Power Module C3		Left Fender Shield	7, 11
Integrated Power Module C4	BL	Left Fender Shield	7, 11
Integrated Power Module C5	BK	Left Fender Shield	7
Integrated Power Module C6	NAT	Left Fender Shield	7
Integrated Power Module C7		Left Fender Shield	7
Integrated Power Module C8	OR	Left Fender Shield	7
Integrated Power Module C9	BK	Left Fender Shield	7
Knock Sensor (Except Export)	BK	At Engine Block	11
Left B Pillar Switch (Power Sliding Door)	GY	Left B Pillar	40
Left Cinch/Release Motor (Power Sliding Door)	GY	Left Sliding Door	N/S
Left Curtain Airbag Squib		Rear of Left Roof Rail	47
Left Cylinder Lock Switch	BK	At Switch	43
Left Door Speaker	BK	At Speaker	43
Left Fog Lamp	BK	At Lamp	5
Left Front Door Ajar Switch (Base)	BK	At Switch	N/S
Left Front Door Lock Motor/Ajar Switch (Except Base)	BK	Left Door	43
Left Front Impact Sensor	BK	Near T/O for C101	5
Left Front Park/Turn Signal Lamp (Except Export)	DKGY	At Lamp	1
Left Front Wheel Speed Sensor	GY	Left Fender Side Shield	5, 11

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

CONNECTOR NAME/NUMBER	COLOR	LOCATION	FIG.
Left Full Open Switch (Power Sliding Door)	BK	Left Sliding Door	N/S
Left Headlamp Caravan/Voyager (Except Export)	BK	At Lamp	1
Left Headlamp (Town & Country)	GN	At Lamp	1
Left Headlamp Leveling Motor (Export)	WT	At Motor	N/S
Left High Beam Lamp (Export)	BK	At Lamp	N/S
Left Instrument Panel Speaker	WT	At Speaker	20, 21, 27
Left Liftgate Flood Lamp (Power Liftgate)	GY	At Lamp	49
Left Low Beam Lamp (Export)	BK	At Lamp	N/S
Left Mid Reading Lamp (Premium/Luxury)	GY	At Lamp	N/S
Left Park Lamp (Export)	BK	At Lamp	NS
Left Power Mirror	BK	At Mirror	27
Left Rear Lamp Assembly	BK	At Lamp	47
Left Rear Pillar Speaker (Highline Audio)	BK	Left of Liftgate	47
Left Rear Reading Lamp (Luxury)	GY	At Lamp	N/S
Left Rear Speaker (Highline)	BK/RD	At Speaker	47
Left Rear Speaker (Lowline)		At Speaker	N/S
Left Rear Vent Motor	NAT	At Motor	46, 47
Left Rear Wheel Speed Sensor	BK	Center Rear of Floor Pan	47
Left Remote Radio Switch	BK	Steering Wheel	N/S
Left Repeater Lamp (Export)	GY	Left Front Fender	4, 36
Left Side Impact Sensor 1	DKGY	Left B Pillar	40
Left Side Impact Sensor 2		Left Sliding Door	N/S
Left Side Impact Sensor 3	BK	Left Quarter Panel	47
Left Sliding Door Control Module C1	BK	Left Sliding Door	N/S
Left Sliding Door Control Module C2		Left Sliding Door	N/S
Left Sliding Door Latch Sensing Switch	BK	Left Sliding Door	N/S
Left Sliding Door Lock Motor	BK	Left Sliding Door	N/S
Left Sliding Door Lock Motor/Ajar Switch (Manual Sliding Door)	BK	Left Sliding Door	N/S
Left Sliding Door Motor	BK	Left Sliding Door	N/S
Left Speed Control Switch	WT	Steering Wheel	N/S
Left Turn Signal Lamp (Export)	OR	AT Lamp	N/S
Left Visor/Vanity Lamp	BK	At Lamp	N/S
License Lamp	DKGY	At Lamp	49
Lift Pump Motor (Diesel)	BK	Left Rear Engine Compartment	N/S

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

CONNECTOR NAME/NUMBER	COLOR	LOCATION	FIG.
Liftgate Ajar Switch (Manual Release)	BK	At Latch	49
Liftgate Ajar Switch (Power Release)	BK	Lower Liftgate	49
Liftgate Cinch/Release Motor (Power Liftgate)	BL	Liftgate	49
Liftgate Left Pinch Sensor (Power Liftgate)	BK	Left Side of Liftgate	49
Liftgate Right Pinch Sensor (Power Liftgate)	BK	Right Side of Liftgate	49
Manifold Absolute Pressure Sensor (Gas)	BK	On Intake	N/S
Mass Air Flow Sensor (Diesel)	OR	Top of Engine	15, 16
Memory Seat/Mirror/Adjustable Pedals Module C1	GY	Under Driver Seat	N/S
Memory Seat/Mirror/ Adjustable Pedals Module C2	GY	Under Driver Seat	N/S
Memory Seat/Mirror/ Adjustable Pedals Module C3	WT	Under Driver Seat	N/S
Memory Seat/Mirror/ Adjustable Pedals Module C4	GY	Under Driver Seat	N/S
Memory Set Switch	BK	At Switch Driver Door	43
Message Center (Highline)	WT	Rear of Message Center	20, 21, 28
Mode Door Actuator	GY	Left Side of HVAC	N/S
Multi Function Switch	BK	At Steering Column	20, 21, 22, 23, 31
Natural Vacuum Leak Detection Assembly (Except Export)	LTGY	Top of Engine	12
Occupant Classification Module	BK	Passenger Seat	N/S
Occupant Restraint Controller C1	YL	Right Side Instrument Panel	
Occupant Restraint Controller C2	YL	Right Side Instrument Panel	20, 24, 25
Output Speed Sensor	GY	Front of Transmission	14, 19
Overhead Console (Except Base)	BK	Front of Console	N/S
Oxygen Sensor 1/1 Upstream (Gas)		Rear of Engine	11, 12, 18
Oxygen Sensor 1/2 Downstream (Gas)		Rear of Engine	11, 12,18
Park Brake Switch		Bottom Left Side of Instrument Panel	20, 21
Park Sensor No.1 (Parktronics)		Rear Fascia	N/S
Park Sensor No.2 (Parktronics)		Rear Fascia	N/S
Park Sensor No.3 (Parktronics)		Rear Fascia	N/S
Park Sensor No.4 (Parktronics)		Rear Fascia	N/S
Passenger Airbag	YL	Passenger Side of Instrument Panel	20, 23, 24, 29
Passenger Airbag On/Off Indicator Lamp		Right Center of Instrument Panel	20, 23, 25
Passenger Blend Door Actuator	GY	On HVAC	N/S

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

CONNECTOR NAME/NUMBER	COLOR	LOCATION	FIG.
Passenger Door Courtesy Lamp	GY	At Lamp	44
Passenger Door Lock Switch	BK	At Switch	44
Passenger Folding Mirror Relay (Export)	BL	Left Kick Panel	7
Passenger Heated Seat Back	GN	At Seat	N/S
Passenger Heated Seat Cushion	BK	At Seat	N/S
Passenger Heated Seat Module	GY	At Heated Seat	N/S
Passenger Power Seat Front Riser Motor	RD	Under Seat	N/S
Passenger Power Seat Horizontal Motor	BK	Under Seat	N/S
Passenger Power Seat Rear Riser Motor	RD	Under Seat	N/S
Passenger Power Seat Recliner Motor	GN	Under Seat	N/S
Passenger Power Seat Switch	GN	At Switch	N/S
Passenger Power Window Motor	RD	At Motor	44
Passenger Power Window Switch	BK	At Switch	44
Passenger Seat Belt Switch (Occupant Sensing)	YL	On Seat Harness	N/S
Passenger Seat Belt Tensioner		On Seat Harness	N/S
Passenger Seat Weight Sensor	BK	Passenger Seat	N/S
Power Folding Mirror Switch (Export)	BK	Near Steering Column	31
Power Liftgate Module C1	BK	Left Quarter	46, 47
Power Liftgate Module C2		Left Quarter	46, 47
Power Liftgate Motor	BK	Left Quarter	47
Power Mirror Switch	BK	Rear of Switch	30
Power Outlet (Except Lowline)	BK	Instrument Panel	20, 23, 25
Power Seat Circuit Breaker	GY	Under Seat	N/S
Powertrain Control Module C1	BK	Left Front Engine Compartment	11
Powertrain Control Module C2	OR	Left Front Engine Compartment	11
Powertrain Control Module C3	NAT	Left Front Engine Compartment	11
Powertrain Control Module C4	GN	Left Front Engine Compartment	11
Power Window Circuit Breaker	GY	Left Side Kick Panel	41 42
Radiator Fan No.1 (Gas)	BK	Left Side At Motor	1
Radiator Fan No.1 (Diesel)	GY	Left Side At Motor	1
Radiator Fan No.2 (Gas)	BK	Right Side At Motor	1, 2
Radiator Fan No.2 (Diesel)	GY	Right Side At Motor	1, 2
Radiator Fan Relay (Gas)		Top of Left Front Frame Rail	1
Radiator Fan Relay No. 1 (Diesel)	BL	Left Front Engine Compartment	2
Radiator Fan Relay No. 2 (Diesel)	BL	Left Front Engine Compartment	2

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

CONNECTOR NAME/NUMBER	COLOR	LOCATION	FIG.
Radiator Fan Relay No. 3 (Diesel)	BL	Left Front Engine Compartment	2
Radio C1		Rear of Radio	20
Radio C2 (CD Changer)		Rear of Radio	20
Radio C2 (DVD/CD Changer)		Rear of Radio	20
Radio C2 (Hands Free)		Rear of Radio	20
Rear A/C-Heater Unit (3 Zone MTC)	LTGN	Right Quarter Panel	NS
Rear Auto Temp Control Switch (3 Zone ATC)	BK	Rear of Switch	50
Rear Blower Front Control Switch (3 Zone MTC)	BK	Rear of Switch	N/S
Rear Blower Motor Power Module C1 (3 Zone ATC)	RD/BK	Right Quarter	N/S
Rear Blower Motor Power Module C2 (3 Zone ATC)	BK	Right Quarter	N/S
Rear Blower Rear Control Switch C1 (3 Zone MTC)	BK	Overhead	50
Rear Blower Rear Control Switch C2 (3 Zone MTC)	BK	Overhead	50
Rear Dome Lamp (Except Luxury)	GY	At Lamp	N/S
Rear Intrusion Sensor (United Kingdom)		At Sensor	N/S
Rear Mode Motor (3 Zone ATC)	GY	At Motor	N/S
Rear Park Assist Display Module		Overhead Console	N/S
Rear Park Assist Module		Left Quarter Panel	47
Rear Power Outlet	GY	Left Quarter Panel	47
Rear Temperature Motor (3 Zone ATC)	GY	Right Quarter	N/S
Rear View Mirror C1	BK	At Mirror	NS
Rear View Mirror C2		At Mirror	N/S
Rear Window Defogger C1		Right Side of Liftgate	49
Rear Window Defogger C2		Left Side of Liftgate	49
Rear Wiper Motor		At Motor	49
Recirculation Door Actuator	GY	Right Side of HVAC	N/S
Right B-Pillar Switch (Power Sliding Door)	GY	Right B Pillar	39
Right Cinch/Release Motor (Power Sliding Door)	GY	Right Sliding Door	45
Right Curtain Airbag Squib		Rear of Right Roof Rail	48
Right Cylinder Lock Switch (Export)	BK	Right Front Door	44
Right Door Speaker		At Speaker	N/S
Right Fog Lamp	WT	At Lamp	3

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

CONNECTOR NAME/NUMBER	COLOR	LOCATION	FIG.
Right Front Door Ajar Switch (Base)	BK	At B Pillar	N/S
Right Front Door Lock Motor/Ajar Switch (Except Base)	BK	Right Front Door	44
Right Front Impact Sensor	BK	Near T/O for C303	N/S
Right Front Park/Turn Signal Lamp (Except Export)	BK	At Lamp	1, 3
Right Front Wheel Speed Sensor	GY	Right Fender Side Shield	3,10, 16, 17
Right Full Open Switch (Power Sliding Door)	BK	Right Sliding Door	45
Right Headlamp (Caravan/Voyager Except Export)	BK	At Lamp	1, 3
Right Headlamp Leveling Motor (Export)	WT	At Right Headlamp	N/S
Right High Beam Lamp (Export)	BK	At Right Headlamp	N/S
Right Instrument Panel Speaker	WT	At Speaker	20, 23, 24
Right Liftgate Flood Lamp (Power Liftgate)	GY	At Lamp	49
Right Low Beam Lamp (Export)	BK	At Right Headlamp	N/S
Right Mid Reading Lamp (Premium/ Luxury)	GY	At Lamp	N/S
Right Park Lamp (Export)	BK	AT Lamp	N/S
Right Power Mirror	BK	At Mirror	20, 24, 28
Right Rear Lamp Assembly	BK	At Lamp	48
Right Rear Pillar Speaker (Highline Audio)	BK	At Speaker	48
Right Rear Reading Lamp (Luxury)	GY	At Lamp	N/S
Right Rear Speaker)		At Speaker	48
Right Rear Vent Motor	NAT	At Motor	48
Right Rear Wheel Speed Sensor	BK	Right Rear of Floor Pan	48
Right Remote Radio Switch	BK	At Steering Wheel	N/S
Right Repeater Lamp (Export)	GY	Right Front Fender	39
Right Side Impact Sensor 1		Right B Pillar	39
Right Side Impact Sensor 2		Right Sliding Door	32
Right Side Impact Sensor 3	BK	Right Quarter Panel	48
Right Sliding Door Control Module C1	BK	Right Sliding Door	45, 46
Right Sliding Door Control Module C2		Right Sliding Door	45, 46
Right Sliding Door Latch Sensing Switch	BK	Right Sliding Door	45
Right Sliding Door Lock Motor	BK	Right Sliding Door	45
Right Sliding Door Lock Motor/Ajar Switch (Manual Sliding Door)	BK	Right Sliding Door	N/S

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

CONNECTOR NAME/NUMBER	COLOR	LOCATION	FIG.
Right Sliding Door Motor	BK	At Sliding Door	45
Right Speed Control Switch	WT	At Steering Wheel	N/S
Right Turn Signal Lamp (Export)	OR	At Lamp	N/S
Right Visor/Vanity Lamp	BK	At Lamp	N/S
Sentry Key Remote Entry Module (SKREEM)	BK	At Steering Column	20, 21, 22, 23, 31
Siren (United Kingdom)	BK	Left Front Body	N/S
Speed Control Servo (Gas)	BK	Near Controller Antilock Brake	11, 17, 18
Sunroof Module (Except Export)	BK	At Sunroof	N/S
Sunroof Switch (Except Export)	NAT	Near Overhead Console	N/S
Thatcham Alarm Module (United Kingdom)	BK	Top Right Side of Instrument Panel Near Speaker	N/S
Throttle Position Sensor (Gas)	GY	On Throttle Body	10, 11, 17
Traction Control Switch	BK	Rear of Swtich	21, 22, 31
Trailer Tow Connector (Except Export)		Left Quarter Panel	N/S
Transmission Control Relay (Diesel)		Near Transmission	16
Transmission Range Sensor	DKGY	Top of Transmission	14, 19
Transmission Solenoid/Pressure Switch Assembly	BK	Side of Transmission	14, 19
Vehicle Speed Sensor (MTX)	BK	Rear of Transmission	16
Washer Fluid Level Switch	BK	Bottom of Reservoir	3
Washer Pump Motor	BK	Right Fender Well	3
Water in Fuel Sensor (Diesel)	BK	Left Rear Engine Compartment	N/S
Wiper Module	DKGY	Left Side Cowl	6

GROUNDS

GROUND NUMBER	LOCATION	FIG.
G100	Body Ground Near Powertrain Control Module	N/S
G101	Above Starter	13, 15, 18
G102	Left Headlamp Area	1
G103	Above Starter	15
G200	Left Side of Instrument Panel	20, 21 29
G201	Right Side of Instrument Panel	20, 24, 29
G202	Near Radio	N/S
G300	Left B Pillar	32
G301	Right B Pillar	33, 39
G302	Left Rear Quarter	47
G303	Liftgate Ground	49

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

SPLICES

SPLICE NUMBER	LOCATION	FIG.
S101 (Gas)	Near T/O for Radiator Fan No.1	1
S103 (Diesel)	Between T/O for Battery Temperature Sensor and T/O for C102	15
S106 (2.5L)	Near T/O for Battery Temperature Sensor	15
S106 (3.3L/3.8L)	Near T/O for G103	18
S107 (Gas)	Near T/O for Integrated Power Module C3	11
S107 (Diesel)	In T/O for Integrated Power Module C3	7
S111 (2.4L)	Near T/O for C101	11
S111 (Diesel)	In T/O for Battery (-)	N/S
S111 (3.3L/3.8L)	Near T/O for Battery Temperature Sensor	N/S
S112 (Gas)	Near T/O for Integrated Power Module - C3	19, 5, 11
S113 (2.4L)	Near T/O for Park/Neutral Position Switch	11
S114 (2.4L)	Near T/O for Powertrain Control Module C4	11
S114 (3.3L/3.8L)	In T/O to Transmission Control Module	N/S
S115 (2.4L)	Near T/O for Powertrain Control Module C4	11
S115 (3.3L/3.8L)	In T/O to Transmission Control Module	N/S
S116 (2.4L)	180mm from T/O for Torque Converter Clutch Solenoid	11, 13
S116 (Diesel)	Near T/O for Mass Air Flow Sensor	16
S116 (3.3L/3.8L)	Near T/O for G103	18
S118 (2.4L)	Near T/O for Knock Sensor	11, 13
S119 (Diesel)	Near T/O for Engine Starter Motor	15
S121 (3.3L/3.8L)	Near T/O for Output Speed Sensor	18
S122 (2.4L)	In T/O to Engine Starter Motor	13
S122 (3.3L/3.8L)	In T/O to Engine Starter Motor	18
S124 (2.4L)	Near T/O for Fuel Injector No.2	N/S
S124 (3.3L/3.8L)	Near T/O for Fuel Injector No.5 and No.6	N/S
S125 (2.4L)	In T/O for Manifold Absolute Pressure Sensor	N/S
S126	In Right Headlamp Leveling Assembly	N/S
S127 (Diesel)	In T/O for Engine Starter Motor	N/S
S128 (Diesel)	Near T/O for Engine Starter Motor	N/S
S129 (Diesel)	Near T/O for Battery (+)	N/S
S130 (Diesel)	Near T/O for Battery (+)	N/S
S131 (2.4L)	Near T/O for Transmission Control Module	11
S131 (3.3L/3.8L)	Near T/O for C110	N/S
S132 (Diesel)	Near T/O for Battery (+)	N/S
S134 (Diesel)	IN T/O for Engine Control Module	N/S
S135 (Diesel)	Near T/O for Glow Plug No.2	N/S
S136 (Diesel)	In T/O for Radiator Fan Relays	2
S137 (Diesel)	Above Starter	15
S138 (Diesel)	Between T/O for Radiator Fan No.2 and T/O for G102	N/S

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

SPLICE NUMBER	LOCATION	FIG.
S139 (Diesel)	Between T/O for Engine Starter Motor and T/O for Engine Control Module C1	15, 16
S141 (2.4L)	Near T/O for Controller Anti-Lock Brake	11
S141 (3.3L/3.8L ABS Except Export)	Near T/O for G100	N/S
S141 (Diesel)	Near T/O for G100	N/S
S141 (3.3L/3.8L)	Near T/O for Powertrain Control Module	N/S
S142 (3.3L/3.8L)	Near T/O for A/C Compressor Clutch	18
S144 (Diesel)	Between T/O for Battery Temperature Sensor and T/O for C103	N/S
S148 (Diesel)	Near T/O for Engine Starter Motor	5
S150 (Diesel)	Near T/O for Controller Anti-Lock Brake	N/S
S151 (Diesel)	Near T/O for Radiator Fan Relays	2
S152 (Diesel)	Near T/O for Radiator Fan No.1	N/S
S157 (Diesel)	Near T/O for Glow Plug No.4	15
S177	In Right Headlamp Wiring Assembly	N/S
S179	In Left Headlamp Wiring Assembly	N/S
S187 (Diesel)	In T/O for Engine Control Module C1	15
S188 (Diesel)	Near T/O for Radiator Fan Relays	2
S189 (Diesel EATX)	Near T/O for Battery (+)	N/S
S190 (Diesel EATX)	Near T/O for Transmission Control Module	N/S
S191 (Diesel EATX)	Near T/O for Transmission Control Module	N/S
S192 (Diesel EATX)	In T/O for Transmission Control Module	N/S
S193 (Diesel EATX)	In T/O for Transmission Control Module	N/S
S201	In T/O to Instrument Panel Speaker	20, 26
S202	Near T/O for Instrument Panel Switch Bank	20, 26
S203	Near T/O for Instrument Panel Switch Bank	20, 26
S204	Near T/O to Instrument Panel Speaker	20, 26
S205	Near T/O for C201	N/S
S206	Near T/O for Instrument Cluster	20
S207	Near T/O for A/C Heater Control	20, 26
S208 (RHD)	Between T/O for Antenna Connector and T/O for Front Cigar Lighter	26
S209	Near T/O for Evaporator Temperature Sensor	N/S
S210 (RHD)	Near T/O for C203	26
S211	In Steering Column Wiring Assembly	N/S
S212	In Steering Column Wiring Assembly	N/S
S222	Near T/O for C204	N/S
S223	Near T/O for Multi-Function Switch	20
S224	Near T/O for Siren	N/S
S225 (Hands Free)	Near T/O for Rear View Mirror	N/S
S226 (Hands Free)	In T/O for C207	N/S
S302	In Floor Pan Track Wiring	37

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

SPLICE NUMBER	LOCATION	FIG.
S303	In T/O to Data Link Connector	37, 41, 42
S304 (Export)	In Floor Pan Track Wiring	38
S305	Near T/O for Memory Seat/Mirror Module - C2	N/S
S306	In Floor Pan Track Wiring	38
S307	Near T/O for Memory Power Seat Switch	N/S
S309	In Floor Pan Track Wiring	N/S
S310	Near T/O for C301	35, 36, 37
S311	In Floor Pan Track Wiring	N/S
S312	Near T/O for C320	N/S
S313	Near T/O for Power Liftgate Module	47
S316	In Floor Pan Track Wiring	34
S317	Near T/O for Body Control Module	42
S318	Near T/O for Power Seat Circuit Breaker	34
S319 (Export)	In Floor Pan Track Wiring	38
S321	Ner T/O for C301	35, 36, 37
S322	Near T/O for C301	37
S323	In Floor Pan Track Wiring	34
S324	In Floor Pan Track Wiring	34
S325 (Export)	In Floor Pan Track Wiring	34
S326	Near T/O for C101	35, 36
S330	Near T/O for Power Liftgate Module	47
S331	Near T/O for Power Liftgate Motor	47
S332	In Floor Pan Track Wiring	N/S
S333 (3 Zone MTC)	In Floor Pan Track Wiring	37
S334	Near T/O to G301	34
S335	Near T/O for Left Rear Reading Lamp	N/S
S336	Near T/O for Left Rear Reading Lamp	N/S
S337	Near T/O for Right Mid Reading Lamp	N/S
S338	Near T/O for Right Visor/Vanity Lamp	N/S
S339	Near T/O for C312	N/S
S342 (LHD)	Near T/O for Passenger Power Window Motor	44
S343 (LHD)	Near T/O for Driver Power Window Motor	43
S344	In T/O to Right Sliding Door Control Module C2	45, 46
S345	Near T/O for Right Sliding Door Motor	45, 46
S346	Near T/O for Driver Power Window Switch	43
S347	Near T/O for Right Sliding Door Lock Motor	45, 46
S348	Near T/O for Left Sliding Door Lock Motor	46
S349	In T/O to Left Sliding Door Control Module - C2	46
S350	Near T/O for Left Sliding Door Motor	46
S352	Near T/O for Liftgate Cinch/Release Motor	49
S354 (Export)	Near T/O for C301	36, 37
S354 (Except Export)	Near T/O for C101	37

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

SPLICE NUMBER	LOCATION	FIG.
S355	In T/O for C307	N/S
S356 (Export)	In Floor Pan Track Wiring	37
S356 (Except Export)	Near T/O for Passenger Heated Seat Back	N/S
S359	Left Quarter Panel	47
S361	Near T/O for C304	N/S
S362	Near T/O for C304	N/S
S363	Near T/O for C331	N/S
S364 (RHD)	Near T/O for Passenger Power Window Window	44
S365 (LHD)	Near T/O for Driver Power Window Window	N/S
S366	In Passenger Power Heated Seat Wiring Assembly	N/S
S367	Near T/O for C301	37
S368 (Diesel)	Near T/O for C101	35, 36
S370 (Except Export)	In T/O for Integrated Power Module C6	7
S371	In T/O to Power Window Switch	N/S
S372	Near T/O for Data Link Connector	41
S373 (Except Export)	In Floor Pan Track Wiring	37
S374	Near T/O for Body Control Module	N/S
S376 (Highline Audio)	In Floor Pan Track Wiring	34
S378	Near T/O for C301	35, 36, 37
S380 (Highline Audio)	Right Quarter Panel	48
S381 (Highline Audio)	Right Quarter Panel	48
S382 (Passenger Heated Seat)	Near T/O for Passenger Seat Weight Sensor	N/S
S383 (Parktronics)	Rear Fascia	N/S
S384 (Parktronics)	Rear Fascia	N/S

81033145





Fig. 1 HEADLAMP CONNECTORS

CONNECTOR/GROUND/SPLICE LOCATION (Continued)




Fig. 2 LEFT FRONT ENGINE COMPARTMENT

81033f5b





Fig. 3 WASHER PUMP CONNECTORS

81033f73



**LEFT
REPEATER
LAMP**

Fig. 4 LEFT REPEATER LAMP

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

81033177




Fig. 5 LEFT FENDER SHIELD

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

810337e





Fig. 6 LEFT SIDE ENGINE COMPARTMENT



81033f83

Fig. 7 INTEGRATED POWER MODULE

80bc2f82





Fig. 8 RIGHT FRONT WHEEL HOUSING

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

81034228



3.3L/3.8L ENGINE

2.4L ENGINE

Fig. 9 INLET AIR SENSORS

810391c5




Fig. 10 2.4 LITER ENGINE CONNECTORS REAR

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

810331cf




Fig. 11 2.4 LITER ENGINE FRONT

8103426C




Fig. 12 OXYGEN SENSORS

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

81034271




Fig. 13 STARTER CONNECTORS

81034278




Fig. 14 TRANSMISSION CONNECTORS

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

81033fcd




Fig. 15 2.5 LITER DIESEL ENGINE FRONT

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

80d5317




Fig. 16 2.5 LITER DIESEL ENGINE REAR

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

80d53e86




Fig. 17 3.3-3.8 LITER ENGINE REAR

81033f4





Fig. 18 3.3-3.8 LITER ENGINE FRONT

CONNECTOR/GROUND/SPLICE LOCATION (Continued)



8123011a

Fig. 19 AUTOMATIC TRANSMISSION

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

8103400f




Fig. 20 INSTRUMENT PANEL HARNESS LHD

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

8103401c





Fig. 21 LEFT SIDE INSTRUMENT PANEL LHD

CONNECTOR/GROUND/SPLICE LOCATION (Continued)



81037911

Fig. 22 STEERING COLUMN

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

810379fa





Fig. 23 CENTER INSTRUMENT PANEL



81037a18

Fig. 24 RIGHT SIDE INSTRUMENT PANEL

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

80d536de




Fig. 25 CENTER INSTRUMENT PANEL RHD




Fig. 26 INSTRUMENT PANEL RHD

81034030




Fig. 27 LEFT SIDE INSTRUMENT PANEL UPPER RHD

81037a24

CONNECTOR/GROUND/SPLICE LOCATION (Continued)




Fig. 28 RIGHT SIDE INSTRUMENT PANEL UPPER RHD

81037a35




Fig. 29 LEFT SIDE INSTRUMENT PANEL LOWER RHD

81037a43

CONNECTOR/GROUND/SPLICE LOCATION (Continued)




Fig. 30 RIGHT SIDE INSTRUMENT PANEL LOWER RHD

80d53672




Fig. 31 STEERING COLUMN CONNECTORS RHD

81037a56

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

80d5384e





Fig. 32 LEFT SIDE BODY LHD


CONNECTOR/GROUND/SPLICE LOCATION (Continued)



80d5362c

Fig. 33 RIGHT SIDE BODY RHD


CONNECTOR/GROUND/SPLICE LOCATION (Continued)



8103410d

Fig. 35 BODY HARNESS SPLICES


CONNECTOR/GROUND/SPLICE LOCATION (Continued)



810342ad

Fig. 36 LEFT FRONT LAMP SPLICES

CONNECTOR/GROUND/SPLICE LOCATION (Continued)



81034143

Fig. 37 LEFT FRONT BODY SPLICES

81034166






Fig. 38 REAR BODY SPLICES

CONNECTOR/GROUND/SPLICE LOCATION (Continued)




80d53617

Fig. 39 RIGHT B PILLAR



81034172


Fig. 40 LEFT B PILLAR



81034179

Fig. 41 LEFT SIDE KICK PANEL LHD

CONNECTOR/GROUND/SPLICE LOCATION (Continued)



810341a1

Fig. 42 RIGHT SIDE KICK PANEL RHD

CONNECTOR/GROUND/SPLICE LOCATION (Continued)




Fig. 43 DRIVER DOOR

810342dd





Fig. 44 PASSENGER DOOR

810341a5

CONNECTOR/GROUND/SPLICE LOCATION (Continued)



80d54089

Fig. 45 RIGHT SLIDING DOOR

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

810341B8





Fig. 47 LEFT REAR BODY

CONNECTOR/GROUND/SPLICE LOCATION (Continued)



810341c0

Fig. 48 RIGHT QUARTER

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

810341c7




Fig. 49 LIFTGATE

CONNECTOR/GROUND/SPLICE LOCATION (Continued)

810342c




Fig. 50 HEADLINER