

## 8W-18 BUS COMMUNICATIONS

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
A/C-Heater Control . . . . .	8W-18-6	Integrated Power Module . . . . .	8W-18-2, 3, 4, 5
Amplifier . . . . .	8W-18-5	Left Sliding Door Control Module . . . . .	8W-18-5
Auto Temp Control . . . . .	8W-18-6	Memory Seat/Mirror/Adjustable Pedals Module . . . . .	8W-18-5
Battery . . . . .	8W-18-2	Occupant Classification Module . . . . .	8W-18-5
Body Control Module . . . . .	8W-18-3, 4, 5	Occupant Restraint Controller . . . . .	8W-18-6
Cabin Heater Assist . . . . .	8W-18-4	Overhead Console . . . . .	8W-18-5
CD Changer . . . . .	8W-18-6	Park Assist Module . . . . .	8W-18-5
Controller Antilock Brake . . . . .	8W-18-3, 4	Power Liftgate Module . . . . .	8W-18-5
Data Link Connector . . . . .	8W-18-2, 3, 4, 5	Powertrain Control Module . . . . .	8W-18-3
DVD/CD Changer . . . . .	8W-18-6	PTC 7 . . . . .	8W-18-2
Engine Control Module . . . . .	8W-18-4	Radio . . . . .	8W-18-6
Front Control Module . . . . .	8W-18-3, 4, 5	Right Sliding Door Control Module . . . . .	8W-18-5
G100 . . . . .	8W-18-2	Sentry Key Remote Entry Module . . . . .	8W-18-6
G101 . . . . .	8W-18-2	Thatcham Alarm Module . . . . .	8W-18-3, 4, 6
G300 . . . . .	8W-18-2	Transmission Control Module . . . . .	8W-18-4
Hands Free Module . . . . .	8W-18-6		
Instrument Cluster . . . . .	8W-18-6		









