




8W-56 CONVENIENCE SYSTEMS

Component	Page	Component	Page
Adjustable Pedals Motor	8W-56-2, 3	Integrated Power Module	8W-56-2, 3, 4
Adjustable Pedals Relay	8W-56-2	Left Sliding Door Control Module	8W-56-2
Adjustable Pedals Sensor	8W-56-3	Memory Seat/Mirror/Adjustable Pedals Module	8W-56-2, 3
Adjustable Pedals Switch	8W-56-2	Park Assist Display	8W-56-4
Driver Heated Seat Module	8W-56-3	Park Assist Module	8W-56-4, 5, 6
Front Control Module	8W-56-2, 4	Park Assist Sensor No. 1	8W-56-5, 6
Fuse 14	8W-56-2	Park Assist Sensor No. 2	8W-56-5, 6
Fuse 18	8W-56-2	Park Assist Sensor No. 3	8W-56-5, 6
Fuse 22	8W-56-3	Park Assist Sensor No. 4	8W-56-5, 6
G200	8W-56-2	Power Seat Circuit Breaker	8W-56-3
G300	8W-56-3	Sentry Key Remote Entry Module	8W-56-4
G302	8W-56-4		
Ignition Switch	8W-56-4		

ADJUSTABLE PEDALS/MEMORY/EXCEPT EXPORT







PARK ASSIST

