

8W-31 TRANSMISSION CONTROL SYSTEM

Component	Page
Assembly-Shift Motor/Mode Sensor . .	8W-31-17, 18
Assembly-Transmission	
Solenoid	8W-31-2, 5, 12, 14, 15
Assembly-Transmission	
Solenoid/TRS	8W-31-2, 6, 7, 8
Assembly-Transmission	
Throttle Valve	8W-31-14, 15
Clockspring	8W-31-15
Cluster	8W-31-9, 13, 16, 20
Electronics	8W-31-2, 9, 12, 14, 17, 18, 19, 20
Fuse 29	8W-31-9, 16
Fuse 31	8W-31-17
Fuse 7	8W-31-20
Fuse 9	8W-31-9
G104	8W-31-9, 19, 20
G106	8W-31-10, 20
G107	8W-31-2, 19
G201	8W-31-2, 15, 16
G203	8W-31-20
Module-Axle Disconnect-Front	8W-31-20
Module-Engine Control	8W-31-13, 14, 15, 20
Module-Final Drive Control	8W-31-9, 10, 11
Module-Powertrain Control . .	8W-31-2, 3, 4, 5, 6, 7, 8, 12, 13, 20

Component	Page
Module-Totally Integrated	
Power	8W-31-2, 9, 12, 14, 16, 17, 18, 19, 20
Relay-Starter	8W-31-20
Relay-Starter Motor	8W-31-20
Sensor-Input Speed	8W-31-3
Sensor-Line Pressure	8W-31-7
Sensor-Output Speed	8W-31-3, 12, 14
Sensor-Prop Shaft Speed-Front	8W-31-18
Sensor-Prop Shaft Speed-Rear	8W-31-18
Sensor-Transfer Case Position	8W-31-19
Sensor-Transmission Range	8W-31-2, 4, 13
Solenoid-Brake Transmission Shift	
Interlock	8W-31-20
Solenoid-Locker-Front	8W-31-11
Solenoid-Locker-Rear	8W-31-11
Solenoid-Reverse Lock-Out	8W-31-20
Switch-Clutch Interlock	8W-31-20
Switch-Disconnecting Stabilizer Bar . .	8W-31-9, 10
Switch-Speed Control-Left	8W-31-15
Switch-Speed Control-Right	8W-31-15
Switch-Tow/Haul Overdrive	8W-31-2, 15
Switch-Transfer Case Selector	8W-31-16





































