




8W-42 AIR CONDITIONING-HEATER


Component	Page
Actuator-Blend Door-Rear	8W-42-6
Actuator-Mode Door-Floor To Defrost- Front	8W-42-3
Actuator-Mode Door-Floor To Panel-Front .	8W-42-3
Actuator-Mode Door-Rear	8W-42-6
Actuator-Recirculation Door	8W-42-3
Assembly-Shift Motor/Mode Sensor	8W-42-10
Cluster	8W-42-4, 5, 9
Clutch-A/C Compressor	8W-42-11
Control-A/C-Heater	8W-42-2, 3, 4, 5, 6, 8, 9
Control-A/C-Heater-Rear	8W-42-9
Fuse 13	8W-42-2
Fuse 18	8W-42-11
Fuse 19	8W-42-12
Fuse 24	8W-42-2, 7, 9, 11
Fuse 7	8W-42-4, 5
G100	8W-42-11
G112	8W-42-6
G114	8W-42-7
G207	8W-42-2, 4, 5, 8


Component	Page
G306	8W-42-12
Junction Block	8W-42-2, 4, 5, 6, 7, 9, 11, 12
Module-Electronic Overhead	8W-42-12
Module-Front Control	8W-42-2, 4, 5, 10
Module-Integrated Power	8W-42-4, 5, 10
Module-Power-Blower Motor-Front	8W-42-4
Module-Powertrain Control	8W-42-11
Motor-Blower-Front	8W-42-4, 5
Motor-Blower-Rear	8W-42-7
Power Distribution Center	8W-42-4, 5, 11
Pump-Auxiliary Coolant	8W-42-6
Relay-A/C Clutch	8W-42-11
Relay-Blower Motor-Front	8W-42-4, 5
Relay-Blower Motor-Rear	8W-42-7
Resistor-Blower Motor-Front	8W-42-5
Resistor-Blower Motor-Rear	8W-42-7, 8
Sensor-Ambient Air Temperature	8W-42-10
Sensor-Evaporator Temperature	8W-42-6
Sensor-Infrared	8W-42-12
Transducer-A/C Pressure	8W-42-10

















HB604209

- ATC
- MTC

