


8W-10 POWER DISTRIBUTION

| Component | Page | Component | Page |
|-------------------------------|--------------------|--------------------------------------|--|
| Battery | 8W-10-7 | G208 | 8W-10-20 |
| Capacitor-Ignition | 8W-10-14 | Generator | 8W-10-7 |
| Cartridge Fuses | 8W-10-2 | Injector-Fuel-No. 1 | 8W-10-15, 16 |
| Circuit Breaker | 8W-10-12 | Injector-Fuel-No. 2 | 8W-10-15, 16 |
| Cluster | 8W-10-20, 21 | Injector-Fuel-No. 3 | 8W-10-15, 16 |
| Coil-Ignition-No. 1 | 8W-10-15, 16 | Injector-Fuel-No. 4 | 8W-10-15, 16 |
| Coil-Ignition-No. 2 | 8W-10-15, 16 | Injector-Fuel-No. 5 | 8W-10-15, 16 |
| Coil-Ignition-No. 3 | 8W-10-15, 16 | Injector-Fuel-No. 6 | 8W-10-15, 16 |
| Coil-Ignition-No. 4 | 8W-10-14, 15, 16 | Injector-Fuel-No. 7 | 8W-10-15, 16 |
| Coil-Ignition-No. 5 | 8W-10-15, 16 | Injector-Fuel-No. 8 | 8W-10-15, 16 |
| Coil-Ignition-No. 6 | 8W-10-14 | Junction Block | 8W-10-8, 9, 10, 11, 12, 17, 18, 19, 20 |
| Coil-Ignition-No. 7 | 8W-10-15, 16 | Mini Fuses | 8W-10-2 |
| Coil-Ignition-No. 8 | 8W-10-14 | Module-Antilock Brakes | 8W-10-9, 17 |
| Fuse 1 | 8W-10-8, 10 | Module-Brake Provision | 8W-10-8, 11 |
| Fuse 10 | 8W-10-8, 9, 12, 17 | Module-Front Control | 8W-10-10, 11, 13, 21 |
| Fuse 11 | 8W-10-8, 12 | Module-Heated Seat | 8W-10-12 |
| Fuse 12 | 8W-10-8, 9, 17 | Module-Integrated Power | 8W-10-8, 10, 11, 13 |
| Fuse 13 | 8W-10-9, 17 | Module-Power Liftgate | 8W-10-8, 12 |
| Fuse 14 | 8W-10-9, 17 | Module-Powertrain Control | 8W-10-9, 12, 14, 18, 21 |
| Fuse 15 | 8W-10-9, 17 | Module-Seat Memory | 8W-10-12 |
| Fuse 16 | 8W-10-19, 21 | Motor-Sunroof | 8W-10-11 |
| Fuse 18 | 8W-10-9, 17, 19 | Power Distribution Center | 8W-10-2, 7, 8, 9, 10, 11, 12, 17, 18, 21 |
| Fuse 19 | 8W-10-9, 17, 19 | Relay-A/C Clutch | 8W-10-9, 18 |
| Fuse 2 | 8W-10-8, 10 | Relay-Accessory Delay | 8W-10-12 |
| Fuse 21 | 8W-10-9, 17 | Relay-Auto Shut Down | 8W-10-8, 12, 13 |
| Fuse 22 | 8W-10-9, 18 | Relay-Blower Motor-Front | 8W-10-11 |
| Fuse 23 | 8W-10-9, 18 | Relay-Blower Motor-Rear | 8W-10-17 |
| Fuse 24 | 8W-10-9, 18, 20 | Relay-Fuel Pump | 8W-10-9, 17 |
| Fuse 25 | 8W-10-9, 18, 20 | Relay-Rear Window Defogger | 8W-10-17 |
| Fuse 26 | 8W-10-20 | Relay-Run Remote | 8W-10-11 |
| Fuse 27 | 8W-10-9, 18 | Relay-Run/Start | 8W-10-10, 19 |
| Fuse 3 | 8W-10-8, 11, 12 | Relay-Starter Motor | 8W-10-8, 10, 21 |
| Fuse 33 | 8W-10-17 | Relay-Transmission Control | 8W-10-9, 17 |
| Fuse 34 | 8W-10-19 | Relay-Wiper High/Low | 8W-10-10 |
| Fuse 35 | 8W-10-11 | Relay-Wiper On/Off | 8W-10-10 |
| Fuse 4 | 8W-10-8, 11 | Starter | 8W-10-7, 10 |
| Fuse 5 | 8W-10-8, 12 | Switch-Ignition | 8W-10-10, 11, 18, 19, 20 |
| Fuse 6 | 8W-10-8, 11 | Switch-Seat-Driver | 8W-10-12 |
| Fuse 7 | 8W-10-8, 11, 17 | Switch-Seat-Passenger | 8W-10-12 |
| Fuse 8 | 8W-10-8, 12, 17 | Switch-Stop Lamp | 8W-10-18 |
| Fuse 9 | 8W-10-17 | Wiring-Trailer Tow 7-Way | 8W-10-9, 18 |
| Fusible Link | 8W-10-7 | | |
| G110 | 8W-10-7 | | |
| G111 | 8W-10-7 | | |
| G113 | 8W-10-13 | | |



FUSES

| FUSE NO. | AMPS | FUSED CIRCUIT | FUNCTION |
|----------|------|---------------|--------------------------------------|
| 1 | 30A | A923 14RD/OR | FUSED B(+) |
| 2 | 30A | A5 14 RD/VT | FUSED B(+) |
| 3 | 40A | A400 12TN/RD | FUSED B(+) |
| 4 | 30A | A904 14RD/GY | FUSED B(+) |
| 5 | 40A | A940 12RD/GY | FUSED B(+) |
| 6 | 20A | A917 16RD/DB | FUSED B(+) |
| 7 | 40A | A927 12RD/BR | FUSED B(+) |
| 8 | 40A | A901 12RD/PK | FUSED B(+) |
| 9 | - | - | - |
| 10 | 30A | A922 14RD/LB | FUSED B(+) |
| 11 | 40A | A115 12YL/RD | FUSED B(+) |
| 12 | 40A | A915 14OR/BR | FUSED B(+) |
| 13 | 30A | A222 14RD/LB | FUSED B(+) |
| 14 | 40A | A107 12TN/RD | FUSED B(+) |
| 15 | 50A | A952 10OR/DB | FUSED B(+) |
| 16 | 10A | F924 20PK/YL | FUSED IGNITION SWITCH OUTPUT (START) |
| 17 | - | - | - |
| 18 | 20A | A921 18OR/PK | FUSED B(+) |
| 19 | 20A | A104 18YL/RD | FUSED B(+) |
| 20 | - | - | - |
| 21 | 20A | A111 18DG/RD | FUSED B(+) |
| 22 | 20A | A919 18OR/GY | FUSED B(+) |
| 23 | 20A | A100 18RD/VT | FUSED B(+) |
| 24 | 15A | A916 20OR/WT | FUSED B(+) |
| 25 | 15A | A103 20GY/RD | FUSED B(+) |
| 26 | - | - | - |
| 27 | 10A | A953 20RD/YL | FUSED B(+) |
| 28 | - | - | - |

RELAYS

RELAY-A/C
CLUTCH

| CAVITY | CIRCUIT | FUNCTION |
|--------|--------------|--|
| 30 | A916 20OR/WT | FUSED B(+) |
| 85 | C13 20LB/OR | A/C CLUTCH RELAY CONTROL |
| 86 | F202 20PK/GY | FUSED IGNITION SWITCH OUTPUT (RUN-START) |
| 87 | C3 20DB/GY | A/C CLUTCH RELAY OUTPUT |
| 87A | - | - |

RELAY-AUTO
SHUT
DOWN

| CAVITY | CIRCUIT | FUNCTION |
|--------|--------------|------------------|
| 30 | A922 14RD/LB | FUSED B(+) |
| 85 | K51 20BR/GY | ASD RELAY OUTPUT |
| 86 | A922 14RD/LB | FUSED B(+) |
| 87 | A955 14RD | ASD RELAY OUTPUT |
| 87A | - | - |

RELAY-BLOWER
MOTOR-
FRONT

| CAVITY | CIRCUIT | FUNCTION |
|--------|--------------|---------------------------------|
| 30 | A927 12RD/BR | FUSED B(+) |
| 85 | C229 20DB | FRONT BLOWER CONTROL |
| 86 | A927 12RD/BR | FUSED B(+) |
| 87 | C7 12DB | FRONT BLOWER MOTOR RELAY OUTPUT |
| 87A | - | - |

RELAY-FUEL
PUMP

| CAVITY | CIRCUIT | FUNCTION |
|--------|--------------|--|
| 30 | A921 18OR/PK | FUSED B(+) |
| 85 | K31 20BR | FUEL PUMP RELAY CONTROL |
| 86 | F202 20PK/GY | FUSED IGNITION SWITCH OUTPUT (RUN-START) |
| 87 | N1 18DB/OR | FUEL PUMP RELAY OUTPUT |
| 87A | - | - |

RELAYS

RELAY-RUN
REMOTE

| CAVITY | CIRCUIT | FUNCTION |
|--------|--------------|------------------------------|
| 30 | A927 12RD/BR | FUSED B(+) |
| 85 | C229 20DB | FRONT BLOWER CONTROL |
| 86 | A927 12RD/BR | FUSED B(+) |
| 87 | F921 12PK/YL | IGNITION SWITCH OUTPUT (RUN) |
| 87A | - | - |

RELAY-RUN/
START

| CAVITY | CIRCUIT | FUNCTION |
|--------|--------------|------------------------------------|
| 30 | A923 14RD/OR | FUSED B(+) |
| 85 | K617 20BR | RUN START RELAY CONTROL |
| 86 | A923 14RD/OR | FUSED B(+) |
| 87 | F941 14PK/LG | IGNITION SWITCH OUTPUT (RUN-START) |
| 87A | - | - |

RELAY-
STARTER
MOTOR

| CAVITY | CIRCUIT | FUNCTION |
|--------|--------------|--------------------------------------|
| 30 | A923 14RD/OR | FUSED B(+) |
| 85 | T752 20DG/OR | ENGINE STARTER MOTOR RELAY CONTROL |
| 86 | F924 20PK/YL | FUSED IGNITION SWITCH OUTPUT (START) |
| 87 | T750 14GY/YL | ENGINE STARTER MOTOR RELAY OUTPUT |
| 87A | - | - |


RELAY-
STOP LAMP
INHIBIT


| CAVITY | CIRCUIT | FUNCTION |
|--------|--------------|------------------------------------|
| 30 | L950 10WT/LG | ACCESSORY DELAY RELAY OUTPUT |
| 85 | B45 20 DG/LB | STOP LAMP INHIBIT RELAY CONTROL |
| 86 | F500 20DG/PK | FUSED IGNITION SWITCH OUTPUT (RUN) |
| 87 | - | - |
| 87A | L50 20WT/TN | BRAKE LAMP SWITCH OUTPUT |


RELAYS


RELAY-
TRANSMISSION
CONTROL


| CAVITY | CIRCUIT | FUNCTION |
|--------|--------------|------------------------------------|
| 30 | A104 18YL/RD | FUSED B(+) |
| 85 | Z915 20BK | GROUND |
| 86 | T15 20YL/VT | TRANSMISSION CONTROL RELAY CONTROL |
| 87 | T16 18YL/OR | TRANSMISSION CONTROL RELAY OUTPUT |
| 87A | - | - |














■ PASSENGER POWER SEAT
 ■ EXCEPT PASSENGER POWER SEAT







5.7L

