

## 8W-31 TRANSMISSION CONTROL SYSTEM

<b>Component</b>	<b>Page</b>
Accelerator Pedal Position Sensor . . . . .	8W-31-12
Battery . . . . .	8W-31-2, 5, 6, 7, 10, 11
Brake Transmission Shift Interlock Solenoid . . . . .	8W-31-3, 8
Data Link Connector . . . . .	8W-31-12
Engine Control Module . . . . .	8W-31-8, 12
Front Control Module . . . . .	8W-31-3, 6, 8, 12
Fuse 15 . . . . .	8W-31-2, 5
Fusible Link . . . . .	8W-31-7, 10, 11
G101 . . . . .	8W-31-2, 5, 6, 7

<b>Component</b>	<b>Page</b>
Input Speed Sensor . . . . .	8W-31-4, 9
Integrated Power Module . . . . .	8W-31-2, 3, 5, 6, 8, 12
Output Speed Sensor . . . . .	8W-31-4, 9
Powertrain Control Module . . . . .	8W-31-2, 3, 4, 5, 6
Transmission Control Module . . . . .	8W-31-7, 8, 9, 10, 11, 12
Transmission Control Relay . . . . .	8W-31-2, 5, 7, 10, 11
Transmission Range Sensor . . . . .	8W-31-3, 4, 8, 9
Transmission Solenoid/Pressure Switch Assembly . . . . .	8W-31-2, 5, 6, 7, 10, 11























