

8W-02 COMPONENT INDEX

Component	Page	Component	Page
A/C Compressor Clutch	8W-42	Dosing Pump	8W-30
A/C Compressor Clutch Relay	8W-42	DVD Screen	8W-47
A/C Pressure Sensor	8W-42	DVD/CD Changer	8W-47
A/C-Heater Control	8W-42	ECM/PCM Relay	8W-30
Accelerator Pedal Position Sensor	8W-30	EGR Solenoid	8W-30
Accessory Relay	8W-13	Engine Control Module	8W-30
Adjustable Pedals Motor	8W-56	Engine Coolant Temp Sensor	8W-30
Adjustable Pedals Relay	8W-56	Engine Oil Pressure Sensor	8W-30
Adjustable Pedals Sensor	8W-56	Engine Oil Pressure Switch	8W-30
Adjustable Pedals Switch	8W-56	EVAP/Purge Solenoid	8W-30
Airbag	8W-43	Evaporator Temperature Sensor	8W-42
Airbag On/Off Indicator Lamp	8W-43	Floor Console Lamp	8W-44
Airbag Squibs	8W-43	Floor Console Power Outlet	8W-41
Ambient Temperature Sensor	8W-49	Fog Lamps	8W-50
Amplifier	8W-47	Folding Mirror Relay	8W-62
Antenna	8W-47	Front Blower Module	8W-42
Anti-Lock Brake Module	8W-35	Front Cigar Lighter	8W-41
ATC Remote Sensor	8W-42	Front Control Module	8W-13
Auto Shut Down Relay	8W-30	Front Fog Lamp Relay	8W-50
Auto Temp Control	8W-42	Front Reading Lamps/Switch	8W-44
B-Pillar Switches	8W-61	Front Wiper High/Low Relay	8W-53
Backup Lamp Switch	8W-51	Front Wiper On/Off Relay	8W-53
Battery	8W-13	Fuel Heater	8W-30
Battery Temperature Sensor	8W-20	Fuel Heater Relay	8W-30
Belt Tension Sensor	8W-43	Fuel Injectors	8W-30
Blend Door Actuators	8W-42	Fuel Pressure Sensor	8W-30
Blower Motors	8W-42	Fuel Pressure Solenoid	8W-30
Blower Motor Relays	8W-42	Fuel Pump Module	8W-30
Blower Motor Resistor	8W-42	Fuel Pump Relay	8W-30
Body Control Module	8W-45	Full Open Switches	8W-61
Boost Pressure Sensor	8W-30	Fuses	8W-13
Brake Fluid Level Switch	8W-35	Fusible Link	8W-13
Brake Lamp Switch	8W-30, 51	Generator	8W-20
Brake Transmission Shift Interlock Solenoid	8W-31	Glow Plug Relay	8W-30
Cabin Heater Assist	8W-30	Glow Plugs	8W-30
Camshaft Position Sensor	8W-30	Grounds	8W-15
CD Changer	8W-47	Hands Free Module	8W-55
Center High Mounted Stop Lamp	8W-51	Headlamp Leveling Motors	8W-50
Cinch/Release Motors	8W-61	Headlamp Switch	8W-50
Clockspring	8W-33, 41, 43, 47	Headlamp Washer Pump Motor	8W-53
Clutch Pedal Interlock Switch	8W-21	Headlamp Washer Relay	8W-53
Clutch Pedal Upstop Switch	8W-30	Headlamps	8W-50
Controller Anti-Lock Brake	8W-35	Heated Seats	8W-63
Crank Case Ventilation Heater	8W-30	Heated Seat Modules	8W-63
Crankshaft Position Sensor	8W-30	High Beam Lamps	8W-50
Cylinder Lock Switches	8W-39	High Note Horn	8W-41
Data Link Connector	8W-18	Hood Ajar Switch	8W-39
Defogger Relay	8W-48	Horn Relay	8W-41
Door Ajar Switches	8W-39	Horn Switch	8W-41
Door Courtesy Lamps	8W-44	Idle Air Control Motor	8W-30
Door Lock Motor/Ajar Switches	8W-61	Ignition Coil	8W-30
Door Lock Switches	8W-61	Ignition Switch	8W-13

Component	Page
Impact Sensors	8W-43
Inlet Air Temperature Sensor	8W-30
Instrument Cluster	8W-40
Instrument Panel Switch Bank	8W-43, 44, 52, 53, 63
Integrated Power Module	8W-13
Intrusion Sensors	8W-39
Knock Sensor	8W-30
Lamp Assemblies	8W-51
License Lamp	8W-51, 61
Lift Pump Relay	8W-30
Liftgate Ajar Switch	8W-39, 61
Liftgate Cinch/Release Motor	8W-61
Liftgate Flood Lamps	8W-44
Liftgate Left Pinch Sensor	8W-61
Liftgate Right Pinch Sensor	8W-61
Low Beam Lamps	8W-50
Manifold Absolute Pressure Sensor	8W-30
Mass Air Flow Sensor	8W-30
Memory Seat/Mirror/Adjustable Pedals Module	8W-56, 62, 63
Memory Set Switch	8W-63
Message Center	8W-40, 46
Mid Reading Lamps	8W-44
Mode Door Actuator	8W-42
Multi-Function Switch	8W-50, 52, 53
Natural Vacuum Leak Detection Assembly	8W-30
Occupant Classification Module	8W-43
Occupant Restraint Controller	8W-43
Overhead Console	8W-49
Oxygen Sensors	8W-30
Park Assist Display	8W-56
Park Assist Module	8W-56
Park Assist Sensors	8W-56
Park Lamp Relay	8W-13
Park Lamps	8W-50
Park/Turn Signal Lamps	8W-50
Parking Brake Switch	8W-40
Power Folding Mirror Switch	8W-62
Power Liftgate Module	8W-61
Power Liftgate Motor	8W-61
Power Mirror Switch	8W-62
Power Mirrors	8W-62
Power Outlet	8W-41
Power Seat Circuit Breaker	8W-13
Power Seat Motors	8W-63
Power Seat Position Sensors	8W-63
Power Seat Switches	8W-63
Power Window Circuit Breaker	8W-13
Power Window Motors	8W-60
Power Window Switches	8W-60
Powertrain Control Module	8W-30, 31
PTCs	8W-13
Radiator Fan Relays	8W-42
Radiator Fans	8W-42
Radio	8W-47

Component	Page
Reading Lamps	8W-44
Rear A/C-Heater Unit	8W-42
Rear Auto Temp Control Switch	8W-42
Rear Blower Front Control Switch	8W-42
Rear Blower Motor Power Module	8W-42
Rear Blower Rear Control Switch	8W-42
Rear Dome Lamp	8W-44
Rear Mode Motor	8W-42
Rear Power Outlet	8W-41
Rear Temperature Motor	8W-42
Rear View Mirror	8W-49, 55, 62
Rear Window Defogger Grid	8W-48
Rear Wiper Motor	8W-53
Recirculation Door Actuator	8W-42
Remote Radio Switches	8W-47
Repeater Lamps	8W-52
Seat Belt Switch	8W-43
Seat Belt Tensioners	8W-43
Seat Weight Sensor	8W-43
Sentry Key Remote Entry Module	8W-39
Siren	8W-39
Sliding Door Control Modules	8W-61
Sliding Door Latch Sensing Switches	8W-61
Sliding Door Lock Motor/Ajar Switches	8W-61
Sliding Door Lock Motors	8W-61
Sliding Door Motors	8W-61
Speakers	8W-47
Speed Control Servo	8W-33
Speed Control Switches	8W-33
Speed Sensors	8W-31
Splices	8W-70
Starter Motor	8W-21
Starter Motor Relay	8W-21
Sunroof Module	8W-64
Sunroof Switch	8W-64
Thatcham Alarm Indicator	8W-39
Thatcham Alarm Module	8W-39
Throttle Position Sensor	8W-30
Traction Control Switch	8W-35
Trailer Tow Connector	8W-54
Transmission Control Module	8W-31
Transmission Control Relay	8W-31
Transmission Range Sensor	8W-31
Transmission Solenoid/Pressure Switch Assembly	8W-31
Turn Signal Lamps	8W-52
Vehicle Speed Sensor	8W-30
Vent Motors	8W-60
Visor/Vanity Lamps	8W-44
Washer Fluid Level Switch	8W-53
Washer Pump Motor	8W-53
Water In Fuel Sensor	8W-30
Wheel Speed Sensors	8W-35
Wiper Module	8W-53