




8W-44 INTERIOR LIGHTING


Component	Page
A/C-Heater Control	8W-44-8
Accessory Relay	8W-44-4
Auto Temp Control	8W-44-8
Body Control Module . . .	8W-44-2, 3, 4, 5, 7, 8, 9, 10
Driver Door Courtesy Lamp	8W-44-2
Floor Console Lamp	8W-44-4, 5
Floor Console Power Outlet	8W-44-4
Front Control Module	8W-44-4
Front Reading Lamps/Switch	8W-44-2, 4, 5
Fuse 6	8W-44-4
G200	8W-44-7, 8
G300	8W-44-2, 8
G301	8W-44-2, 3, 5, 6
G302	8W-44-4
G303	8W-44-9, 10
Headlamp Switch	8W-44-3
Instrument Cluster	8W-44-7


Component	Page
Instrument Panel Switch Bank	8W-44-7
Integrated Power Module	8W-44-4
Left Liftgate Flood Lamp	8W-44-9, 10
Left Mid Reading Lamp	8W-44-3
Left Rear Reading Lamp	8W-44-3
Left Visor/Vanity Lamp	8W-44-5, 6
Overhead Console	8W-44-5
Passenger Door Courtesy Lamp	8W-44-2
Radio	8W-44-7
Rear Auto Temp Control Switch	8W-44-8
Rear Blower Rear Control Switch	8W-44-8
Rear Dome Lamp	8W-44-3, 5
Rear Power Outlet	8W-44-4
Right Liftgate Flood Lamp	8W-44-9, 10
Right Mid Reading Lamp	8W-44-3
Right Rear Reading Lamp	8W-44-3, 4
Right Visor/Vanity Lamp	8W-44-5, 6














△ HEATED SEATS
△△ EXCEPT HEATED SEATS

