

## 8W-50 FRONT LIGHTING

<b>Component</b>	<b>Page</b>
Body Control Module . . . . .	8W-50-2, 4, 5
Front Control Module . . . .	8W-50-3, 4, 6, 7, 8, 9, 10
Front Fog Lamp Relay . . . . .	8W-50-10
Fuse 1 . . . . .	8W-50-10
Fuse 2 . . . . .	8W-50-4, 6
Fuse 3 . . . . .	8W-50-4, 6
G102 . . . . .	8W-50-4, 6, 10
G200 . . . . .	8W-50-2, 9
G300 . . . . .	8W-50-3
Headlamp Switch . . . . .	8W-50-2, 9
Integrated Power Module . . . . .	8W-50-3, 4, 5, 6, 7, 8, 9, 10
Left Fog Lamp . . . . .	8W-50-10
Left Front Park/Turn Signal Lamp . . . . .	8W-50-4

<b>Component</b>	<b>Page</b>
Left Headlamp . . . . .	8W-50-3
Left Headlamp Leveling Motor . . . . .	8W-50-6, 9
Left High Beam Lamp . . . . .	8W-50-6, 7
Left Low Beam Lamp . . . . .	8W-50-7
Left Park Lamp . . . . .	8W-50-6, 7
Multi-Function Switch . . . . .	8W-50-5
Park Lamp Relay . . . . .	8W-50-4, 6
Right Fog Lamp . . . . .	8W-50-10
Right Front Park/Turn Signal Lamp . . . . .	8W-50-4
Right Headlamp . . . . .	8W-50-3
Right Headlamp Leveling Motor . . . . .	8W-50-6, 9
Right High Beam Lamp . . . . .	8W-50-6, 8
Right Low Beam Lamp . . . . .	8W-50-8
Right Park Lamp . . . . .	8W-50-6, 8



















