


## 8W-10 POWER DISTRIBUTION

<b>Component</b>	<b>Page</b>
B+ Module	8W-10-2
Battery	8W-10-7
Capacitor-Ignition	8W-10-14
Cartridge Fuses	8W-10-2
Circuit Breaker	8W-10-12
Coil-Ignition-No. 1	8W-10-15
Coil-Ignition-No. 2	8W-10-15
Coil-Ignition-No. 3	8W-10-15
Coil-Ignition-No. 4	8W-10-14, 15
Coil-Ignition-No. 5	8W-10-15
Coil-Ignition-No. 6	8W-10-14
Coil-Ignition-No. 7	8W-10-15
Coil-Ignition-No. 8	8W-10-14
Data Link Connector	8W-10-18
Fuse 1	8W-10-8, 10
Fuse 2	8W-10-8, 10
Fuse 3	8W-10-8, 11, 12
Fuse 4	8W-10-8, 11
Fuse 5	8W-10-8, 12
Fuse 6	8W-10-8, 11
Fuse 7	8W-10-8, 11, 16
Fuse 8	8W-10-8, 12, 16
Fuse 9	8W-10-16
Fuse 10	8W-10-8, 9, 12, 16
Fuse 11	8W-10-8, 12
Fuse 12	8W-10-8, 9, 16
Fuse 13	8W-10-9, 16
Fuse 14	8W-10-9, 16, 18
Fuse 15	8W-10-9, 16
Fuse 16	8W-10-8, 17, 19
Fuse 18	8W-10-9, 16, 17
Fuse 19	8W-10-9, 16, 17
Fuse 21	8W-10-9, 16
Fuse 22	8W-10-9, 17
Fuse 23	8W-10-9, 17
Fuse 24	8W-10-9, 11, 17
Fuse 25	8W-10-9, 17
Fuse 27	8W-10-9, 17
Fuse 33	8W-10-16
Fuse 34	8W-10-17, 18
Fuse 35	8W-10-11
Fusible Link	8W-10-7
G110	8W-10-7
G111	8W-10-7
G113	8W-10-13
G208	8W-10-18
Generator	8W-10-7

<b>Component</b>	<b>Page</b>
Injector-Fuel-No. 1	8W-10-15
Injector-Fuel-No. 2	8W-10-15
Injector-Fuel-No. 3	8W-10-15
Injector-Fuel-No. 4	8W-10-14, 15
Injector-Fuel-No. 5	8W-10-15
Injector-Fuel-No. 6	8W-10-15
Injector-Fuel-No. 7	8W-10-15
Injector-Fuel-No. 8	8W-10-14
Junction Block	8W-10-8, 9, 11, 12, 16, 17, 18
Mini Fuses	8W-10-2
Module-110v Inverter	8W-10-19
Module-Antilock Brakes	8W-10-9, 16
Module-Brake Provision	8W-10-8, 11
Module-Front Control	8W-10-10, 11, 13, 18, 19
Module-Heated Seat	8W-10-12
Module-Integrated Power	8W-10-8, 10, 11, 13, 17, 18
Module-Power Liftgate	8W-10-8, 12
Module-Powertrain Control	8W-10-9, 12, 14, 15, 17
Module-Seat Memory	8W-10-12
Module-Wireless Control	8W-10-18
Motor-Sunroof	8W-10-11
Power Distribution Center	8W-10-2, 7, 8, 9, 10, 11, 12, 16, 17, 19
Relay-A/C Clutch	8W-10-9, 17
Relay-Accessory Delay	8W-10-12
Relay-Auto Shut Down	8W-10-8, 12, 13
Relay-Blower Motor-Front	8W-10-11
Relay-Blower Motor-Rear	8W-10-16
Relay-Fuel Pump	8W-10-9, 16
Relay-Rear Window Defogger	8W-10-16
Relay-Run Remote	8W-10-11
Relay-Run/Start	8W-10-10, 17
Relay-Starter Motor	8W-10-8, 10
Relay-Stop Lamp Inhibit	8W-10-17
Relay-Transmission Control	8W-10-9, 16
Relay-Wiper High/Low	8W-10-10
Relay-Wiper On/Off	8W-10-10
Starter	8W-10-7, 10
Switch-Ignition	8W-10-18
Switch-Inverter	8W-10-19
Switch-Seat-Driver	8W-10-12
Switch-Seat-Passenger	8W-10-12
Switch-Stop Lamp	8W-10-17
Wiring-Trailer Tow 7-Way	8W-10-9, 17



## FUSES

FUSE NO.	AMPS	FUSED CIRCUIT	FUNCTION
1	30A	A923 14RD/OR	FUSED B(+)
2	30A	A5 14 RD/VT	FUSED B(+)
3	40A	A400 12TN/RD	FUSED B(+)
4	30A	A904 14RD/GY	FUSED B(+)
5	40A	A940 12RD/GY	FUSED B(+)
6	20A	A917 14RD/DB	FUSED B(+)
7	40A	A927 12RD/BR	FUSED B(+)
8	40A	A901 12RD/PK	FUSED B(+)
9	-	-	-
10	30A	A922 14RD/LB	FUSED B(+)
11	40A	A115 12YL/RD	FUSED B(+)
12	40A	A915 12OR/BR	FUSED B(+)
13	30A	A222 14RD/LB	FUSED B(+)
14	40A	A107 12TN/RD	FUSED B(+)
15	50A	A952 10OR/DB	FUSED B(+)
16	25A	A957 16RD	FUSED IGNITION SWITCH OUTPUT (START)
17	-	-	-
18	20A	A921 18OR/PK	FUSED B(+)
19	20A	A104 18YL/RD	FUSED B(+)
20	-	-	-
21	20A	A111 18DG/RD	FUSED B(+)
22	20A	A919 14OR/GY	FUSED B(+)
23	20A	A100 14RD/VT	FUSED B(+)
24	15A	A916 20OR/WT	FUSED B(+)
25	15A	A103 20GY/RD	FUSED B(+)
26	-	-	-
27	10A	A928 18RD	FUSED B(+)
28	-	-	-

## RELAYS

RELAY-A/C  
CLUTCH

CAVITY	CIRCUIT	FUNCTION
30	A916 20OR/WT	FUSED B(+)
85	C13 20LB/OR	A/C CLUTCH RELAY CONTROL
86	F202 20PK/GY	FUSED IGNITION SWITCH OUTPUT (RUN-START)
87	C3 20DB/GY	A/C CLUTCH RELAY OUTPUT
87A	-	-

RELAY-AUTO  
SHUT  
DOWN

CAVITY	CIRCUIT	FUNCTION
30	A922 14RD/LB	FUSED B(+)
85	K51 20BR/GY	ASD RELAY OUTPUT
86	A922 14RD/LB	FUSED B(+)
87	A955 14RD	ASD RELAY OUTPUT
87A	-	-

RELAY-BLOWER  
MOTOR-  
FRONT

CAVITY	CIRCUIT	FUNCTION
30	A927 12RD/BR	FUSED B(+)
85	C229 20DB	FRONT BLOWER CONTROL
86	A927 12RD/BR	FUSED B(+)
87	C7 12DB	FRONT BLOWER MOTOR RELAY OUTPUT
87A	-	-

RELAY-FUEL  
PUMP

CAVITY	CIRCUIT	FUNCTION
30	A921 18OR/PK	FUSED B(+)
85	K31 20BR	FUEL PUMP RELAY CONTROL
86	F202 20PK/GY	FUSED IGNITION SWITCH OUTPUT (RUN-START)
87	N1 18DB/OR	FUEL PUMP RELAY OUTPUT
87A	-	-

## RELAYS

RELAY-RUN  
REMOTE

CAVITY	CIRCUIT	FUNCTION
30	A917 14RD/BR	FUSED B(+)
85	C229 20DB	FRONT BLOWER CONTROL
86	A917 14RD/BR	FUSED B(+)
87	F921 14PK/YL	IGNITION SWITCH OUTPUT (RUN)
87A	-	-

RELAY-RUN/  
START

CAVITY	CIRCUIT	FUNCTION
30	A928 18RD	FUSED B(+)
85	K617 20BR	RUN START RELAY CONTROL
86	A928 18RD	FUSED B(+)
87	F941 18PK/LG	IGNITION SWITCH OUTPUT (RUN-START)
87A	-	-

RELAY-  
STARTER  
MOTOR

CAVITY	CIRCUIT	FUNCTION
30	A923 14RD/OR	FUSED B(+)
85	T752 20DG/OR	ENGINE STARTER MOTOR RELAY CONTROL
86	F924 20PK/YL	FUSED IGNITION SWITCH OUTPUT (START)
87	T750 14GY/YL	ENGINE STARTER MOTOR RELAY OUTPUT
87A	-	-

RELAY-  
STOP LAMP  
INHIBIT

CAVITY	CIRCUIT	FUNCTION
30	L950 10WT/LG	ACCESSORY DELAY RELAY OUTPUT
85	B45 20 DG/LB	STOP LAMP INHIBIT RELAY CONTROL
86	F500 20DG/PK	FUSED IGNITION SWITCH OUTPUT (RUN)
87	-	-
87A	L50 20WT/TN	BRAKE LAMP SWITCH OUTPUT

RELAYS

RELAY-  
TRANSMISSION  
CONTROL

CAVITY	CIRCUIT	FUNCTION
30	A104 18YL/RD	FUSED B(+)
85	Z915 20BK	GROUND
86	T15 20YL/VT	TRANSMISSION CONTROL RELAY CONTROL
87	T16 18YL/OR	TRANSMISSION CONTROL RELAY OUTPUT
87A	-	-

