

8W - 31 TRANSMISSION CONTROL SYSTEM

Component	Page
Accelerator Pedal Position Sensor	8W-31-12
Battery	8W-31-2, 5, 6, 7, 10, 11
Brake Transmission Shift Interlock Solenoid	8W-31-3, 8
Data Link Connector	8W-31-12
Engine Control Module	8W-31-8, 12
Front Control Module	8W-31-3, 6, 8, 12
Fuse 15	8W-31-2, 5
Fusible Link	8W-31-7, 10, 11
G101	8W-31-2, 5, 6, 7

Component	Page
Input Speed Sensor	8W-31-4, 9
Integrated Power Module	8W-31-2, 3, 5, 6, 8, 12
Output Speed Sensor	8W-31-4, 9
Powertrain Control Module	8W-31-2, 3, 4, 5, 6
Transmission Control Module	8W-31-7, 8, 9, 10, 11, 12
Transmission Control Relay	8W-31-2, 5, 7, 10, 11
Transmission Range Sensor	8W-31-3, 4, 8, 9
Transmission Solenoid/Pressure Switch Assembly	8W-31-2, 5, 6, 7, 10, 11

GAS





















