




8W - 30 FUEL / IGNITION SYSTEM

Component	Page
A/C Compressor Clutch	8W-30-20
A/C Compressor Clutch Relay	8W-30-4, 20
A/C Pressure Sensor	8W-30-13, 18, 27
Accelerator Pedal Position Sensor	8W-30-32, 34
Ambient Temperature Sensor	8W-30-8
Auto Shut Down Relay	8W-30-4, 11, 14, 16, 19
Battery	8W-30-2, 6, 10, 15, 20, 28
Battery Temperature Sensor	8W-30-27
Body Control Module	8W-30-5, 21
Boost Pressure Sensor	8W-30-27
Brake Lamp Switch	8W-30-7, 23, 33
Cabin Heater Assist	8W-30-24
Camshaft Position Sensor	8W-30-8, 26
Clockspring	8W-30-5, 25, 32
Clutch Pedal Interlock Switch	8W-30-7
Clutch Pedal Upstop Switch	8W-30-32
Crank Case Ventilation Heater	8W-30-21
Crankshaft Position Sensor	8W-30-12, 17, 26
Data Link Connector	8W-30-3, 24
Dosing Pump	8W-30-24
ECM/PCM Relay	8W-30-20, 22, 26, 28, 30
EGR Solenoid	8W-30-15, 30
EVAP/Purge Solenoid	8W-30-4
Engine Control Module	8W-30-20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35
Engine Coolant Temp Sensor	8W-30-13, 18, 27
Engine Oil Pressure Sensor	8W-30-23
Engine Oil Pressure Switch	8W-30-7
Front Control Module	8W-30-2, 5, 24, 32
Fuel Heater	8W-30-21, 31
Fuel Heater Relay	8W-30-21, 31
Fuel Injector No. 1	8W-30-14, 19, 29
Fuel Injector No. 2	8W-30-14, 19, 29
Fuel Injector No. 3	8W-30-14, 19, 29
Fuel Injector No. 4	8W-30-14, 19, 29
Fuel Injector No. 5	8W-30-19
Fuel Injector No. 6	8W-30-19
Fuel Pressure Sensor	8W-30-33
Fuel Pressure Solenoid	8W-30-22
Fuel Pump Module	8W-30-5, 21
Fuel Pump Relay	8W-30-5
Fuse 15	8W-30-24, 31
Fuse 16	8W-30-4, 11, 14, 16, 19, 20, 22, 26, 28, 30
Fuse 17	8W-30-2, 5, 21, 31
Fuse 18	8W-30-20


Component	Page
Fuse 26	8W-30-33
Fusible Link	8W-30-28
G100	8W-30-2, 6, 15, 21
G101	8W-30-2, 6, 7, 10, 15, 20
G103	8W-30-20, 21, 24, 31
G300	8W-30-7, 23, 32
G302	8W-30-5, 21
Generator	8W-30-4, 21
Glow Plug No. 1	8W-30-28
Glow Plug No. 2	8W-30-28
Glow Plug No. 3	8W-30-28
Glow Plug No. 4	8W-30-28
Glow Plug Relay	8W-30-28
Idle Air Control Motor	8W-30-9
Ignition Coil	8W-30-11, 16
Ignition Switch	8W-30-10
Inlet Air Temperature Sensor	8W-30-12, 17
Integrated Power Module	8W-30-2, 3, 4, 5, 10, 11, 14, 16, 19, 20, 21, 22, 24, 26, 28, 30, 31, 32, 33
Knock Sensor	8W-30-9
Left Speed Control Switch	8W-30-5, 25
Lift Pump Relay	8W-30-31
Manifold Absolute Pressure Sensor . . .	8W-30-13, 18
Mass Air Flow Sensor	8W-30-22
Natural Vacuum Leak Detection Assembly	8W-30-10
Oxygen Sensor 1/1 Upstream	8W-30-6
Oxygen Sensor 1/2 Downstream	8W-30-6
Powertrain Control Module	8W-30-2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19
Radiator Fan Relay	8W-30-11, 16
Radiator Fan Relay No. 1	8W-30-33
Radiator Fan Relay No. 2	8W-30-33
Radiator Fan Relay No. 3	8W-30-33
Right Speed Control Switch	8W-30-5, 25
Speed Control Servo	8W-30-7
Starter Motor Relay	8W-30-5, 21
Throttle Position Sensor	8W-30-12, 17
Throttle Valve Solenoid	8W-30-20
Transmission Control Module	8W-30-28, 32, 34, 35
Transmission Control Relay	8W-30-28
Transmission Range Sensor	8W-30-32
Vehicle Speed Sensor	8W-30-9, 30
Water In Fuel Sensor	8W-30-32











GAS















■ MTX




2.4L











2.4L































DIESEL





■ ■ GROUND (DRAIN)





