

8W - 18 BUS COMMUNICATIONS

Component	Page
A/C-Heater Control	8W-18-6
Amplifier	8W-18-5
Anti-Lock Brake Module	8W-18-3, 4
Auto Temp Control	8W-18-6
Battery	8W-18-2
Body Control Module	8W-18-3, 4, 5
CD Changer	8W-18-6
Cabin Heater Assist	8W-18-4
Controller Anti-Lock Brake	8W-18-3, 4
DVD/CD Changer	8W-18-6
Data Link Connector	8W-18-2, 3, 4, 5
Engine Control Module	8W-18-4
Front Control Module	8W-18-3, 4, 5
G100	8W-18-2
G101	8W-18-2
G300	8W-18-2
Hands Free Module	8W-18-6

Component	Page
Instrument Cluster	8W-18-6
Integrated Power Module	8W-18-2, 3, 4, 5
Left Sliding Door Control Module	8W-18-5
Memory Seat/Mirror/Adjustable Pedals Module	8W-18-5
Occupant Classification Module	8W-18-5
Occupant Restraint Controller	8W-18-6
Overhead Console	8W-18-5
PTC 7	8W-18-2
Park Assist Module	8W-18-5
Power Liftgate Module	8W-18-5
Powertrain Control Module	8W-18-3
Radio	8W-18-6
Right Sliding Door Control Module	8W-18-5
Sentry Key Remote Entry Module	8W-18-6
Thatcham Alarm Module	8W-18-3, 4, 6
Transmission Control Module	8W-18-4









