

8W - 02 COMPONENT INDEX

Component	Page	Component	Page
A/C Compressor Clutch	8W-42	Dosing Pump	8W-30
A/C Compressor Clutch Relay	8W-42	ECM/PCM Relay	8W-30
A/C Pressure Sensor	8W-42	EGR Solenoid	8W-30
A/C-Heater Control	8W-42	EVAP/Purge Solenoid	8W-30
ATC Remote Sensor	8W-42	Engine Control Module	8W-30
Accelerator Pedal Position Sensor	8W-30	Engine Coolant Temp Sensor	8W-30
Accessory Relay	8W-13	Engine Oil Pressure Sensor	8W-30
Adjustable Pedals Motor	8W-56	Engine Oil Pressure Switch	8W-30
Adjustable Pedals Relay	8W-56	Evaporator Temperature Sensor	8W-42
Adjustable Pedals Sensor	8W-56	Floor Console Lamp	8W-44
Adjustable Pedals Switch	8W-56	Floor Console Power Outlet	8W-41
Airbag	8W-43	Fog Lamps	8W-50
Airbag On/Off Indicator Lamp	8W-43	Folding Mirror Relay	8W-62
Airbag Squibs	8W-43	Front Blower Module	8W-42
Ambient Temperature Sensor	8W-49	Front Cigar Lighter	8W-41
Amplifier	8W-47	Front Control Module	8W-13
Antenna	8W-47	Front Fog Lamp Relay	8W-50
Antenna-Satellite Radio	8W-47	Front Reading Lamps/Switch	8W-44
Anti-Lock Brake Module	8W-35	Front Wiper High/Low Relay	8W-53
Auto Shut Down Relay	8W-30	Front Wiper On/Off Relay	8W-53
Auto Temp Control	8W-42	Fuel Heater	8W-30
B-Pillar Switches	8W-61	Fuel Heater Relay	8W-30
Backup Lamp Switch	8W-51	Fuel Injectors	8W-30
Battery	8W-13	Fuel Pressure Sensor	8W-30
Battery Temperature Sensor	8W-20	Fuel Pressure Solenoid	8W-30
Belt Tension Sensor	8W-43	Fuel Pump Module	8W-30
Blend Door Actuators	8W-42	Fuel Pump Relay	8W-30
Blower Motor Relays	8W-42	Full Open Switches	8W-61
Blower Motor Resistor	8W-42	Fuses	8W-13
Blower Motors	8W-42	Fusible Link	8W-13
Body Control Module	8W-45	Generator	8W-20
Boost Pressure Sensor	8W-30	Glow Plug Relay	8W-30
Brake Fluid Level Switch	8W-35	Glow Plugs	8W-30
Brake Lamp Switch	8W-30, 51	Grounds	8W-15
Brake Transmission Shift Interlock Solenoid	8W-31	Hands Free Module	8W-55
CD Changer	8W-47	Headlamp Leveling Motors	8W-50
Cabin Heater Assist	8W-30	Headlamp Switch	8W-50
Camshaft Position Sensor	8W-30	Headlamp Washer Pump Motor	8W-53
Center High Mounted Stop Lamp	8W-51	Headlamp Washer Relay	8W-53
Cinch/Release Motors	8W-61	Headlamps	8W-50
Clockspring	8W-33, 41, 43, 47	Heated Seat Backs	8W-63
Clutch Pedal Interlock Switch	8W-21	Heated Seat Cushions	8W-63
Clutch Pedal Upstop Switch	8W-30	Heated Seat Modules	8W-63
Controller Anti-Lock Brake	8W-35	High Beam Lamps	8W-50
Crank Case Ventilation Heater	8W-30	High Note Horn	8W-41
Crankshaft Position Sensor	8W-30	Hood Ajar Switch	8W-39
Cylinder Lock Switches	8W-39	Horn Relay	8W-41
DVD Screen	8W-47	Horn Switch	8W-41
DVD/CD Changer	8W-47	Idle Air Control Motor	8W-30
Data Link Connector	8W-18	Ignition Coil	8W-30
Defogger Relay	8W-48	Ignition Switch	8W-13
Door Ajar Switches	8W-39	Impact Sensors	8W-43
Door Courtesy Lamps	8W-44	Inlet Air Temperature Sensor	8W-30
Door Lock Motor/Ajar Switches	8W-61	Instrument Cluster	8W-40
Door Lock Switches	8W-61	Instrument Panel Switch Bank	8W-43, 44, 52, 53, 63

Component	Page
Integrated Power Module	8W-13
Intrusion Sensors	8W-39
Knock Sensor	8W-30
Lamp Assemblies	8W-51
License Lamp	8W-51, 61
Lift Pump Relay	8W-30
Liftgate Ajar Switch	8W-39, 61
Liftgate Cinch/Release Motor	8W-61
Liftgate Flood Lamps	8W-44
Liftgate Pinch Sensors	8W-61
Low Beam Lamps	8W-50
Manifold Absolute Pressure Sensor	8W-30
Mass Air Flow Sensor	8W-30
Memory Seat/Mirror/Adjustable Pedals Module	8W-56, 62, 63
Memory Set Switch	8W-63
Message Center	8W-40, 46
Mid Reading Lamps	8W-44
Mode Door Actuator	8W-42
Multi-Function Switch	8W-50, 52, 53
Natural Vacuum Leak Detection Assembly	8W-30
Occupant Classification Module	8W-43
Occupant Restraint Controller	8W-43
Overhead Console	8W-49
Oxygen Sensors	8W-30
PTCs	8W-13
Park Assist Display	8W-56
Park Assist Module	8W-56
Park Assist Sensors	8W-56
Park Lamp Relay	8W-13
Park Lamps	8W-50
Park/Turn Signal Lamps	8W-50
Parking Brake Switch	8W-40
Power Folding Mirror Switch	8W-62
Power Liftgate Module	8W-61
Power Liftgate Motor	8W-61
Power Mirror Switch	8W-62
Power Mirrors	8W-62
Power Outlets	8W-41
Power Seat Circuit Breaker	8W-13
Power Seat Motors	8W-63
Power Seat Position Sensors	8W-63
Power Seat Switches	8W-63
Power Window Circuit Breaker	8W-13
Power Window Motors	8W-60
Power Window Switches	8W-60
Powertrain Control Module	8W-30, 31
Radiator Fan Relays	8W-42
Radiator Fans	8W-42
Radio	8W-47
Reading Lamps	8W-44
Rear A/C-Heater Unit	8W-42
Rear Auto Temp Control Switch	8W-42
Rear Blower Front Control Switch	8W-42

Component	Page
Rear Blower Motor Power Module	8W-42
Rear Blower Rear Control Switch	8W-42
Rear Dome Lamp	8W-44
Rear Intrusion Sensor	8W-39
Rear Mode Motor	8W-42
Rear Temperature Motor	8W-42
Rear View Mirror	8W-49, 55, 62
Rear Window Defogger Grid	8W-48
Rear Wiper Motor	8W-53
Recirculation Door Actuator	8W-42
Remote Radio Switches	8W-47
Repeater Lamps	8W-52
Satellite Radio Multiplexer	8W-47
Satellite Radio Receiver	8W-47
Seat Belt Switches	8W-43
Seat Belt Tensioners	8W-43
Seat Weight Sensor	8W-43
Sentry Key Remote Entry Module	8W-39
Siren	8W-39
Sliding Door Control Modules	8W-61
Sliding Door Latch Sensing Switches	8W-61
Sliding Door Lock Motor/Ajar Switches	8W-61
Sliding Door Lock Motors	8W-61
Sliding Door Motors	8W-61
Speakers	8W-47
Speed Control Servo	8W-33
Speed Control Switches	8W-33
Speed Sensors	8W-31
Splices	8W-13, 15, 18, 30, 31, 39, 42, 44, 45, 47, 55, 56, 63, 70
Starter Motor	8W-21
Starter Motor Relay	8W-21
Sunroof Module	8W-64
Sunroof Switch	8W-64
Thatcham Alarm Indicator	8W-39
Thatcham Alarm Module	8W-39
Throttle Position Sensor	8W-30
Throttle Valve Solenoid	8W-30
Traction Control Switch	8W-35
Trailer Tow Connector	8W-54
Transmission Control Module	8W-31
Transmission Control Relay	8W-31
Transmission Range Sensor	8W-31
Transmission Solenoid/Pressure Switch Assembly	8W-31
Turn Signal Lamps	8W-52
Vehicle Speed Sensor	8W-30
Vent Motors	8W-60
Visor/Vanity Lamps	8W-44
Washer Fluid Level Switch	8W-53
Washer Pump Motor	8W-53
Water In Fuel Sensor	8W-30
Wheel Speed Sensors	8W-35
Wiper Module	8W-53