




8W-31 TRANSMISSION CONTROL SYSTEM


Component	Page	Component	Page
Assembly-Shift Motor/Mode		Module-Front Control	8W-31-2, 7, 11
Sensor	8W-31-16, 17, 18	Module-Integrated	
Assembly-Transmission		Power	8W-31-2, 7, 10, 11, 12, 13, 15, 19
Solenoid	8W-31-10, 12, 14	Module-Powertrain	
Assembly-Transmission		Control	8W-31-2, 3, 4, 5, 6, 10, 11
Solenoid/TRS	8W-31-2, 3, 4	Module-Transfer Case	
Assembly-Transmission		Control	8W-31-15, 16, 17, 18, 19
Throttle Valve	8W-31-12, 14	Relay-Starter Motor	8W-31-15
Clockspring	8W-31-14	Relay-Transmission Control	8W-31-2, 10, 12
Cluster	8W-31-8, 11, 13, 19	Sensor-Input Speed	8W-31-5
Data Link Connector	8W-31-16	Sensor-Line Pressure	8W-31-6
Fuse 5	8W-31-2, 10, 12	Sensor-Output Speed	8W-31-5, 10, 12
Fuse 28	8W-31-19	Sensor-Transfer Case Position	8W-31-9, 19
Fuse 38	8W-31-2, 11, 13	Sensor-Transmission Range	8W-31-11, 13
Fuse 43	8W-31-7, 15	Solenoid-Locker Front	8W-31-9
Fuse 50	8W-31-7, 12	Solenoid-Locker Rear	8W-31-9
G103	8W-31-2	Switch-Axle Lock	8W-31-8
G104	8W-31-2, 7, 16, 19	Switch-Clutch Interlock	8W-31-15
G106	8W-31-7, 8, 16, 19	Switch-Disconnecting Stabilizer Bar	8W-31-7, 8
G107	8W-31-5, 19	Switch-Speed Control-Left	8W-31-14
G201	8W-31-3, 14	Switch-Speed Control-Right	8W-31-14
Mirror-Inside Rearview	8W-31-11, 13	Switch-Tow/Haul Overdrive	8W-31-3, 14
Module-Engine Control	8W-31-12, 13, 14	Switch-Transfer Case Selector	8W-31-15, 19
Module-Final Drive Control	8W-31-7, 8, 9		


NGC














5.7L HD





5.7L HD







SRT





DIESEL





DIESEL

