

## 8W-21 STARTING SYSTEM

<b>Component</b>	<b>Page</b>
Battery . . . . .	8W-21-2, 3, 4
Battery-Auxiliary . . . . .	8W-21-4
Fuse 14 . . . . .	8W-21-2, 4
Fuse 30 . . . . .	8W-21-2
G103 . . . . .	8W-21-2
G104 . . . . .	8W-21-2, 3, 5
G107 . . . . .	8W-21-2
Module-Engine Control . . . . .	8W-21-5
Module-Integrated Power . . . . .	8W-21-2, 3, 4, 5
Module-Powertrain Control . . . . .	8W-21-2, 3

<b>Component</b>	<b>Page</b>
Module-Transfer Case Control . . . . .	8W-21-5
PTC No. 2 . . . . .	8W-21-3
Relay-Starter . . . . .	8W-21-3
Relay-Starter Motor . . . . .	8W-21-2, 4
Sensor-Transmission Range . . . . .	8W-21-5
Starter . . . . .	8W-21-2, 3, 4
Switch-Clutch Interlock . . . . .	8W-21-2, 3, 4, 5
Switch-Ignition . . . . .	8W-21-2, 3, 4
Switch-Push-Button Starter . . . . .	8W-21-3









