

8W-63 POWER SEATS

Component	Page
Cluster	8W-63-5
Fuse 7	8W-63-2
Fuse 48	8W-63-6
G203	8W-63-5
G302	8W-63-2, 3, 4, 7
G303	8W-63-7
Heater-Seat Cushion-Driver	8W-63-7
Heater-Seat Cushion-Passenger	8W-63-7
Lumbar Motor-Passenger	8W-63-4
Module-Heated Seats	8W-63-6, 7
Module-Integrated Power	8W-63-2, 6
Motor-Lumbar-Driver	8W-63-2
Motor-Lumbar-Passenger	8W-63-3

Component	Page
Motor-Seat Adjuster-Driver Horizontal	8W-63-2
Motor-Seat Adjuster-Front Driver Vertical .	8W-63-2
Motor-Seat Adjuster-Front Passenger Vertical	8W-63-4
Motor-Seat Adjuster-Passenger Horizontal .	8W-63-4
Motor-Seat Adjuster-Rear Driver Vertical . .	8W-63-2
Motor-Seat Adjuster-Rear Passenger Vertical	8W-63-4
Switch-Heated Seat-Driver	8W-63-5, 6
Switch-Heated Seat-Passenger	8W-63-5, 6
Switch-Seat-Driver	8W-63-2
Switch-Seat-Passenger	8W-63-3, 4













