

## 8W-43 OCCUPANT RESTRAINT SYSTEM

<b>Component</b>	<b>Page</b>
Airbag-Driver Squib 1 . . . . .	8W-43-3
Airbag-Driver Squib 2 . . . . .	8W-43-3
Airbag-Passenger Squib . . . . .	8W-43-3
Airbag-Side Curtain-Left . . . . .	8W-43-4
Airbag-Side Curtain-Right . . . . .	8W-43-4
Clockspring . . . . .	8W-43-3
Cluster . . . . .	8W-43-4
Data Link Connector . . . . .	8W-43-2
Fuse 52 . . . . .	8W-43-2
Fuse 53 . . . . .	8W-43-2
G204 . . . . .	8W-43-2

<b>Component</b>	<b>Page</b>
Module-Integrated Power . . . . .	8W-43-2, 4
Module-Occupant Restraint	
Controller . . . . .	8W-43-2, 3, 4
PTC No. 2 . . . . .	8W-43-4
Seat Belt Tensioner-Driver . . . . .	8W-43-3
Seat Belt-Tension Reducer-Driver . . . . .	8W-43-4
Seat Belt-Tensioner-Passenger . . . . .	8W-43-3
Sensor-Side Impact-Left 1 . . . . .	8W-43-4
Sensor-Side Impact-Right 1 . . . . .	8W-43-4
Switch-Passenger Airbag On/Off . . . . .	8W-43-2





