



8W-30 FUEL/IGNITION SYSTEM


Component	Page
Actuator-Fuel Control	8W-30-40
Assembly-Exhaust Gas Recirculation Valve . . .	8W-30-27, 28
Assembly-Natural Vacuum Leak Detection	8W-30-12
Assembly-Transmission Solenoid	8W-30-44, 45
Assembly-Transmission Throttle Valve	8W-30-45
Battery	8W-30-30, 31
Capacitor-Ignition	8W-30-6
Clockspring	8W-30-13, 28, 38
Coil-Ignition-Left	8W-30-24
Coil-Ignition-No. 1	8W-30-7, 8
Coil-Ignition-No. 2	8W-30-7, 9
Coil-Ignition-No. 3	8W-30-7, 8
Coil-Ignition-No. 4	8W-30-7, 9
Coil-Ignition-No. 5	8W-30-6, 8
Coil-Ignition-No. 6	8W-30-6, 9
Coil-Ignition-No. 7	8W-30-6, 8
Coil-Ignition-No. 8	8W-30-6, 9
Coil-Ignition-Right	8W-30-24
Data Link Connector	8W-30-14, 38
Data Link Connector-Engine	8W-30-40
Drive-Fan-Radiator	8W-30-36, 37
Fuse 2	8W-30-5
Fuse 5	8W-30-26, 44
Fuse 12	8W-30-34
Fuse 17	8W-30-3
Fuse 23	8W-30-2
Fuse 36	8W-30-37
Fuse 49	8W-30-5
Fuse 50	8W-30-2, 35, 44
Fusible Link	8W-30-30
G103	8W-30-13
G104	8W-30-3, 13, 24, 34, 45
G105	8W-30-30
G106	8W-30-3
G107	8W-30-2, 12, 18, 19, 27
G110	8W-30-2, 20
G114	8W-30-31
G120	8W-30-34
G201	8W-30-11
Generator	8W-30-12, 40
Heater-Fuel	8W-30-34
Heater-Intake Air No. 1	8W-30-30
Heater-Intake Air No. 2	8W-30-30
Injector-Fuel-No. 1	8W-30-7, 8, 10, 43
Injector-Fuel-No. 2	8W-30-7, 9, 10, 43
Injector-Fuel-No. 3	8W-30-7, 8, 10, 43
Injector-Fuel-No. 4	8W-30-7, 9, 10, 42
Injector-Fuel-No. 5	8W-30-7, 8, 10, 42
Injector-Fuel-No. 6	8W-30-7, 9, 10, 42
Injector-Fuel-No. 7	8W-30-6, 8, 10
Injector-Fuel-No. 8	8W-30-6, 9, 10
Injector-Fuel-No. 9	8W-30-10
Injector-Fuel-No. 10	8W-30-10
Module-Anti-Lock Brakes	8W-30-11, 39
Module-Engine Control	8W-30-30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45
Module-Fuel Pump	8W-30-3, 35
Module-Integrated Power	8W-30-2, 3, 4, 5, 14, 26, 31, 33, 34, 35, 37, 38, 44


Component	Page
Module-Powertrain Control	8W-30-2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29
Motor-Iac	8W-30-14
PTC No. 1	8W-30-3, 4, 14, 34, 35, 38
Pto Switch	8W-30-11
Pump-Fuel Injection	8W-30-33
Relay-Auto Shut Down	8W-30-5, 21
Relay-Clutch-A/C Compressor	8W-30-14, 35
Relay-Condenser Fan	8W-30-14
Relay-Fuel Heater	8W-30-34
Relay-Fuel Pump	8W-30-3
Relay-Intake Air Heater No. 1	8W-30-30
Relay-Intake Air Heater No. 2	8W-30-30
Relay-Oxygen Sensor Downstream	8W-30-5, 20
Relay-Starter	8W-30-25
Relay-Starter Motor	8W-30-2, 33
Relay-Transmission Control	8W-30-44
Sensor-Accelerator Pedal Position	8W-30-28, 32
Sensor-Ambient Air Temperature	8W-30-25
Sensor-Battery Temperature	8W-30-4, 30
Sensor-Camshaft Position	8W-30-15, 28, 41
Sensor-Crankshaft Position	8W-30-15, 41
Sensor-Engine Coolant Temperature	8W-30-22, 23, 32
Sensor-Engine Oil Pressure	8W-30-23
Sensor-Engine Oil Temperature	8W-30-26
Sensor-Intake Air Temperature	8W-30-22, 23
Sensor-Knock	8W-30-17
Sensor-Knock No. 1	8W-30-17
Sensor-Knock No. 2	8W-30-17
Sensor-Line Pressure	8W-30-16
Sensor-Map	8W-30-22, 23, 28
Sensor-Output Speed	8W-30-44
Sensor-Oxygen-Left Front	8W-30-19, 21
Sensor-Oxygen-Left Rear	8W-30-18, 20
Sensor-Oxygen-Right Front	8W-30-19, 21
Sensor-Oxygen-Right Rear	8W-30-18, 20
Sensor-Temperature/Pressure Intake	8W-30-36
Sensor-Temperature/Pressure-Map	8W-30-40
Sensor-Throttle Position	8W-30-16, 26
Sensor-Transmission Range	8W-30-25, 33
Sensor-Water In Fuel	8W-30-32, 33
Servo-Speed Control	8W-30-13
Solenoid-EVAP/Purge	8W-30-4
Solenoid-Radiator Fan	8W-30-24
Solenoid-Reverse Lock-Out	8W-30-26
Solenoid-Wastegate	8W-30-37, 38
Switch-Clutch Interlock	8W-30-25, 33
Switch-Engine Oil Pressure	8W-30-31
Switch-Ignition	8W-30-11
Switch-Oil Pressure	8W-30-2
Switch-Power Steering Pressure	8W-30-12
Switch-Speed Control-Left	8W-30-13, 28, 38
Switch-Speed Control-Right	8W-30-13, 28
Switch-Stop Lamp	8W-30-13, 39, 45
Switch-Tow/Haul Overdrive	8W-30-11, 33
Throttle Body	8W-30-29
Transducer-A/C Pressure	8W-30-22, 23, 41





☐ NGC
☐ ☐ ☐ SRT















5.7L





5.7L























3.7L
4.7L
5.7L
3.7L/4.7L
SRT

