

8W-54 TRAILER TOW

| Component | Page | Component | Page |
|-------------------------------------|-------------|-------------------------------------|------------------|
| Fuse 3 | 8W-54-2 | Mirror-Inside Rearview | 8W-54-5 |
| Fuse 9 | 8W-54-3 | Module-Brake Provision | 8W-54-2 |
| Fuse 19 | 8W-54-4 | Module-Front Control | 8W-54-4, 5 |
| Fuse 21 | 8W-54-4 | Module-Integrated Power | 8W-54-3, 4, 5 |
| Fuse 23 | 8W-54-5 | Power Distribution Center | 8W-54-2, 5 |
| G114 | 8W-54-2 | Relay-Park Lamp | 8W-54-3 |
| G305 | 8W-54-3 | Relay-Trailer Tow-Left | 8W-54-4 |
| Junction Block | 8W-54-2, 5 | Relay-Trailer Tow-Right | 8W-54-4 |
| Lamp-High Mounted Stop | 8W-54-2 | Switch-Stop Lamp | 8W-54-2 |
| Lamp-Tail/Stop/Turn-Left | 8W-54-2, 5 | Wiring-Trailer Tow 4-Way | 8W-54-3, 4 |
| Lamp-Tail/Stop/Turn-Right | 8W-54-2, 5 | Wiring-Trailer Tow 7-Way | 8W-54-2, 3, 4, 5 |









