

8W-20 CHARGING SYSTEM

Component	Page	Component	Page
Battery	8W-20-2	Module-Front Control	8W-20-2
Fusible Link	8W-20-2	Module-Integrated Power	8W-20-2
G100	8W-20-2	Module-Powertrain Control	8W-20-2
G110	8W-20-2	Power Distribution Center	8W-20-2
G111	8W-20-2	Sensor-Battery Temperature	8W-20-2
Generator	8W-20-2	Starter	8W-20-2

