

## 8W-91 CONNECTOR/GROUND/SPLICE LOCATION

## TABLE OF CONTENTS

page

**CONNECTOR/GROUND/SPLICE LOCATION**

DESCRIPTION ..... 1

**CONNECTOR/GROUND/SPLICE LOCATION****DESCRIPTION**

This section provides illustrations identifying connector, ground and splice locations in the vehicle. Connector, ground and splice indexes are provided. Use the wiring diagrams in each section for connector, ground and splice identification. Refer to the appropriate index for the proper figure number. For items that are not shown in this section N/S is placed in the Fig. column.

**CONNECTORS**

CONNECTOR NAME/ NUMBER	COLOR	LOCATION	FIG.
Actuator-Blend Door-Front	GY	Front HVAC Unit	27
Actuator-Blend Door-Rear	GY	Rear HVAC Unit	48
Actuator-Mode Door-Floor to Defrost-Front	GY	Front HVAC Unit	27
Actuator-Mode Door-Floor to Panel-Front	GY	Front HVAC Unit	27
Actuator-Mode Door-Rear	GY	Rear HVAC Unit	48
Actuator-Recirculation Door-Front	GY	Front HVAC Unit	27
Airbag-Driver Squib 1	TAN	Steering Wheel	33
Airbag-Driver Squib 2	BK	Steering Wheel	33
Airbag-Passenger Squib	YL	Right Instrument Panel	29
Airbag-Side Curtain-Left	YL	Left Side B-Pillar	44
Airbag-Side Curtain-Right	YL	Right Side B-Pillar	47
Amplifier-Radio C1	NAT	Right Lower Kick Panel	36, 46
Amplifier-Radio C2	WT	Right Lower Kick Panel	36
Antenna-Radio	-	Right Lower Kick Panel	37
Antenna-Receiver Satellite	-	Rear of Roof	45
Assembly-EGR Valve	BK	Right Front of Engine	22, 23
Assembly-Natural Vacuum Leak Detection	BK	Left Side of Fuel Tank	53
Assembly-Shift Motor/Mode Sensor	GY	Front of Transfer Case	20
Assembly-Transmission Solenoid/TRS	BK	Right Side of Transmission	13, 18, 26

CONNECTOR NAME/ NUMBER	COLOR	LOCATION	FIG.
Battery (+)	-	Right Front Engine Compartment	5
Battery (-)	-	Right Front Engine Compartment	5
C105	BK	Near T/O for Oil Pressure Switch	10
C108	BK	Right Front of Engine Compartment	4, 17
C109 (5.7L)	BK	Top Right Rear of Engine	21, 24
C110 (5.7L)	BK	Top Right Rear of Engine	21, 24
C200	BK	Lower Left Instrument Panel	28, 31, 35
C201	NAT	Lower Left Instrument Panel	28, 31
C202	GY	Front HVAC Unit	27, 29, 36
C203		Lower Left Instrument Panel	31
C220	BK	Right Side Headliner	42
C221	WT	Left Side Instrument Panel	35, 42
C222	WT	Left Side Instrument Panel	35, 42
C248	BK	Under Driver Seat	39, 43
C249	BK	Under Passenger Seat	40, 46
C250	BK	Under Driver Seat	39, 43
C302	BK	Center Body	43
C326	WT	Top of Liftgate	45, 52
C349	BK	Right Rear Quarter Panel	47, 48
C352	BK	Right Side of Frame in Front of Fuel Tank	9, 53
C361	WT	Right Kick Panel	46, 50
C362	BK	Right Kick Panel	46, 50
C363	WT	Left Side Instrument Panel	35, 50
C364	BK	Left Side Instrument Panel	35, 50
C365	WT	Right Side B-Pillar	47, 51
C366	WT	Left Side B-Pillar	44, 51
Capacitor-Ignition	BK	Right Side Engine Compartment	17
Clockspring C1	WT	At Steering Column	32
Clockspring C2	BK	Steering Wheel	34
Clockspring C3	BK	Steering Wheel	34
Clockspring C4	YL	At Steering Column	32
Cluster C1	GY	Left Side of Instrument Panel	31
Cluster C2	GY	Left Side of Instrument Panel	31
Cluster C3	WT	Left Side of Instrument Panel	31
Clutch-A/C Compressor	BK	At A/C Compressor	11, 15, 16
Coil-Ignition-No. 1 (3.7L)	BK	Left Top Engine	10
Coil-Ignition-No. 1 (4.7L)	BK	Left Top Engine	14
Coil-Ignition-No. 1 (5.7L)	BK	Left Top Engine	24
Coil-Ignition-No. 2 (3.7L)	BK	Right Top Engine	11
Coil-Ignition-No. 2 (4.7L)	BK	Right Top Engine	15
Coil-Ignition-No. 2 (5.7L)	BK	Right Top Engine	25

CONNECTOR NAME/ NUMBER	COLOR	LOCATION	FIG.
Coil-Ignition-No. 3 (3.7L)	BK	Left Top Engine	10
Coil-Ignition-No. 3 (4.7L)	BK	Left Top Engine	14
Coil-Ignition-No. 3 (5.7L)	BK	Left Top Engine	24
Coil-Ignition-No. 4 (3.7L)	BK	Right Top Engine	11
Coil-Ignition-No. 4 (4.7L)	BK	Right Top Engine	15
Coil-Ignition-No. 4 (5.7L)	BK	Right Top Engine	25
Coil-Ignition-No. 5 (3.7L)	BK	Left Top Engine	10
Coil-Ignition-No. 5 (4.7L)	BK	Left Top Engine	14
Coil-Ignition-No. 5 (5.7L)	BK	Left Top Engine	24
Coil-Ignition-No. 6 (3.7L)	BK	Right Top Engine	11
Coil-Ignition-No. 6 (4.7L)	BK	Right Top Engine	15
Coil-Ignition-No. 6 (5.7L)	BK	Right Top Engine	25
Coil-Ignition-No. 7 (4.7L)	BK	Left Top Engine	14
Coil-Ignition-No. 7 (5.7L)	BK	Left Top Engine	24
Coil-Ignition-No. 8 (4.7L)	BK	Right Top Engine	15
Coil-Ignition-No. 8 (5.7L)	BK	Right Top Engine	25
Control-A/C-Heater C1	BK	Center of Instrument Panel	31
Control-A/C-Heater C2	BK	Center of Instrument Panel	31
Control-A/C-Heater C3	BK	Center of Instrument Panel	31
Control-A/C-Heater-Rear	BK	Center Console	38
Data Link Connector	BK	Lower Left Instrument Panel	28, 31
Fan Module-Condenser Cooling	BK	Front Center of Engine Compartment	9
Generator	GY	At Generator	11, 15, 16, 21, 22
Glass-Liftgate-Heated	-	At Liftgate	52
Glass-Liftgate-Heated Ground	-	At Liftgate	52
Heater-Cushion Pad-Driver	GY	Under Driver Seat	39
Heater-Cushion Pad-Passenger	GY	Under Passenger Seat	40
Heater-Seat Back-Driver	-	Driver Seat	39
Heater-Seat Back-Passenger	-	Passenger Seat	40
Horn No. 1	BK	In front of Left Radiator	3
Horn No. 2	BK	In Front of Left Radiator	3
Injector-Fuel-No. 1 (3.7L)	BK	Left Top Engine	10
Injector-Fuel-No. 1 (4.7L)	BK	Left Top Engine	14
Injector-Fuel-No. 1 (5.7L)	BK	Left Top Engine	24
Injector-Fuel-No. 2 (3.7L)	BK	Right Top Engine	11
Injector-Fuel-No. 2 (4.7L)	BK	Right Top Engine	15
Injector-Fuel-No. 2 (5.7L)	BK	Right Top Engine	25
Injector-Fuel-No. 3 (3.7L)	BK	Left Top Engine	10
Injector-Fuel-No. 3 (4.7L)	BK	Left Top Engine	14
Injector-Fuel-No. 3 (5.7L)	BK	Left Top Engine	24

CONNECTOR NAME/ NUMBER	COLOR	LOCATION	FIG.
Injector-Fuel-No. 4 (3.7L)	BK	Right Top Engine	11
Injector-Fuel-No. 4 (4.7L)	BK	Right Top Engine	15
Injector-Fuel-No. 4 (5.7L)	BK	Right Top Engine	25
Injector-Fuel-No. 5 (3.7L)	BK	Left Top Engine	10
Injector-Fuel-No. 5 (4.7L)	BK	Left Top Engine	14
Injector-Fuel-No. 5 (5.7L)	BK	Left Top Engine	24
Injector-Fuel-No. 6 (3.7L)	BK	Right Top Engine	11
Injector-Fuel-No. 6 (4.7L)	BK	Right Top Engine	15
Injector-Fuel-No. 6 (5.7L)	BK	Right Top Engine	25
Injector-Fuel-No. 7 (4.7L)	BK	Left Top Engine	14
Injector-Fuel-No. 7 (5.7L)	BK	Left Top Engine	24
Injector-Fuel-No. 8 (4.7L)	BK	Right Top Engine	15
Injector-Fuel-No. 8 (5.7L)	BK	Right Top Engine	25
Junction Block C1	GY	Lower Left Kick Panel	31
Junction Block C2	BR	Lower Left Kick Panel	28, 31
Junction Block C3	BK	Lower Left Kick Panel	28, 31, 35
Junction Block C4	GY	Lower Left Kick Panel	28, 31
Junction Block C5	BL	Lower Left Kick Panel	31
Lamp-Center Bezel	BK	At Cigar Lighter	31
Lamp-Dome-Front	WT	Headliner Front	42
Lamp-Dome-Rear	BK	Headliner Rear	42
Lamp-Fog-Left Front	GY	Left Front Fender	1
Lamp-Fog-Right Front	GY	Right Front Fender	1
Lamp-Headlamp-Left	DK GN	Left Front Headlamp Assembly	1
Lamp-Headlamp-Right	DK GN	Right Front Headlamp Assembly	1
Lamp-High Mounted Stop	BK	Top of Liftgate	45, 52, 57
Lamp-License Plate	WT	At Rear License Plate	52
Lamp-Liftgate	BK	At Liftgate	52
Lamp-Park/Turn-Left Front	BK	At Left Headlamp Assembly	1
Lamp-Park/Turn-Right Front	BK	At Right Headlamp Assembly	1
Lamp-Passenger Airbag On/Off Indicator	BK	Instrument Panel	29
Lamp-Reading-Front	BK	At Lamp	42
Lamp-Side Marker-Left Front	BK	At Left Headlamp Assembly	1
Lamp-Side Marker-Right Front	BK	At Right Headlamp Assembly	1
Lamp-Tail/Stop/Turn-Left	BK	At Left Tail Lamp Assembly	56
Lamp-Tail/Stop/Turn-Right	BK	At Right Tail Lamp Assembly	44, 56
Lamp-Vanity-Left	BK	Left Sunvisor	42
Lamp-Vanity-Right	BK	Right Sunvisor	42
Latch-Door-Left Front	BK	At Latch	50
Latch-Door-Left Rear	BK	At Latch	51

CONNECTOR NAME/ NUMBER	COLOR	LOCATION	FIG.
Latch-Door-Right Front	BK	At Latch	50
Latch-Door-Right Rear	BK	At Latch	51
Latch-Liftgate	BK	At Liftgate	52
Power Outlet-Instrument Panel	GY	Center of Instrument Panel	31
Media System-Monitor/DVD	BK	At Monitor	42
Mirror-Inside Rearview C1	BK	At Mirror	42
Mirror-Inside Rearview C2	BK	At Mirror	42
Mirror-Outside Rearview- Driver	BK	Left Door	50
Mirror-Outside Rearview- Passenger	BK	Right Door	50
Module-Antilock Brakes	BK	Lower Left Kick Panel	9
Module-Brake Provision		Left Rear Engine Compartment	31
Module-Electronic Overhead	BK	Front Headliner	42
Module-Front Control C1	BK	Left Side Engine Compartment	8
Module-Front Control C2	BK	Left Side Engine Compartment	8
Module-Front Control IPM	-	At Power Distribution Module	8
Module-Fuel Pump	LT GY	Top of Fuel Tank	53
Module-Hands Free	BK	Right Side Instrument Panel	29
Module-Heated Seat	BK	Right Rear Quarter Panel	47
Module-Integrated Power C1	GY	Left Front Engine Compartment	8
Module-Integrated Power C2	BK	Left Front Engine Compartment	8
Module-Integrated Power Eyelet	-	Right Side of Power Distribution Module	7
Module-Memory Mirror Driver C1	GY	Left Front Door	50
Module-Memory Mirror Driver C2	GY	Left Front Door	50
Module-Memory Mirror Passenger		Right Front Door	50
Module-Occupant Classification C1	BK	Under Passenger Seat	40
Module-Occupant Classification C2	BK	Under Passenger Seat	40
Module-Occupant Restraint Controller C1	YL	Below Center Console	43
Module-Occupant Restraint Controller C2	YL	Below Center Console	36
Module-Power-Blower Motor-Front C1 (ATC)		Front HVAC unit	27
Module-Power-Blower Motor-Front C2 (ATC)		Front HVAC unit	27
Module-Powertrain Control C1	BK	Right Front Engine Compartment	17

CONNECTOR NAME/ NUMBER	COLOR	LOCATION	FIG.
Module-Powertrain Control C2	BK/OR	Right Front Engine Compartment	17
Module-Powertrain Control C3	BK/WT	Right Front Engine Compartment	4
Module-Powertrain Control C4	BK/GN	Right Front Engine Compartment	17
Module-Seat Memory C1	BK	Under Driver Seat	39
Module-Seat Memory C2	BK	Under Driver Seat	39
Module-Seat Memory C3	WT	Under Driver Seat	39
Module-Seat Memory C4	BL	Under Driver Seat	39
Module-Seat Memory C5	BK	Under Driver Seat	39
Module-Sentry Key Remote Entry	BK	At Steering Column	32
Motor-Adjustable Pedals	WT	At Pedals	30
Motor-Blower-Front	BK	Front HVAC Unit	27
Motor-Blower-Rear	NAT	Rear HVAC Unit	48
Motor-IAC (3.7L)	BK	At Throttle Body	10
Motor-IAC (4.7L)	BK	At Throttle Body	14
Motor-Rear Window Wiper	BK	At Liftgate	52
Motor-Seat Adjuster-Driver Horizontal	BK	Under Driver Seat	39
Motor-Seat Adjuster-Driver Recliner	BK	Under Driver Seat	39
Motor-Seat Adjuster-Front Driver Vertical	BK	Under Driver Seat	39
Motor-Seat Adjuster-Passenger Horizontal	BK	Left Side Under Passenger Seat	40
Motor-Seat Adjuster-Passenger Recliner	BK	Right Side Under Passenger Seat	40
Motor-Seat Adjuster-Rear Driver Vertical	BK	Under Driver Seat	39
Motor-Sunroof	BK	At Sunroof	49
Motor-Window-Left Front	BK	In Left Front Door	50
Motor-Window-Left Rear	BK	In Left Rear Door	51
Motor-Window-Right Front	BK	In Right Front Door	50
Motor-Window-Right Rear	BK	In Right Rear Door	51
Motor-Windshield Wiper	BK	Near Power Brake Booster	8
Power Distribution Center eyelet	-	Right Side of Power Distribution Center	7
Power Outlet-Console	GY	At Console	38
Power Outlet-Instrument Panel	GY	Center of Instrument Panel	31
Power Outlet-Rear	GY	Right Rear Quarter Panel	47
Pump-Auxiliary Coolant	BK	Right Side of Engine Compartment	4
Pump Washer-Windshield	BK	Left Front of Engine Compartment	2

CONNECTOR NAME/ NUMBER	COLOR	LOCATION	FIG.
Radio C1	GY	Rear of Radio	31
Radio C2	GY	Rear of Radio	31
Receiver-Satellite	BK	Left Rear Quarter Panel	45
Relay-Adjustable Pedals	-	In Module-Power Distribution	8
Relay-Trailer Tow Left	-	In Module-Power Distribution	8
Relay-Trailer Tow Right	-	In Module-Power Distribution	8
Resistor-Blower Motor-Front (MTC)	BK	Front HVAC Unit	27
Resistor-Blower Motor-Rear	NAT	Rear HVAC Unit	48
Resistor-Condenser Fan		Front Center Engine Compartment	9
Seat Belt-Tensioner-Driver	BK	Base of Left B-Pillar	44
Seat Belt-Tensioner-Passenger	BK	Base of Right B-Pillar	47
Sensor-Accelerator Pedal Position	BK	Center of Instrument Panel	29
Sensor-Adjustable Pedals		Near Adjustable Pedals	28
Sensor-Ambient Air Temperature	BK	Front Center of Engine Compartment	2
Sensor-Battery Temperature	BK	Left Rear Engine Compartment	4
Sensor-Brake Fluid Level	BK	Left Rear Engine Compartment	8
Sensor-Camshaft Position (3.7L)	GY	Right Front Side of Engine	6
Sensor-Camshaft Position (4.7L)	GY	Right Front Side of Engine	18
Sensor-Camshaft Position (5.7L)	GY	Right Front Side of Engine	23
Sensor-Crankshaft Position (3.7L)	BK	Right Front Side of Engine	6
Sensor-Crankshaft Position (4.7L)	BK	Right Front Side of Engine	18
Sensor-Crankshaft Position (5.7L)	BK	Right Front Side of Engine	23
Sensor-Engine Coolant Temperature	BK	Right Front Side of Engine	11, 15, 16
Sensor-Evaporator Temperature	BK	Front HVAC Unit	27
Sensor-Front Impact-Left	YL	Left Front of Engine Compartment	2
Sensor-Front Impact-Right	YL	Right Front of Engine Compartment	2
Sensor-G	BK	Right Side of Instrument Panel	29
Sensor-Infrared	BK	Near T/O For Lamp-Dome-Front	42
Sensor-Input Speed	BK	Right Front of Transmission	13, 18, 26
Sensor-Intake Air Temperature (3.7L)	GY	At Throttle Body	10
Sensor-Intake Air Temperature (4.7L)	GY	At Throttle Body	14

CONNECTOR NAME/ NUMBER	COLOR	LOCATION	FIG.
Sensor-Knock (3.7L/4.7L)	BK	Left Rear of Engine	10
Sensor Knock No. 1 (5.7L)	BK	Left Side of Engine	23
Sensor-Knock No. 2 (5.7L)	BK	Right Side of Engine	23
Sensor-Line Pressure	BK	Left Rear of Transmission	19, 26
Sensor-MAP	GY	Right Front Side of Engine	11, 15, 16
Sensor-Output Speed	BK	Right Rear of Transmission	13, 18, 20, 26
Sensor-Oxygen-Left Front (3.7L)	BK	Left Front of Transmission	10
Sensor-Oxygen-Left Front (4.7L)	BK	Left Front of Transmission	14, 20
Sensor-Oxygen-Left Front (5.7L)	BK	Left Front of Transmission	26
Sensor-Oxygen-Left Rear	BK	Left Rear of Transmission	13, 18, 20, 26
Sensor-Oxygen-Right Front	BK	Right Front of Transmission	13, 19, 26
Sensor-Oxygen-Right Rear	BK	Right Rear of Transmission	13, 19, 26
Sensor-Seat Track Position-Driver	DK GY	Under Driver Seat	39
Sensor-Seat Track Position-Passenger	DK GY	Right Side Under Passenger Seat	40
Sensor-Seat Weight-Left Front	BK	Left Front Under Passenger Seat	40
Sensor-Seat Weight-Left Rear	BK	Left Rear Under Passenger Seat	40
Sensor-Seat Weight-Right Front	BK	Right Front Under Passenger Seat	40
Sensor-Seat Weight-Right Rear	BK	Right Rear Under Passenger Seat	40
Sensor-Side Impact-Left 1	YL	Left Side Near B-Pillar	44
Sensor-Side Impact-Left 2	YL	Left Side Body Behind Left Rear Door	44
Sensor-Side Impact-Left 3	YL	Left Rear Quarter Panel	44
Sensor-Side Impact-Right 1	YL	Right Side Near B-Pillar	47
Sensor-Side Impact-Right 2	YL	Right Side Body Behind Right Rear Door	47
Sensor-Side Impact-Right 3	YL	Right Rear Quarter Panel	47
Sensor-Sun	BK	Right Side of Instrument Panel	29
Sensor-Throttle Position (3.7L)	NAT	At Throttle Body	10
Sensor-Throttle Position (4.7L)	NAT	At Throttle Body	14
Sensor-Transmission Range	LT GN	Left Side of Transmission	13
Sensor-Washer Fluid Level-Front Rear	GY	Left Front of Engine Compartment	2
Sensor-Wheel Speed-ABS-Left Front	BK	Left Front Wheel	9
Sensor-Wheel Speed-ABS-Left Rear	BK	Left Rear Wheel	54



CONNECTOR NAME/ NUMBER	COLOR	LOCATION	FIG.
Sensor-Wheel Speed-ABS-Rear	BK	Near Right Rear Wheel by Crossmember	55
Sensor-Wheel Speed-ABS-Right Front	BK	Right Front Wheel	4
Sensor-Wheel Speed-ABS-Right Rear	BK	Right Rear Wheel	54
Servo-Speed Control	BK	Left Front Engine Compartment	8
Solenoid-Brake Transmission Interlock	BK	At Steering Column	32
Solenoid-EVAP/Purge	BK	Near Power Brake Booster	8
Speaker-Left Front Door	WT	At Left Front Door	50
Speaker-Left Rear Door	WT	At Left Rear Door	51
Speaker-Right Front Door	WT	At Right Front Door	50
Speaker-Right Rear Door	WT	At Right Rear Door	51
Speaker-Subwoofer	WT	Left Rear Quarter Panel	44
Speaker-Tweeter-Left Front (Premium)	WT	Left Front Instrument Panel	29
Speaker-Tweeter-Left Rear (Premium)	BK	Left Rear Door	51
Speaker-Tweeter-Right Front (Premium)	WT	Right Front Instrument Panel	29
Speaker-Tweeter-Right Rear (Premium)	BK	Right Rear Door	51
Starter	-	At Engine Starter Motor	12, 18, 23
Switch-Adjustable Pedals	BL	Left Side of Instrument Panel	28, 31
Switch-Headlamp	BK	Left Side of Instrument Panel	31
Switch-Heated Seat-Driver	RD	Center of Instrument Panel	31
Switch-Heated Seat-Passenger	BL	Center of Instrument Panel	31
Switch-Hood Ajar		Front Center Engine Compartment	9
Switch-Horn	WT	In Steering Wheel	34
Switch-Ignition	BK	At Steering Column	32
Switch-Liftgate Ajar	WT	At Liftgate	52
Switch-Memory Selector		Left Front Door	50
Switch-Mirror	GY	Left Front Door	50
Switch-Multifunction	BK	At Steering Column	32
Switch-Oil Pressure (3.7L)	BK	Right Front of Engine	12
Switch-Oil Pressure (4.7L)	BK	Right Front of Engine	16
Switch-Oil Pressure (5.7L)	BK	Right Front of Engine	23
Switch-Parking Brake	BK	Left Side Instrument Panel	35
Switch-Power Steering Pressure	BK	Left Front of Engine	23
Switch-Power Window-Left Rear	GY	Left Rear Door	51

CONNECTOR NAME/ NUMBER	COLOR	LOCATION	FIG.
Switch-Power Window-Right Rear	GY	Right Rear Door	51
Switch-Remote Radio-Left	BK	Steering Wheel	34
Switch-Remote Radio-Right	BK	Steering Wheel	34
Switch-Seat Belt-Driver		Under Driver Seat	39
Switch-Seat-Driver		At Driver Seat	39
Switch-Seat-Passenger		At Passenger Seat	41
Switch-Speed Control-Left	BK	Steering Wheel	34
Switch-Speed Control-Right	BK	Steering Wheel	34
Switch-Stop Lamp	BK	Left Lower Instrument Panel	28, 31
Switch-Sunroof	BK	At Switch	42
Switch-Tow/Haul Overdrive	NAT	At Lower Steering Column	32
Switch-Traction Control	BK	At Switch	31
Switch-Transfer Case Selector	BK	Center of Instrument Panel	31
Switch-Window/Door Lock Driver C1	GY	Left Front Door	50
Switch-Window/Door Lock Driver C2	GY	Left Front Door	50
Switch-Window/Door Lock Passenger	GY	Right Front Door	50
Switch and Lamp-Glove Box	BK	Right Instrument Panel	29, 36
Throttle Body (5.7L)	BK	Top of Engine	22
Transducer-A/C Pressure	GY	Top of Radiator Fan	9
Wiring-Trailer Tow 4-Way	BK	Near Rear Bumper	55
Wiring-Trailer Tow 7-Way	BK	Near Rear Bumper	55

**GROUNDS**


GROUND	LOCATION	FIG.
G100	Right Side Engine Compartment	17
G102	Left Front Frame	9
G110	Right Front Engine	6
G111	Right Engine Compartment Near Battery	5
G112	Right Front Engine Compartment	4
G113	Left Front Engine Compartment	8
G114	Left Front Engine Compartment	8
G201	Center Body	43
G207	Right Lower Kick Panel	36
G208	Left Lower Kick Panel	28, 31, 36
G210	Right Lower Kick Panel	36
G304	Left Rear Quarter Panel	45
G305	Left Front Frame	9
G306	Center Body	43

**SPLICES**


<b>SPLICE</b>	<b>LOCATION</b>	<b>FIG.</b>
S102	Near T/O for Sensor-Oxygen-Right Front	13, 19
S103	Near T/O for Injector-Fuel No. 8	11, 15, 22
S104	Near T/O for Input Sensor-Speed	13, 19
S105	Near T/O for Sensor-MAP	11, 15, 23
S106	Near T/O for Sensor-Input Speed	13, 18, 26
S107	Near T/O for Sensor-Oxygen-Right Front	13, 19, 26
S108	Near T/O for Module-Powertrain Control C4	17
S109	Near T/O for Module-Powertrain Control C4	17
S110	On Battery Harness Near Battery	5
S113	Near T/O for Sensor-Ambient Air Temperature	2
S114	Near T/O for Sensor-Ambient Air Temperature	2
S115	Near T/O for Sensor-Ambient Air Temperature	2
S117	Near T/O for Sensor-Front Impact-Left	2
S118	Near T/O for Sensor-Front Impact-Left	2
S119	Near T/O for Servo-Speed Control	8
S120	Near T/O for Module-Antilock Brakes	9
S121	Near T/O for Module-Antilock Brakes	9
S122	Near T/O for Solenoid-Proportional Purge	9
S123	Near T/O for C201	31
S124	Near T/O for Junction Block C5	31
S125	Near T/O for Junction Block C5	31
S126	Right Side Engine	25
S127	Right Side Engine	25
S128	Left Side Engine	24
S129	Left Side Engine	24
S130	Left Side Engine	24
S131	Left Side Engine Compartment	8
S132	Left Side Engine Compartment	8
S133	Left Side Engine Compartment	8
S134	Near T/O For Injector-Fuel No. 5	10, 14
S141 (4.7L)	Near Positive Battery Terminal	5
S141 (5.7L)	Near Positive Battery Terminal	22
S176	Near T/O For C108	4
S184	Engine Harness near T/O for C108	17
S185	Near T/O for Injector-Fuel No. 4	11, 15
S186	Near T/O to Motor-IAC	10, 14
S187	Near T/O for Module-Power Distribution C1	8
S188	On HVAC Unit Near T/O for C202	27
S200	Near T/O for Airbag-Passenger Squib	29
S201	Near T/O For Switch-Overdrive	32
S202	Left Front Instrument Panel	28

SPLICE	LOCATION	FIG.
S203	Left Front Instrument Panel	28
S204	Center of Instrument Panel	29
S205	Near T/O for Airbag-Passenger Squib	29
S206	Near T/O for Speaker-Tweeter-Left Front	29
S207	Center of Instrument Panel	29
S208	Center of Instrument Panel	29
S209	Near T/O for Speaker-Tweeter-Left Front	29
S210	In T/O to Cluster C3	31
S211	In T/O for Cluster C1	31
S214	Lower Steering Column	32
S215	Lower Steering Column	32
S300	Body Under Rear Door Sill	44, 47
S301	Left Front Door Near T/O for C364	50
S302	Body Under Rear Door Sill	44, 47
S303	Left Body Between A and B-Pillar	43
S304	Left Body Between A and B-Pillar	43
S305	Left Body Between A and B-Pillar	43
S306	Near T/O for Assembly-Natural Vacuum Leak Detection	53
S307	Left Body Between A and B-Pillar	43
S308	Left Body Between A and B-Pillar	43
S309	Left Body Between A and B-Pillar	43
S310	Left Body Between A and B-Pillar	43
S311	Near T/O for C250	43
S312	Near T/O for C250	43
S313	Near T/O for G306	43
S314	Near T/O for G306	43
S315	Right Body Between A and B-Pillar	46
S316	Right Body Between A and B-Pillar	46
S317	Left Front Door Near T/O for Switch-Memory Selector	50
S318	In T/O for Mirror-Outside Rearview-Driver	50
S319	Left Rear Door Near T/O for C366	51
S320	Left Rear Door Near T/O for C366	51
S321	Near T/O for Speaker-Right Rear Door	51
S322	Near T/O for Speaker-Right Rear Door	51
S323	Near T/O for Lamp-Reading-Front	42
S324	Headliner Near T/O for C222	42
S325	Headliner Near T/O for C222	42
S326	Headliner Near T/O for C222	42
S327	Left Front Door Near T/O for Switch-Mirror	50
S328	Near T/O for Switch-Window-Door Lock Passenger	50
S329	Headliner Near T/O for C222	42
S330	Near T/O for Wiring-Trailer Tow	54
S331	Near T/O for Wiring-Trailer Tow	54


SPLICE	LOCATION	FIG.
S332	Near T/O for Wiring-Trailer Tow	54
S333	Near T/O for Wiring-Trailer Tow	54
S334	In T/O To Sensor-Wheel Speed-ABS-Left Rear	54
S335	Near T/O for Lamp-License Plate	52
S336	In T/O to Sensor-Seat Weight-Right Rear	40
S337	In T/O to Sensor-Seat Weight -Left Rear	40
S338	Near T/O for Mirror-Inside Rearview C2	42
S339	Under Left Seat	N/S
S342	Rear HVAC	48
S343	Rear HVAC	48
S351	Headliner Near T/O for C222	42
S356	Left Body Between A and B-Pillar	43
S358	In T/O for Sensor-Wheel Speed-ABS-Left Rear	54
S359	Near T/O for G306	43
S360	Near Right Rear Wheel on Crossmember	54
S361	Near Right Rear Wheel on Crossmember	54



**Fig. 1 ENGINE COMPARTMENT - RIGHT FRONT**




**Fig. 2 ENGINE COMPARTMENT - FRONT**




**Fig. 3 ENGINE COMPARTMENT - TOP LEFT FRONT**






**Fig. 4 ENGINE COMPARTMENT - RIGHT**




**Fig. 5 BATTERY**





**Fig. 6 LOWER RIGHT FRONT ENGINE (3.7L/4.7L)**



**Fig. 7 PDC AND IPM POWER CONNECTIONS**




Fig. 8 ENGINE COMPARTMENT - LEFT




Fig. 9 ENGINE COMPARTMENT - LEFT FRONT




Fig. 10 ENGINE 3.7L




Fig. 11 ENGINE 3.7L - RIGHT




Fig. 12 ENGINE 3.7L - FRONT






Fig. 13 TRANSMISSION 3.7L





Fig. 14 ENGINE 4.7L



*Fig. 15 ENGINE 4.7L - RIGHT*






Fig. 16 ENGINE 4.7L - FRONT




Fig. 17 ENGINE COMPARTMENT - LEFT AND RIGHT SIDES





Fig. 18 ENGINE AND TRANSMISSION 4.7L



**Fig. 19 TRANSMISSION 3.7L - RIGHT**




Fig. 20 TRANSMISSION 4.7L/5.7L - LEFT







Fig. 21 ENGINE 5.7L



**Fig. 22 ENGINE 5.7L - RIGHT REAR**






Fig. 23 ENGINE 5.7L - FRONT





**Fig. 24 ENGINE 5.7L - TOP LEFT**



**Fig. 25 ENGINE 5.7L - TOP RIGHT**

8126dd2a






Fig. 26 TRANSMISSION 5.7L



81281470

Fig. 27 FRONT HVAC



8126dd35

Fig. 28 INSTRUMENT PANEL - LEFT





Fig. 29 INSTRUMENT PANEL - RIGHT







**Fig. 30 INSTRUMENT PANEL - CENTER LEFT**



**Fig. 31 INSTRUMENT PANEL - LEFT CENTER**




**Fig. 32 STEERING COLUMN**



**Fig. 33 STALK SWITCH HOUSING**





**Fig. 34 STEERING WHEEL**




Fig. 35 LEFT KICK PANEL







Fig. 36 BODY - RIGHT FRONT



**Fig. 37 RIGHT FRONT FENDER**



**Fig. 38 CENTER CONSOLE**



8126d895

Fig. 39 DRIVER SEAT - BOTTOM





Fig. 40 PASSENGER SEAT - BOTTOM





***Fig. 41 PASSENGER SEAT - RIGHT SIDE***




Fig. 42 HEADLINER




Fig. 43 BODY - LEFT SIDE




Fig. 44 BODY - LEFT REAR




Fig. 45 BODY - REAR






Fig. 46 BODY - RIGHT SIDE






8126dd6b

Fig. 47 BODY - RIGHT REAR



*Fig. 48 REAR HVAC*



*Fig. 49 INSIDE ROOF*




Fig. 50 FRONT DOORS





Fig. 51 REAR DOORS



8126dd72

Fig. 52 DECKLID




Fig. 53 CHASSIS - LEFT






Fig. 54 CHASSIS






Fig. 55 CHASSIS - REAR



**Fig. 56 TAIL LAMP**



**Fig. 57 CENTER HIGH MOUNTED STOP LAMP**