




## 8W-31 TRANSMISSION CONTROL SYSTEM


<b>Component</b>	<b>Page</b>
Assembly-Shift Motor/Mode Sensor . . . . .	8W-31-6
Assembly-Transmission Solenoid/Pressure Switch . . . . .	8W-31-2, 7
Assembly-Transmission Solenoid/TRS . . . . .	8W-31-2, 3, 4, 5
Cluster . . . . .	8W-31-9
Fuse 19 . . . . .	8W-31-2, 9
G100 . . . . .	8W-31-10
G113 . . . . .	8W-31-2
G208 . . . . .	8W-31-9
Junction Block . . . . .	8W-31-9
Module-Front Control . . . . .	8W-31-6
Module-Integrated Power . . . . .	8W-31-6


<b>Component</b>	<b>Page</b>
Module-Powertrain Control . . . . .	8W-31-2, 3, 4, 5, 7, 8, 9, 10
Power Distribution Center . . . . .	8W-31-2
Relay-Transmission Control . . . . .	8W-31-2, 3, 4, 7
Sensor-Input Speed . . . . .	8W-31-10
Sensor-Line Pressure . . . . .	8W-31-5
Sensor-Output Speed . . . . .	8W-31-10
Sensor-Transmission Range . . . . .	8W-31-8
Solenoid-Brake Transmission Shift Interlock . . . . .	8W-31-9
Switch-Tow/Haul Overdrive . . . . .	8W-31-9
Switch-Transfer Case Selector . . . . .	8W-31-9












### 3.7L



## 3.7L

