

## 8W-63 POWER SEATS

<b>Component</b>	<b>Page</b>
Electronics . . . . .	8W-63-4
Fuse 27 . . . . .	8W-63-2
Fuse 32 . . . . .	8W-63-4
G201 . . . . .	8W-63-4
G302 . . . . .	8W-63-2, 3, 5
Heater-Seat Back-Driver . . . . .	8W-63-5
Heater-Seat Back-Passenger . . . . .	8W-63-5
Heater-Seat Cushion-Driver . . . . .	8W-63-4, 5
Heater-Seat Cushion-Passenger . . . . .	8W-63-4, 5
Module-Totally Integrated Power . . . . .	8W-63-2, 4
Motor-Seat Adjuster-Driver Horizontal . . . .	8W-63-2
Motor-Seat Adjuster-Front Driver Vertical . . . . .	8W-63-2

<b>Component</b>	<b>Page</b>
Motor-Seat Adjuster-Front Passenger Vertical . . . . .	8W-63-3
Motor-Seat Adjuster-Passenger Horizontal .	8W-63-3
Motor-Seat Adjuster-Rear Driver Vertical . .	8W-63-2
Motor-Seat Adjuster-Rear Passenger Vertical . . . . .	8W-63-3
Switch-Heated Seat-Driver . . . . .	8W-63-4
Switch-Heated Seat-Passenger . . . . .	8W-63-4
Switch-Seat-Driver . . . . .	8W-63-2
Switch-Seat-Passenger . . . . .	8W-63-3









